Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WOSERLD B0DFLGP3QS

WOSERLD Electric Mason Jar Vacuum Sealer Kit

Model: B0DFLGP3QS

Introduction

This manual provides essential instructions for the safe and efficient operation of your WOSERLD Electric Mason Jar Vacuum Sealer Kit. Please read this manual thoroughly before first use and retain it for future reference. This device is designed to create airtight seals on mason jars and vacuum food bags, extending the freshness of your stored items.



Image: The WOSERLD Electric Mason Jar Vacuum Sealer Kit, a compact pink device, shown sealing a wide-mouth mason jar filled with peaches. Other sealed jars with lemons and sauce are visible on a wooden surface.

Product Overview and Components

Your WOSERLD Electric Mason Jar Vacuum Sealer Kit includes the following components:

- Electric Vacuum Sealer Unit
- Storage Cover
- Punch Tool
- Silicone Umbrella (for custom lids)
- Lid Opener
- Charging Cable
- Mason Jar Caps (standard and wide-mouth)



Image: A four-step diagram illustrating the use of the punch tool and silicone umbrella to prepare a standard jar lid for vacuum sealing. Below, individual images of the storage cover, puncher, silicone umbrella, and lid opener are displayed.

Safety Instructions

- Do not immerse the electric vacuum sealer unit in water or other liquids.

- Keep the device out of reach of children.
- Use only the provided charging cable.
- Do not attempt to disassemble or repair the unit yourself. Contact customer support if service is required.
- Ensure jars and lids are clean and dry before sealing to achieve an effective vacuum.
- This device is intended for household use only.

Setup

1. **Charge the Unit:** Before first use, fully charge the electric vacuum sealer unit using the provided charging cable. The LED display will indicate charging status.
2. **Prepare Jars/Lids:** Ensure mason jars and lids are clean and free from any debris or moisture. For custom lids, use the punch tool and silicone umbrella as shown in the 'Product Overview' section.
3. **Assemble for Use:** Attach the appropriate sealing head (for wide-mouth or regular-mouth jars) to the main unit if it's not already assembled.

Operating Instructions

Sealing Mason Jars

1. Place food into the mason jar, ensuring the rim is clean.
2. Place the lid on the jar.
3. Position the electric vacuum sealer unit directly on top of the lid, ensuring it is centered and stable.
4. Press the power button to start the vacuum sealing process. The LED display will show a countdown.
5. The unit will automatically stop when the vacuum is complete.
6. Carefully remove the sealer unit. Test the seal by gently lifting the lid; it should be firmly attached.



Image: A step-by-step guide showing how to vacuum seal a mason jar. Steps include placing food, positioning the sealer, pressing the button, and removing the sealer after the process is complete.



Image: A diagram showing the WOSERLD vacuum sealer unit and its compatibility with two different sizes of mason jar lids: 6.8 cm (ordinary caliber) and 8.5 cm (large caliber), highlighting its versatility.

Sealing Vacuum Food Bags

1. Place food into a compatible vacuum food bag.
2. Ensure the bag's sealing area is clean and flat.
3. Place the electric vacuum sealer unit over the air valve on the vacuum bag.

4. Press the power button to start the vacuum sealing process. The LED display will show a countdown.
5. The unit will automatically stop when the vacuum is complete.
6. Remove the sealer unit and ensure the bag is sealed.



Image: The WOSERLD electric vacuum sealer unit placed on a vacuum food bag containing sausages, demonstrating its use for sealing flexible food storage bags.

Sealing Wine Bottles

To seal wine bottles, use a compatible wine stopper (not always included, may be sold separately). Place the stopper into the bottle opening, then place the vacuum sealer unit over the stopper and activate it as described for jars and bags.

Your browser does not support the video tag.

Video: A demonstration of the WOSERLD Electric Mason Jar Vacuum Sealer Kit in action, showing how to vacuum seal mason jars, vacuum bags, and wine bottles. The video highlights the automatic operation and the LED display countdown.

Maintenance and Cleaning

- Wipe the exterior of the vacuum sealer unit with a soft, damp cloth. Do not use abrasive cleaners or immerse in water.
- Ensure the sealing area of the unit is clean and free of food particles to maintain optimal performance.
- Store the unit in a cool, dry place when not in use.

Troubleshooting

Problem	Possible Cause	Solution
Unit does not turn on.	Battery is low or depleted.	Charge the unit fully using the provided charging cable.
Vacuum seal is not achieved.	Lid or jar rim is dirty/wet; unit not properly centered; lid is damaged.	Ensure lid and jar rim are clean and dry. Reposition the sealer unit to be centered. Inspect lid for damage and replace if necessary.
Unit stops prematurely.	Insufficient battery charge.	Recharge the unit.

Specifications

Brand: WOSERLD

Model: B0DFLGP3QS

Material: Acrylonitrile Butadiene Styrene (ABS)

Color: Pink

Item Weight: 0.8 Pounds

Power Source: Battery Powered (1200mAh high-capacity lithium battery)

Operation Mode: Automatic

Certifications: FCC, CE, RoHS



Image: An abstract diagram depicting strong suction force emanating from the WOSERLD vacuum sealer unit, indicating its powerful sealing capability.

Warranty and Support

For warranty information, technical support, or any inquiries regarding your WOSERLD Electric Mason Jar Vacuum Sealer Kit, please refer to the manufacturer's official website or contact WOSERLD customer service directly. Contact details are typically found on the product packaging or the brand's online presence.

© 2026 WOSERLD. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DFLGP3QS

More documents and user manuals: **https://manuals.plus/**