Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WOPET B0DFLNCYQ1

WOPET Automatic Cat Feeder Instruction Manual

Brand: WOPET | Model: B0DFLNCYQ1

1. Introduction

The WOPET Automatic Cat Feeder is designed to provide scheduled meals for your pets, ensuring they are fed consistently even when you are away. This feeder is ideal for households with multiple cats, offering dual stainless steel bowls and programmable meal controls. It features a large capacity, dual power supply options, and easy-to-clean components for convenience and reliability.



Figure 1: Front view of the WOPET Automatic Cat Feeder with two stainless steel bowls.

2. Setup and Assembly

Follow these steps to assemble and set up your WOPET Automatic Cat Feeder:

1. **Unpack Components:** Carefully remove all components from the packaging. You should have the feeder body, tank lid, tank, tank base, food splitter, and two stainless steel bowls.
2. **Disassemble for Initial Cleaning:**
    - Rotate the tank lid counter-clockwise to align with the "unlock" sign and lift it up.

- Lift the tank from the base by rotating it counter-clockwise to the unlock position and lifting it up.
- Remove the food splitter from the base.
- Clean all removable parts (tank lid, tank, tank base, food splitter, and stainless steel bowls) with mild soap and water. Ensure they are completely dry before reassembly.

3. **Install Desiccant Bag:** Open the desiccant bag compartment located on the underside of the tank lid. Insert the provided desiccant bag to help keep food fresh. Close the compartment securely.
4. **Reassemble Feeder:**
    - Place the tank back onto the base, aligning the arrow on the tank with the "unlocked" icon on the base. Rotate clockwise to lock it into place.
    - Insert the food splitter into the designated slot in the base.
    - Place the two stainless steel bowls onto the feeder base, ensuring they are securely seated.
    - Place the tank lid back on the tank, aligning the arrow on the lid with the "unlocked" icon on the tank. Rotate clockwise to lock it into place.
5. **Connect Power:** Connect the DC power adapter to the feeder and plug it into a wall outlet. For backup power, insert 3 alkaline D batteries (not included) into the battery compartment at the bottom of the feeder.




Figure 2: Dual power supply setup, showing DC adapter and battery compartment.



Figure 3: Visual guide for feeder assembly and power connection.

3. Operating Instructions

The WOPET Automatic Cat Feeder allows for precise control over your pet's feeding schedule and portion sizes. The LCD screen and control buttons facilitate easy programming.

3.1 Setting Current Time

To set the current time on the feeder:

1. Ensure the screen is unlocked. If locked, press and hold the "Settings" button (gear icon) for 2 seconds until the lock icon disappears.
2. Press the "Settings" button once. The clock icon will flash.
3. Use the "Up" and "Down" arrow buttons to adjust the hour. Press "Settings" to confirm the hour.
4. Use the "Up" and "Down" arrow buttons to adjust the minute. Press "Settings" to confirm the minute.
5. The current time is now set.



Figure 4: Close-up of the feeder's LCD screen and control panel.

3.2 Programming Meal Times and Portions

The feeder supports up to 6 meals per day. To program a meal:

1. Ensure the screen is unlocked.
2. Press the "Down" arrow button (V-shaped icon) to select the meal number (1-6). The selected meal number will flash.
3. Press the "Settings" button. The hour digits for that meal will flash. Use the "Up" and "Down" arrows to set the

desired hour. Press "Settings" to confirm.

4. The minute digits for that meal will flash. Use the "Up" and "Down" arrows to set the desired minute. Press "Settings" to confirm.
5. The portion size indicator (P-XX) will flash. Use the "Up" and "Down" arrows to set the desired portion size (1-20 portions, 12g per portion). Press "Settings" to confirm.
6. Repeat for additional meals (up to 6).
7. Once all meals are programmed, press the "Return" button (curved arrow icon) to exit the programming mode.




Figure 5: Example of a programmed feeding schedule.

3.3 Voice Recording

You can record a 10-second voice message to call your pets to their meals. This message will play automatically at each scheduled feeding time.

1. Ensure the screen is unlocked.
2. Press and hold the "Microphone" button (microphone icon) for 3 seconds. The feeder will beep, indicating it's ready to record.
3. Speak your message clearly into the microphone. The recording will automatically stop after 10 seconds or when you release the button.
4. A double beep will confirm that your recording has been successfully saved.



Figure 6: Personalized voice message feature.

3.4 Manual Feeding

To dispense food manually outside of the scheduled times:

- Ensure the screen is unlocked.
- Press the "Manual Feed" button (paw print icon). One portion of food will be dispensed immediately.

- You can press this button multiple times to dispense additional portions.

3.5 Video Demonstration of Interface Operation

For a visual guide on setting up feeding times and operating the interface, please watch the official seller video below:

Your browser does not support the video tag.

Video 1: "Automatic Cat Feeders for 2 Cats Interface operation video" by Petke Technology Co., Limited STORE. This video demonstrates how to navigate the feeder's interface to set up feeding schedules and other features.

4. Maintenance and Cleaning

Regular cleaning ensures the longevity and hygiene of your WOPET Automatic Cat Feeder. The detachable design makes cleaning simple.

- **Disassembly:** Follow the disassembly steps outlined in Section 2.2 to remove the tank lid, tank, tank base, food splitter, and stainless steel bowls.
- **Cleaning:** Wash all removable parts with mild soap and water. Avoid abrasive cleaners. The main feeder body (containing electronics) should only be wiped with a damp cloth. Do not submerge the main body in water.
- **Drying:** Ensure all parts are completely dry before reassembling to prevent moisture damage and maintain food freshness.
- **Desiccant Bag Replacement:** Replace the desiccant bag every few weeks or as needed to ensure optimal food freshness.



Figure 7: Detachable parts for thorough cleaning.

5. Troubleshooting

Problem	Possible Cause	Solution
Feeder not powering on / Screen is blank.	No power supply; batteries are dead or not inserted correctly; power adapter issue.	Check if the DC adapter is securely plugged into the feeder and the wall outlet. Ensure batteries (if used) are new and correctly oriented. Try a different power outlet.

Problem	Possible Cause	Solution
Food not dispensing at scheduled times.	Incorrect time setting; feeder is locked; food hopper is empty; food is clogged; power interruption.	Verify current time and meal schedule settings. Unlock the screen if it's locked. Refill the food hopper. Check for food clogs in the dispenser mechanism. Ensure continuous power supply (use backup batteries).
Uneven food distribution between bowls.	Food splitter misalignment; kibble size inconsistency.	Ensure the food splitter is correctly installed and aligned. Use kibble sizes between 2-12mm for optimal performance.
Voice message not playing.	No message recorded; low volume.	Re-record the voice message following the instructions in Section 3.3. Ensure the volume is set appropriately.
Feeder clock loses time or resets.	Power interruption without battery backup; internal clock issue.	Ensure backup batteries are installed and functional. If the issue persists, contact customer support.

6. Specifications

Feature	Detail
Brand	WOPET
Model	B0DFLNCYQ1
Item Weight	3.74 pounds
Item Dimensions (LxWxH)	7.8 x 7.48 x 13 inches
Material	Stainless Steel
Color	Black
Food Storage Capacity	4L / 17 cups
Kibble Size Compatibility	2-12mm (dry food only)
Meals Per Day	Up to 6 meals
Portions Per Meal	1-20 portions (approx. 12g per portion)
Voice Recording	10-second personalized message
Power Supply	DC power adapter; 3 alkaline D batteries (backup)
Special Features	Easy to Use, Feeding Schedule, Dual Power Supply, Easy to Clean, Desiccant Bag

7. Warranty and Support

Specific warranty details for the WOPET Automatic Cat Feeder are not provided in the product information. For warranty claims, technical support, or any inquiries regarding your feeder, please contact WOPET customer service directly through their official website or the contact information provided with your purchase.

You can visit the WOPET Store on Amazon for more information:WOPET Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question