

[Manuals.plus](#) /

› [Yaber PROJECTOR](#) /

› Yaber L2s 1080P Projector with WiFi 6 and Bluetooth User Manual

Yaber PROJECTOR L2s

Yaber L2s 1080P Projector User Manual

Model: L2s

1. INTRODUCTION

Thank you for choosing the Yaber L2s 1080P Projector. This manual provides essential information for setting up, operating, and maintaining your projector. Please read it thoroughly before use to ensure optimal performance and longevity of your device.



Image: The Yaber L2s Projector, a compact device with a lens on the front and a remote control beside it.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x Yaber L2s Projector
- 1 x HDMI Cable
- 1 x Power Cord
- 1 x Projector Lens Cover
- 1 x Remote Control
- 1 x Cleaning Kit

3. PRODUCT OVERVIEW

The Yaber L2s projector is designed for versatile home entertainment. It features a robust lens, integrated speakers, and multiple connectivity ports for various devices.

3.1 Front and Rear Panels

One Projector, Unlock Endless Fun

NETFLIX

YouTube

hulu

Disney+

prime video



iPad/iPhone



Speakers



USB Drive



PS4/5



Headphone



TV Stick



(Note: TV Stick not included)



Image: The rear panel of the Yaber L2s Projector, displaying various input and output ports including HDMI, USB, and a 3.5mm audio jack. The rear panel includes:

- **HDMI Port:** For connecting devices like laptops, gaming consoles, or TV sticks.
- **USB Port:** For connecting USB drives to play media files.
- **3.5mm Audio Jack:** For connecting external headphones or speakers.
- **Power Input:** For connecting the power cord.

4. SETUP

4.1 Placement

Position the projector on a stable, flat surface. Ensure there is adequate ventilation around the device. The projection distance influences the screen size. Refer to the table below for recommended distances:



Image: A chart illustrating recommended projection distances for various screen sizes, ranging from 4 feet for a 40-inch screen to 15 feet for a 150-inch screen.

Projection Distance vs. Screen Size

Distance (ft)	Screen Size (inch)
4.0	40
6.0	60
8.0	80
10.0	100
12.0	120
15.0	150

4.2 Power Connection

- 1. Connect the power cord to the projector's power input.
- 2. Plug the other end of the power cord into a power outlet.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press the power button on the projector or the remote control to turn the device on or off.

5.2 Seamless Autofocus and Auto Vertical Keystone

The Yaber L2s features seamless autofocus and auto vertical keystone correction. Upon startup or movement, the projector will automatically adjust the image for clarity and correct trapezoidal distortion vertically. Manual correction may be needed for horizontal alignment if the projector is not positioned directly in front of the screen.

Seamless Autofocus, Sharp Images Instantly



Auto
Focus



Auto Vertical
Keystone



100-50%
Zoom



Image: A visual representation of the projector's automatic focus, vertical keystone correction, and digital zoom capabilities, ensuring a clear and properly shaped image.

5.3 Zoom Function

The projector supports a 50% zoom function, allowing you to adjust the image size without moving the projector. This can be controlled via the remote control.

5.4 Connectivity (WiFi 6 & Bluetooth)

The Yaber L2s supports WiFi 6 for fast and stable wireless streaming and Bluetooth for audio connections.

- **WiFi 6:** Navigate to the projector's settings menu, select 'Network', and connect to your desired WiFi 6 network. This enables screen mirroring from compatible devices.
- **Bluetooth:** In the settings menu, select 'Bluetooth' to pair with external Bluetooth speakers or headphones. The projector can also function as a standalone JBL Bluetooth speaker for music playback.

Level Up Gaming with Unbreakable Connections




Image: A split screen demonstrating the speed of WiFi 6, showing a clear, fast-moving image on one side and a blurry, loading image on the other, highlighting the benefit of stable connections.

Sound That Roams Free



Image: A Yaber L2s Projector projecting a sunset scene, while also connected via Bluetooth to an external speaker, illustrating its dual functionality as a projector and a Bluetooth speaker.

5.5 Audio (JBL Sound)

Equipped with dual 8W JBL speakers, the projector delivers clear and powerful audio. For an enhanced experience, you can connect external audio systems via Bluetooth or the 3.5mm audio jack.

Sound That Moves You Crisp and Clear

SOUND BY



2x8W




Image: An exploded view of the Yaber L2s Projector, emphasizing the two 8W JBL speakers integrated into its design, indicating high-quality audio output.

5.6 Input Sources

Connect various devices to the projector using the available ports:

- **HDMI:** Connect laptops, gaming consoles (PS5), or TV sticks for streaming content.
- **USB:** Plug in a USB drive to play local media files (videos, photos, music).
- **TV Stick:** For access to streaming platforms like Netflix, YouTube, Hulu, Disney+, and Prime Video, plug a TV stick into the HDMI port. (TV stick sold separately).







Image: A graphic illustrating the Yaber L2s Projector's compatibility with various devices and streaming services, including Netflix, YouTube, Hulu, Disney+, Prime Video, iPads/iPhones, external speakers, USB drives, PS4/PS5, headphones, and TV sticks, connected via HDMI and USB ports.

6. MAINTENANCE

6.1 Cleaning the Lens

Use the provided cleaning kit or a soft, lint-free cloth to gently wipe the projector lens. Avoid abrasive materials or harsh chemicals.

6.2 Dust Filter

The projector features a built-in dust filter to minimize dust accumulation and maintain performance. Regularly check and clean the filter as needed to ensure optimal airflow and prevent overheating.



Image: A cutaway diagram of the Yaber L2s Projector highlighting its built-in dust filter, designed to block up to 95% of dust and reduce maintenance requirements.

7. TROUBLESHOOTING

If you encounter issues with your Yaber L2s Projector, refer to the following common solutions:

- **No Image/Blurry Image:** Ensure the projector is powered on and the lens cover is removed. The autofocus feature should provide a clear image; if not, try repositioning the projector or checking for obstructions.
- **No Sound:** Verify that the volume is not muted and is set to an audible level. Check Bluetooth connections if using external speakers. Ensure the audio output is correctly configured in the projector's settings.
- **Connectivity Issues (WiFi/Bluetooth):** Restart the projector and the connected device. Ensure the projector is within range of the WiFi router or Bluetooth device. Re-pair Bluetooth devices if necessary.
- **Remote Control Not Working:** Check the batteries in the remote control. Ensure there are no obstructions between the remote and the projector's IR receiver.
- **Overheating:** Ensure adequate ventilation around the projector. Clean the dust filter if it appears clogged.

For further assistance, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	Yaber PROJECTOR
Model Number	L2s
Display Resolution	1920 x 1080 (Native 1080P)
Connectivity Technology	3.5mm Jack, Bluetooth, HDMI, USB, Wi-Fi 6
Special Features	Sound by JBL, Seamless Autofocus, Auto Vertical Keystone, 100-50% Zoom, Built-In 8W*2 Speakers
Item Weight	5.06 pounds
Product Dimensions	7.48 x 6.3 x 9.06 inches

Feature	Specification
Recommended Uses	Business, Education, Home Cinema

9. WARRANTY AND SUPPORT

Yaber PROJECTOR provides customer support for its products. For any inquiries, technical assistance, or warranty claims, please contact us directly.

Customer Support Email: service@yaber.com

Please have your model number (L2s) and purchase information ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question