Bellemave TH-00273-P

Bellemave Twin Over Twin Bunk Bed with Trundle Instruction Manual

Model: TH-00273-P

1. Product Overview

The Bellemave Twin Over Twin Bunk Bed with Trundle is designed to provide a versatile and space-saving sleeping solution. This bed features a twin-over-twin configuration, a pull-out trundle bed for additional sleeping space, and the ability to convert into two separate twin-sized beds. Constructed from quality rubber wood, it offers durability and stability.



Image 1: The Bellemave Twin Over Twin Bunk Bed with Trundle in Espresso finish, showcasing its compact design.



Image 2: Detailed dimensions of the bunk bed, including length, width, and height for both the main structure and the trundle.

2. Safety Information

Adherence to safety guidelines is crucial for the safe use of this bunk bed. Please read and understand all instructions before assembly and use.

- Always use the ladder and guardrails carefully to prevent falls.
- This bed frame is intended for children aged 6 and above.
- Always follow the assembly instructions precisely to ensure stability and prevent collapse.
- Inspect the bed frame regularly for any signs of damage or wear, and repair or replace components as necessary to prevent splinters or other injuries.
- Ensure mattresses used on both bunks and the trundle are of the appropriate size (Twin) and thickness to maintain guardrail effectiveness.



Image 3: A close-up view of the full-length guardrails on the top bunk, designed for enhanced safety.

3. Setup and Assembly

The Bellemave Twin Over Twin Bunk Bed with Trundle is delivered in two individual packages. A comprehensive instruction manual and all necessary hardware are included to guide you through the assembly process. It is recommended to assemble the bed with at least two adults.

Assembly Steps:

1. Unpack all components and verify against the parts list in the included manual.
2. Follow the step-by-step diagrams and instructions provided in the manual.
3. Ensure all bolts and screws are securely tightened, but do not overtighten to avoid damaging the wood.
4. Once assembled, double-check all connections for stability before use.

4. Operating Instructions

Using the Bunk Bed Configuration:

The standard configuration provides two sleeping surfaces, one above the other, accessible via the integrated ladder. The trundle bed can be pulled out from underneath the lower bunk for an additional sleeping area.




Image 4: The bunk bed with the trundle fully extended, providing a third sleeping space.

Converting to Two Separate Twin Beds:

This bunk bed can be separated into two independent twin-sized beds. Refer to the assembly manual for specific instructions on how to safely disassemble the bunk bed structure and reassemble it into two individual beds.



Image 5: The bunk bed disassembled and configured as two separate twin beds, demonstrating its versatility.

Video Demonstration:

Video 1: A demonstration of the Bellemave Bunk Bed with Trundle, showing its features and functionality.

5. Maintenance

To ensure the longevity and appearance of your Bellemave bunk bed, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Hardware Check:** Periodically check all bolts, screws, and connections to ensure they remain tight. Retighten as needed to maintain structural integrity.
- **Avoid Excessive Moisture:** Protect the wood from prolonged exposure to moisture, which can cause warping or damage.
- **Sunlight Exposure:** Minimize direct sunlight exposure to prevent fading or discoloration of the wood finish.



Image 6: Detail of the solid wooden slats, which provide robust support for the mattress and contribute to the bed's sturdy construction.

6. Troubleshooting

If you encounter any issues with your bunk bed, consider the following common troubleshooting steps:

- **Wobbling or Instability:** This is often caused by loose hardware. Re-check and tighten all bolts and screws throughout the entire frame. Ensure the bed is on a level surface.
- **Difficulty with Trundle Movement:** Check for any obstructions under the trundle bed. Ensure the wheels are clean and free of debris. If the trundle is new, it may require a few uses to move smoothly.
- **Squeaking Noises:** Squeaking can result from loose connections. Identify the source of the squeak and tighten the corresponding hardware. Applying a small amount of wax or lubricant to friction points (not on load-bearing joints) can sometimes help.
- **Missing Parts:** If you discover any missing parts during assembly, refer to the contact information in your assembly manual for assistance.

7. Specifications

Feature	Detail

Feature	Detail
Brand	Bellemave
Model Number	TH-00273-P
Size	Twin over Twin
Product Dimensions	77.3"L x 43.5"W x 61.3"H
Color	Espresso
Finish Type	Painted
Material	Rubber Wood
Special Feature	No Box Spring Needed
Included Components	Guardrails, Slats
Compatible Mattress Size	Twin
Assembly Required	Yes
Item Weight	63 pounds
UPC	733805185527

8. Warranty and Support

For specific warranty details, please refer to the documentation included with your product or contact Bellemave customer support directly. General support for this product includes:

- **90-Day Easy Returns:** If purchased through Amazon, this product is eligible for 90-day easy returns.
- **Customer Support:** For any questions, concerns, or assistance with assembly or parts, please reach out to Bellemave customer service. Contact information can typically be found in the product packaging or on the manufacturer's official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question