



Manuals.plus /

› SUPERJARE /

› SUPERJARE Drafting Chair and Huuger 47 Inch Computer Desk Bundle User Manual

SUPERJARE B0DFM1QS2P

SUPERJARE Drafting Chair and Huuger 47 Inch Computer Desk Bundle User Manual

Model: B0DFM1QS2P

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your SUPERJARE Drafting Chair and Huuger 47 Inch Computer Desk bundle. Please read all instructions carefully before assembly and use to ensure safe and proper functionality.



Image: The SUPERJARE Drafting Chair and Huuger 47 Inch Computer Desk bundle set up in a modern office environment.

SETUP AND ASSEMBLY

Assembly is required for both the drafting chair and the computer desk. Follow the steps below carefully. It is recommended to assemble on a soft, clean surface to prevent scratches.

Drafting Chair Assembly

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list (refer to the included physical manual for a complete list).
2. **Attach Casters:** Insert the five casters into the holes at the end of each leg of the chair base. Push firmly until they click into place.
3. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the chair base.
4. **Attach Footrest Ring:** Slide the footrest ring over the gas lift cylinder and secure it at your desired height using the adjustment knob.
5. **Attach Seat Plate:** Secure the seat plate to the underside of the seat cushion using the provided screws. Ensure the front of the seat plate faces the front of the seat.

6. **Connect Seat to Gas Lift:** Place the assembled seat onto the gas lift cylinder, ensuring it is centered and fully seated.
7. **Attach Backrest:** Connect the backrest to the seat plate mechanism using the provided screws. Adjust the backrest height and angle as desired. The backrest is removable for different use needs.



Image: Detailed dimensions of the SUPERJARE Drafting Chair, showing height, seat width, and footrest height ranges.



Image: The SUPERJARE Drafting Chair demonstrating its removable backrest feature, allowing for versatile use.


Computer Desk Assembly

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list (refer to the included physical manual for a complete list).
2. **Assemble Frame:** Connect the desk legs and support beams according to the diagrams in your physical manual. Ensure all screws are tightened securely.
3. **Attach Desktop Panels:** Place the desktop panels onto the assembled frame and secure them with the provided screws.
4. **Install Monitor Stand:** Attach the monitor stand to the desktop using the designated fasteners. Ensure the power outlets and USB ports are accessible.
5. **Insert Drawers:** Assemble the fabric drawers and slide them into the designated compartments on the desk. The desk features a reversible design, allowing the drawer unit to be installed on either the left or right side.
6. **Connect Power:** Plug the desk's power cord into a standard wall outlet to activate the power outlets and LED lights.
7. **Apply LED Light Strip:** Adhere the LED light strip to the desired location on the desk, typically along the

back edge of the monitor stand or desktop, ensuring the controller is accessible.



Image: The Huuger 47 Inch Computer Desk set up with a monitor, keyboard, and various accessories, showcasing its functional design.



Huuger

Image: Detailed dimensions of the Huuger 47 Inch Computer Desk, including desktop size, monitor stand, and drawer unit measurements.




Image: Illustration demonstrating the reversible design of the Huuger 47 Inch Computer Desk, allowing the drawer unit to be installed on either side.

OPERATING INSTRUCTIONS

Drafting Chair Operation

- **Height Adjustment:** To adjust the seat height, lift the lever located under the seat. While seated, lift the lever to lower the seat. To raise the seat, lift the lever while standing or with minimal weight on the seat. The height can be adjusted from 23.6" to 32.2".
- **Footrest Adjustment:** Loosen the knob on the footrest ring, slide the ring to the desired height, and then tighten the knob securely.
- **Backrest Adjustment/Removal:** The backrest can be adjusted for angle and height. It can also be removed if a backless stool is preferred. Refer to the assembly section for reattachment.
- **Mobility:** The chair is equipped with 5 durable wheels for smooth movement across various floor surfaces.

Computer Desk Operation

- **Power Outlets:** The monitor stand includes 4 AC outlets and 2 USB ports. Plug your devices directly into these ports for convenient power access. Ensure the desk's main power cord is connected to a wall outlet.

- **LED Light Strips:** The LED light strip is controlled via an RF remote.
 - **Power On/Off:** Use the power button on the remote to turn the lights on or off.
 - **Color Selection:** Choose from 20 vibrant colors using the color buttons on the remote.
 - **Dynamic Modes:** Select from 22 dynamic modes for various lighting effects.
 - **Brightness Adjustment:** Adjust the brightness level (5 levels available) using the dedicated buttons.
- **Monitor Stand:** Use the integrated monitor stand to elevate your display, promoting better ergonomics and reducing neck and back strain.
- **Storage Drawers:** Utilize the four fabric drawers for organizing office supplies, documents, or personal items.



Removable Backrest

Meet different use needs with comfortable backrest width

Image: A close-up view of the SUPERJARE Drafting Chair's 4-inch thick seat cushion, highlighting its sponge padding, high elasticity, and waterproof PVC material for comfort.

Thick Seat Cushion for Extra Comfort



Image: An illustration of the RGB LED Light Strip controller and its features, including power, scene modes, brightness adjustment, color selection, and music/timing modes.

MAINTENANCE

- **Cleaning the Chair:** Wipe the PVC seat cushion and backrest with a damp cloth and mild soap. Avoid harsh chemicals that may damage the material. Clean the chrome base and casters with a soft, dry cloth.
- **Cleaning the Desk:** Wipe the laminated wood surface with a soft, damp cloth. Avoid abrasive cleaners. For spills, wipe immediately to prevent staining.
- **Caster Maintenance:** Periodically check casters for hair or debris and clean as needed to ensure smooth rolling.
- **Tighten Fasteners:** Regularly check all screws and bolts on both the chair and desk and tighten them if they have loosened over time to maintain stability.
- **Electrical Components:** Ensure the power cord for the desk is not pinched or damaged. Do not attempt to repair electrical components yourself.

TROUBLESHOOTING

Drafting Chair Issues

- **Chair Sinks or Does Not Adjust Height:**

Solution: Ensure the gas lift lever is fully engaged. If the issue persists, the gas lift cylinder may be faulty and require replacement. Contact customer support.

- **Chair Wobbles:**

Solution: Check all screws and bolts on the chair base and seat plate. Tighten any loose fasteners. Ensure the casters are fully inserted into the base.

- **Casters Not Rolling Smoothly:**

Solution: Remove any hair, dust, or debris from the caster wheels. Lubricate the caster stems if necessary.

Computer Desk Issues

- **LED Lights Not Working:**

Solution: Ensure the desk's main power cord is securely plugged into a working wall outlet. Check the connection of the LED strip to its controller and the controller to the desk's power supply. Verify the remote control has working batteries and is pointed at the receiver.

- **Power Outlets Not Functioning:**

Solution: Confirm the desk's main power cord is plugged into a live wall outlet. Test the wall outlet with another device. Check for any tripped circuit breakers in your home or office.

- **Desk Wobbles:**

Solution: Ensure all frame screws and desktop fasteners are securely tightened. Adjust the leveling feet (if present) on the bottom of the desk legs to compensate for uneven floors.

SPECIFICATIONS

SUPERJARE Drafting Chair

- **Brand:** SUPERJARE
- **Seat Material:** PVC, Sponge padded
- **Base Type:** Metal/Plastic with 5 casters
- **Adjustable Height:** 23.6" to 32.2"
- **Special Features:** Adjustable footrest, Removable backrest

Huuger 47 Inch Computer Desk

- **Brand:** Huuger (part of SUPERJARE bundle)
- **Desk Design:** Computer Desk
- **Color:** Black
- **Top Material Type:** Wood
- **Finish Type:** Laminated
- **Working Surface Diagonal Length:** 47 Inches
- **Special Features:** Monitor Stand, 4 AC outlets, 2 USB ports, LED Light Strips, 4 Fabric Drawers, Reversible Design
- **Included Components:** Desk, Chair

WARRANTY INFORMATION

Specific warranty details for this product bundle are typically provided with the purchase documentation or on

the manufacturer's official website. Please refer to the warranty card included in your product packaging or visit the SUPERJARE website for the most current warranty terms and conditions.

CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your SUPERJARE Drafting Chair and Huuger 47 Inch Computer Desk bundle, please contact SUPERJARE customer support. Contact information can typically be found on the product packaging, the included manual, or the official SUPERJARE website.

When contacting support, please have your product model number (B0DFM1QS2P) and purchase date readily available.