#### Manuals+

Q & A | Deep Search | Upload

## manuals.plus /

- KING /
- KING KGP5050BFFD 4 Burner Gas Stove User Manual

#### KING KGP5050BFFD

# KING KGP5050BFFD 4 Burner Gas Stove User Manual

Model: KGP5050BFFD

#### INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your KING KGP5050BFFD 4 Burner Gas Stove. Please read these instructions carefully before using the appliance and retain them for future reference.

The KING KGP5050BFFD is a 4-burner gas stove with a gas oven, featuring a flame failure device (FFD) for enhanced safety and auto-ignition for the burners. The oven utilizes manual ignition.

# **SAFETY INFORMATION**

**WARNING:** Improper installation, adjustment, alteration, service, or maintenance can cause injury or property damage. Refer to this manual. For assistance or additional information, consult a qualified installer, service agency, or the gas supplier.

- Ensure adequate ventilation when operating the appliance.
- Do not store flammable materials near the stove.
- Keep children away from the appliance during operation.
- Always check that all burner and oven controls are in the "OFF" position after use.
- In case of a gas leak, immediately turn off the gas supply, open windows, and do not operate any electrical switches or appliances.
- The Flame Failure Device (FFD) automatically cuts off the gas supply if the flame extinguishes, preventing gas leaks.

## PRODUCT OVERVIEW

The KING KGP5050BFFD gas stove is designed for efficient cooking with its four gas burners and a spacious gas oven. Key components include:

- 4 Gas Burners with Brass Burner Caps
- Enamel Grids
- · Control Knobs for Burners and Oven
- · Gas Oven with Double Glass Door

- Splash Guard Panel
- Adjustable Feet





Image 1: Front view of the KING KGP5050BFFD 4 Burner Gas Stove, showing the four burners, control panel, oven with glass door, and splash guard.

## SETUP AND INSTALLATION

Installation must be performed by a qualified technician in accordance with local regulations and gas safety standards.

# **Unpacking**

- 1. Carefully remove the appliance from its packaging.
- 2. Inspect for any damage. Report any damage to your supplier immediately.
- 3. Remove all protective films and packaging materials.

# **Positioning**

- Place the stove on a stable, level surface.
- Ensure adequate clearance from combustible materials (refer to local building codes).
- The appliance dimensions are approximately 50 cm (W) x 54 cm (D) x 80 cm (H).

#### **Gas Connection**

- Connect the stove to the gas supply using an approved flexible gas hose and regulator.
- Check all connections for gas leaks using a soapy water solution. Do not use an open flame.

## **OPERATING INSTRUCTIONS**

## **Using the Gas Burners**

- 1. Ensure the gas supply is open.
- 2. Place your cookware on the enamel grid over the desired burner.
- 3. Push in and turn the corresponding burner control knob counter-clockwise to the high flame setting.
- 4. The auto-ignition system will spark and ignite the gas. Hold the knob in for a few seconds to allow the flame failure device to engage.
- 5. Adjust the flame size by turning the knob between the high and low settings.
- 6. To turn off, turn the knob clockwise to the "OFF" position.

## **Using the Gas Oven**

- 1. Ensure the gas supply is open.
- 2. Open the oven door.
- 3. Locate the oven burner at the bottom of the oven cavity.

- 4. Push in and turn the oven control knob counter-clockwise to the desired temperature setting.
- 5. Using a long match or a gas lighter, manually ignite the oven burner through the ignition port.
- 6. Once ignited, hold the knob in for a few seconds to allow the flame failure device to engage.
- 7. Close the oven door and allow it to preheat to the set temperature.
- 8. To turn off, turn the knob clockwise to the "OFF" position.

# MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your gas stove.

# **General Cleaning**

- Always ensure the appliance is cool and the gas supply is turned off before cleaning.
- Wipe exterior surfaces with a damp cloth and mild detergent. Avoid abrasive cleaners.
- Clean the enamel grids and burner caps with warm soapy water. Ensure they are completely dry before reassembling.
- The oven interior can be cleaned with specialized oven cleaners, following the product instructions.

#### **Burner Maintenance**

- Periodically check burner ports for blockages. Use a fine wire or needle to clear any debris.
- Ensure burner caps are correctly seated after cleaning.

## **TROUBLESHOOTING**

Problem	Possible Cause	Solution
Burner does not ignite	No gas supply; Igniter dirty/blocked; Burner cap not seated correctly	Check gas valve; Clean igniter and burner ports; Reseat burner cap
Flame goes out after ignition (FFD)	Knob not held long enough; Thermocouple dirty/faulty	Hold knob in for 5-10 seconds; Clean thermocouple; Contact service
Oven not heating	No gas supply; Oven burner not ignited; Thermostat issue	Check gas valve; Re-ignite oven burner manually; Contact service

#### **SPECIFICATIONS**

• Model: KGP5050BFFD

• Type: 4 Burner Gas Stove with Gas Oven

Ignition (Burners): Auto Ignition
 Ignition (Oven): Manual Ignition

• Safety Feature: Flame Failure Device (FFD) on all burners and oven

• Oven Capacity: 57 Liters

• Dimensions (W x D x H): 50 cm x 54 cm x 80 cm

• Color: Black

• Power Source: Gas

# WARRANTY AND SUPPORT

This KING KGP5050BFFD gas stove comes with a**24-month supplier warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical assistance, service, or warranty claims, please contact your retailer or the authorized service center.

For further information or to locate an authorized service provider, please visit the manufacturer's website or refer to the contact details provided with your purchase.

KING KGP5050BFFD User Manual | Version 1.0 | Date: October 2024

#### Related Documents - KGP5050BFFD



## King KKM1173 Frezzio Katı Meyve Sıkacağı Kullanım Kılavuzu ve Garanti Bilgileri

Kullanım kılavuzu ve garanti bilgileri için King KKM1173 Frezzio Katı Meyve Sıkacağı. Ürün özellikleri, güvenlik talimatları, bakım ve temizlik önerileri.



#### King KBÜ700 Larsen Buharlı Ütü Kullanım Kılavuzu

Detaylı kullanım kılavuzu, güvenlik talimatları, bakım ve sorun giderme bilgileri içeren King KBÜ700 Larsen buharlı ütü kullanım rehberi.



## King K451 Haz Turkish Coffee Maker User Manual and Warranty Information

Detailed user manual and warranty information for the King K451 Haz Turkish Coffee Maker, including operating instructions, safety warnings, cleaning procedures, troubleshooting, and warranty terms.



#### KING QUEST VQ4100 Satellite TV Antenna Quick Start Guide

Quick reference guide for setting up the KING QUEST VQ4100 satellite TV antenna for DIRECTV reception, covering placement, connections, and initial scanning.



# King KV1716 Barva Kumandalı Ayaklı Vantilatör Kullanım Kılavuzu

King KV1716 Barva kumandalı ayaklı vantilatörünüzü güvenli ve etkili bir şekilde kullanmak, monte etmek ve bakımını yapmak için detaylı kullanım kılavuzunu ve garanti şartlarını inceleyin.



# King KKM692 Beefy Et Kıyma Makinesi Kullanım Kılavuzu ve Garanti Bilgileri

King KKM692 Beefy et kıyma makinesi için kapsamlı kullanım kılavuzu; güvenlik talimatları, parçalar, montaj, çalıştırma, temizlik, bakım ve garanti detaylarını içerir. Bu belge, ürünün güvenli ve etkili bir şekilde kullanılmasını sağlamak için tasarlanmıştır.