

Furologee CTHK-BS-015-C

Furologee 4-Tier Bookshelf with Power Outlet Instruction Manual

Model: CTHK-BS-015-C

Brand: Furologee

INTRODUCTION

Thank you for choosing the Furologee 4-Tier Bookshelf with Power Outlet. This versatile and stylish bookshelf is designed to provide ample storage space while offering convenient power access for your electronic devices. Its rustic brown finish and durable construction make it a perfect addition to any room, from living areas to home offices. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new furniture.

- **Durable Construction:** Made from high-quality engineered wood and a sturdy metal frame.
- **Integrated Power Outlet:** Features built-in power outlets and USB ports for charging convenience.
- **Space-Saving Design:** Offers four tiers of storage, ideal for books, decor, and other essentials.
- **Versatile Use:** Can be used as a bookshelf, display shelf, or even a kitchen spice rack or toiletries shelf.

SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- Do not overload the shelves. Refer to the specifications section for weight capacity.
- Place the bookshelf on a flat, stable, and level surface to prevent tipping.
- For electrical components, ensure the power cord is not pinched or damaged. Do not use in wet environments.
- Always unplug the power outlet before cleaning or moving the bookshelf.
- Do not attempt to modify the product or its electrical components.

PACKAGE CONTENTS

Before beginning assembly, please verify that all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Metal Frame Components
- Engineered Wood Shelves (4 tiers)
- Integrated Power Outlet with USB Ports
- Assembly Hardware (screws, bolts, Allen wrench, etc.)
- Anti-tip Kit (for wall attachment)
- Instruction Manual

SETUP AND ASSEMBLY

Follow these steps carefully to assemble your Furologee Bookshelf. It is recommended to assemble the unit with two people.

Step 1: Unpack and Identify Parts

Lay out all components on a clean, soft surface (e.g., a carpet or blanket) to prevent scratching. Identify each part using the provided parts list in your package.

Step 2: Assemble the Metal Frame

Connect the vertical metal frame pieces using the provided screws and the Allen wrench. Do not fully tighten screws until all frame components are loosely assembled.



Image: The fully assembled Furolee 4-Tier Bookshelf, showcasing its rustic brown shelves, black metal frame, and integrated power outlet with devices plugged in. Various items like books, plants, and decorative pieces are displayed on the shelves.

Step 3: Attach Shelves and Power Outlet

Carefully place each engineered wood shelf onto the designated frame supports. Secure them with screws. Install the power outlet unit into its designated slot on one of the shelves, ensuring the wiring is routed correctly and not pinched.




Image: A detailed view of the integrated power outlet on the bookshelf, showing a smartphone connected for charging and a small potted plant next to it, highlighting the convenience of the built-in electrical features.

Step 4: Final Tightening and Stability Check

Once all parts are in place, gradually tighten all screws. Ensure the bookshelf is stable and does not wobble. If included, attach the anti-tip kit to the top of the bookshelf and secure it to a wall stud to prevent accidental tipping, especially in households with children or pets.

Optional Assembly Configurations

This versatile bookshelf can be assembled in different configurations to suit your needs. It can be built as a single 4-tier unit or separated into two 2-tier units, functioning as smaller bookshelves or end tables.

Kitchen Spice Rack



Desktop Bookshelf



Makeup Organizer



Toiletries Shelf

Image: A comparison showing the bookshelf configured as a single tall 4-tier unit on the left, and on the right, the same components reconfigured into two separate 2-tier units, demonstrating its modularity and adaptability for different spaces.



Image: Two side-by-side views of the bookshelf, labeled "Before Adjustment" and "After Adjustment," illustrating how the unit can be reconfigured or adjusted to fit different functional or aesthetic requirements within a room.

OPERATING THE POWER OUTLET

The integrated power outlet provides convenient access to power for your devices. It includes standard AC outlets and USB charging ports.

- **Connecting to Power:** Plug the bookshelf's power cord into a standard wall outlet. Ensure the wall outlet is properly grounded.
- **Using AC Outlets:** Insert the plugs of your electronic devices (e.g., lamps, laptops) into the AC outlets.
- **Using USB Ports:** Connect your USB charging cables to the USB-A or USB-C ports to charge smartphones, tablets, or other USB-powered devices.
- **Overload Protection:** The power outlet is equipped with overload protection. If the total power draw exceeds the maximum rating, the circuit breaker may trip. Unplug some devices and reset the breaker if this occurs.

Important: Do not exceed the maximum power rating of the integrated outlet. Avoid plugging in high-power appliances

like heaters or microwaves directly into the bookshelf's outlet.

MAINTENANCE

Regular maintenance will help prolong the life and appearance of your bookshelf.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish. For the power outlet, ensure it is unplugged before wiping.
- **Dusting:** Regularly dust the shelves and metal frame with a dry, soft cloth.
- **Fastener Check:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Electrical Inspection:** Inspect the power cord and outlet for any signs of damage (fraying, cracks). If damage is found, discontinue use and contact customer support.
- **Spills:** Immediately wipe up any liquid spills to prevent damage to the wood shelves.

TROUBLESHOOTING

If you encounter any issues with your Furologee Bookshelf, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Bookshelf is wobbly.	Screws are loose; uneven floor.	Ensure all screws are fully tightened. Adjust leveling feet if present, or place shims under the legs on an uneven floor.
Power outlet is not working.	Not plugged in; circuit breaker tripped; faulty device.	Check if the bookshelf's power cord is securely plugged into a working wall outlet. Reset the circuit breaker on the power outlet if it has one. Test with a different device.
Parts do not align during assembly.	Incorrect orientation of parts; screws overtightened too early.	Loosen all screws, re-orient parts as per instructions, then gradually tighten. Ensure you are using the correct parts for each step.

SPECIFICATIONS

Detailed specifications for the Furologee 4-Tier Bookshelf with Power Outlet.

Brand: Furologee

Model Number: CTHK-BS-015-C

Color: Rustic Brown

Product Dimensions: 35 cm (D) x 40.01 cm (W) x 124.79 cm (H)

Product Weight: 6.4 kg

Material: Engineered Wood, Metal Frame

Number of Shelves: 4

Special Features: Durable, Lightweight, Space-saving, Waterproof, Integrated Power Outlet (AC & USB)

Assembly Type: Manual Assembly

Room Type: Common Room (Versatile)

Style: Country Rustic



Image: A technical diagram illustrating the precise dimensions of the Furologee bookshelf, including height, width, and depth measurements, to assist users in planning placement and understanding its size.

WARRANTY INFORMATION

Furologee products are manufactured with quality and durability in mind. While specific warranty details are not provided in this manual, please retain your proof of purchase. In the event of manufacturing defects or issues arising from normal use, please contact our customer support for assistance. Warranty coverage typically applies to defects in materials and workmanship.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Furologee 4-Tier Bookshelf, please contact our customer support team. Have your model number (CTHK-BS-015-C) and purchase information ready when you call or email. Please refer to the retailer's website or your purchase documentation for specific contact methods (phone, email, or online chat).



© 2024 Furologee. All rights reserved.