

Flysky FS-7022BK

Flysky UK7022BK Executive Chair User Manual

Model: FS-7022BK

1. INTRODUCTION

Thank you for choosing the Flysky UK7022BK Executive Chair. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal use and longevity of your chair. Please read this manual thoroughly before assembly and use, and retain it for future reference.



Image 1.1: The Flysky UK7022BK Executive Chair positioned in a modern office environment.

2. SAFETY INFORMATION

To prevent injury or damage to the chair, please observe the following safety guidelines:

- Ensure all components are securely fastened before use.
- Do not stand on the chair.
- Do not use the chair as a ladder or step stool.
- Avoid placing heavy objects on the chair's backrest or armrests.
- Keep children away from the chair during assembly.
- Maximum weight recommendation: 225 Kilograms (approximately 496 lbs). Do not exceed this limit.

3. PACKAGE CONTENTS

Please verify that all parts are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Backrest
- Seat Cushion
- Armrests (2)
- Gas Lift Cylinder
- Star Base
- Casters (5)
- Mechanism Plate
- Hardware Kit (screws, washers, Allen wrench)

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your Flysky UK7022BK Executive Chair. Assembly tools are included in the package.

1. **Attach Casters to Base:** Insert each of the five casters into the holes at the end of each leg of the star base. Push firmly until they click into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the star base.
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the pre-drilled holes on the underside of the seat cushion. Ensure the front of the mechanism (usually indicated by a label or the lever) faces the front of the seat. Secure with screws and washers using the provided Allen wrench.
4. **Attach Armrests to Seat:** Attach the armrests to the sides of the seat cushion using the designated screws. Do not fully tighten yet.
5. **Attach Backrest to Seat and Armrests:** Align the backrest with the seat and the armrests. Secure the backrest to the seat and armrests using the remaining screws. Once all screws are in place, fully tighten all armrest and backrest screws.
6. **Connect Seat Assembly to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring the center hole of the mechanism plate aligns with the top of the gas lift. Press down firmly to secure.

Comfortable, flexible, durable



Breathable



360° rotating wheel



Upholstered seat cushion



SGS-tested 3-stage gas springs



Thickly padded armrests



Robust metal base

Image 4.1: Key components and features of the chair, including the robust metal base and SGS-tested gas springs.

5. OPERATING INSTRUCTIONS

Your Flysky UK7022BK Executive Chair offers several adjustable features for personalized comfort.

5.1. Height Adjustment

To adjust the chair's height, pull the lever located on the right side of the seat upwards. While holding the lever, stand up to raise the chair or remain seated to lower it. Release the lever at the desired height.

5.2. Tilt Function and Tension

The chair features a tilt function allowing the backrest and seat to recline together. Pull the lever on the left side of the seat outwards to unlock the tilt. Push the lever inwards to lock the chair in an upright position.

To adjust the rocking tension, turn the round knob located under the front of the seat. Turn clockwise to increase tension (making it harder to recline) or counter-clockwise to decrease tension (making it easier to recline).

5.3. Foldable Armrests

The padded armrests can be folded upwards to save space or allow the chair to be pushed closer to a desk. Simply lift the armrests to fold them up.



Image 5.1: Visual guide to the chair's height adjustment lever and rocking tension knob.

FOLDABLE ARMRESTS

The padded armrests not only enhance comfort, but can also be folded up to save space.



Image 5.2: The foldable armrests feature, designed for space-saving and versatility.

6. MAINTENANCE

Regular maintenance helps prolong the life and appearance of your chair.

- **Cleaning:** Wipe fabric surfaces with a damp cloth and mild soap. Avoid harsh chemicals. For the base and plastic parts, use a soft, dry cloth.
- **Fasteners:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary.
- **Casters:** Clean casters regularly to remove hair and debris that may hinder smooth movement.

7. TROUBLESHOOTING

If you encounter any issues with your chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Chair does not adjust height	Gas lift cylinder malfunction or lever not engaged.	Ensure the height adjustment lever is fully pulled. If the issue persists, the gas lift may need replacement.
Chair wobbles	Loose screws or uneven floor.	Check and tighten all assembly screws. Ensure the chair is on a flat, even surface.
Casters do not roll smoothly	Debris in casters or damaged casters.	Remove any hair or debris from the caster wheels. If damaged, casters may need replacement.
Chair squeaks	Loose connections or friction between parts.	Tighten all screws. Apply a small amount of silicone lubricant to moving parts if necessary.

8. SPECIFICATIONS

Feature	Detail
Brand	Flysky
Model Number	FS-7022BK
Product Dimensions	25"D x 25"W x 25"H (approximate, varies with adjustment)
Maximum Weight Recommendation	225 Kilograms (496 lbs)
Tilting Function	Yes, with adjustable tension
Foldable Armrests	Yes
Gas Lift	SGS-tested 3-stage gas springs
Upholstery Material	Breathable fabric
Base Material	Robust metal
Item Weight	0.564 ounces (Note: This weight seems incorrect for a chair and may be a data entry error. Please refer to packaging for actual weight.)

DIMENSIONS

225KG



Image 8.1: Detailed dimensions and weight capacity of the Flysky UK7022BK Executive Chair.

9. WARRANTY AND SUPPORT

Flysky products are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your purchase or visit the official Flysky website. For technical support, missing parts, or any inquiries, please contact Flysky customer service through the retailer where the product was purchased or via the contact information provided on the Flysky website.

	<p>Flysky Executive Office Chair Model 7008 Assembly Instructions and Warranty</p> <p>Detailed assembly instructions, parts list, hardware kit, and warranty information for the Flysky Executive Office Chair Model 7008. Learn how to assemble your chair step-by-step.</p>
	<p>Paladin PL18 Ultra Flysky 18</p> <p>Flysky Paladin PL18 Ultra 18 2.4GHz AFHDS 3</p> <p>Paladin PL18 Ultra</p> <p>Ultra</p> <p style="text-align: right;">Paladin PL18</p>
	<p>Flysky Noble Pro User Manual - Advanced Radio Control System Guide</p> <p>Comprehensive user manual for the Flysky Noble Pro radio control system, detailing setup, operation, functions, specifications, and safety guidelines for RC models. Learn to use the transmitter, receivers, and advanced features for optimal performance.</p>
	<p>Flysky FS-G7P+ Quick Start Guide</p> <p>Quick Start Guide for the Flysky FS-G7P+ RC transmitter system. Covers setup, operations, binding, calibration, failsafe, firmware updates, and specifications.</p>
	<p>FLYSKY FS-MG11-BT-BS 2.4GHz Radio Control System Quick Start Guide</p> <p>Quick start guide and specifications for the FLYSKY FS-MG11-BT-BS 2.4GHz radio control system, including setup, operation, and safety precautions.</p>
	<p>Flysky FS-G11P</p> <p>FS-G11P FS-G11P FS-R11P</p>