

- Manuals.plus /
- › WALI /
 - › WALI Floating TV Shelf User Manual

WALI CS303NW

WALI Floating TV Shelf User Manual

Model: CS303NW | Brand: WALI

INTRODUCTION

Thank you for choosing the WALI Floating TV Shelf. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new wall-mounted shelf. Designed to hold various media devices, this shelf helps organize your entertainment area while saving space.



The WALI 3-Shelf Floating TV Shelf, shown with a game controller, projector, and smart speaker, designed to organize media devices.

SAFETY INFORMATION

Please read and understand all safety instructions before installation and use. Failure to follow these guidelines may result in property damage or personal injury.

- Adjust the shelf height carefully to ensure your unit is mounted at the perfect height for your setup.
- Do not exceed the maximum weight limit of **22 lbs (10 kg) per shelf**. Overloading can cause the shelf to detach from the wall.
- Always follow proper wall mounting techniques. Ensure the mounting surface is structurally sound and capable of supporting the shelf's weight plus the weight of all devices placed on it.
- Manage cables efficiently to prevent tripping hazards and ensure devices are securely placed.
- Keep small parts and hardware out of reach of children.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x WALI Floating Shelf System (Wooden)
- 3 x Reinforced Wooden Shelves
- 1 x Installation Hardware Kit (screws, anchors, etc.)
- 1 x User Manual (this document)



Note: The base of the item to be placed needs to be smooth or have a support point



Note: Width not to exceed 213mm (**8.39inch**)
Length recommended not to exceed 351mm (**13.8inch**)


Key features of the shelf, including wire management, thick wood construction, and rounded corners for safety and durability.

SPECIFICATIONS

Feature	Detail
Model Name	DVD Shelf
Number of Shelves	3
Product Dimensions (D x W x H)	11"D x 13.8"W x 22.8"H
Shelf Thickness	0.7 Inches
Weight Limit (per shelf)	22 lbs (10 kg)
Assembly Required	Yes

Feature	Detail
Installation Type	Wall-Mounted
Room Type	Bedroom, Living Room, Playroom

Product Features



Detailed dimensions of the WALI Floating TV Shelf.




After



VS



Before



Wood	✓	Glass	✗
Strong	✓	Fragile	✗
Ultrathick	✓	Thin	✗
Durable	✓	Unstable	✗

Guidance on device compatibility based on shelf dimensions, showing a PlayStation 5 for reference.

SETUP AND INSTALLATION

Follow these steps for proper installation of your WALI Floating TV Shelf. It is recommended to have a second person assist during installation.

1. Step 1: Mark Location

Mark the desired location for the holes on your wall. Use a level to ensure the shelf will be straight. Drill holes at the marked spots, then insert plastic anchors suitable for your wall type (e.g., brick, concrete, wood stud).

2. Step 2: Connect Plates

Connect the two main wall plates and install them securely using the provided hardware. Press the screw caps into the holes on the plate face for a clean finish.

3. Step 3: Attach Shelves

Attach each wooden shelf to the wall plate using a screwdriver and the appropriate screws. Ensure each shelf is firmly secured before placing any items on it.

Step 1 : Mark the location of the holes on the wall you want to install, drilling on the wall, then secure plastic anchor to the wall for almost any wall.



Step 2 : Connect the two plates and install them. Press the screw cap in the hole on the plate face. Secure the two plate using the included hardware.



Step 3 : Attach the shelf to the wall plate with a screwdriver.



Visual guide for the three main installation steps.



The shelf can be installed on various wall types including brick, concrete, and wood studs. Do not mount on drywall alone.

OPERATING INSTRUCTIONS

The WALI Floating TV Shelf is designed for convenient storage and organization of your media devices and accessories.

- **Placement:** Place DVD/Blu-ray players, satellite/cable boxes, game consoles, routers, Hi-Fi speakers, projectors, and other audio-video accessories on the shelves. Ensure even weight distribution.
- **Cable Management:** Utilize the two round holes on either side of each wooden shelf for efficient cable routing. This helps keep wires organized and out of sight, contributing to a tidier entertainment area.
- **Space Saving:** By mounting your devices on the wall, you free up valuable floor and tabletop space, enhancing the overall aesthetics of your living room, bedroom, or playroom.



The integrated wire holes allow for neat and efficient cable management.

Versatile Installation



The shelf is compatible with a wide range of devices and accessories.

MAINTENANCE

To ensure the longevity and appearance of your WALI Floating TV Shelf, follow these simple maintenance guidelines:


- **Cleaning:** Wipe the wooden surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Inspection:** Periodically check all mounting screws and connections to ensure they remain tight and secure. Re-tighten if necessary.
- **Weight Distribution:** Always ensure that the weight on each shelf is evenly distributed and does not exceed the maximum weight capacity of 22 lbs (10 kg).

TROUBLESHOOTING

If you encounter any issues with your WALI Floating TV Shelf, refer to the following common problems and solutions:

- **Shelf Appears Unstable:**
Solution: Ensure all mounting screws are fully tightened and that the wall anchors are properly installed for your specific wall type. Verify that the shelf is not overloaded beyond its 22 lbs (10 kg) capacity.
- **Devices Do Not Fit:**
Solution: Refer to the product dimensions and recommended device sizes in the Specifications section. Ensure the base of the item to be placed has a smooth surface or a support point.
- **Cables Are Tangled:**
Solution: Utilize the integrated cable management holes on each shelf to route and organize your device cables. Use

cable ties if necessary for a neater appearance.



The wooden construction offers superior strength and stability compared to glass shelves, reducing concerns about fragility.

OFFICIAL PRODUCT VIDEOS

No official seller videos were found for this product in the provided data.

CUSTOMER SUPPORT

For further assistance or inquiries, WALI offers experienced and friendly US customer support available 24/7 to assist you. You can typically expect a response to emails within 12 hours.

For the complete user manual in PDF format, please visit: [WALI Floating TV Shelf User Manual \(PDF\)](#)

You can also visit the [Wali Electric Seller Page](#) for more information.

© 2024 WALI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DFM9JK2M>

More documents and user manuals: <https://manuals.plus/>