

[Manuals.plus](#) /

> [EYYTHUNG](#) /

> EYYTHUNG Fluted Wall Cabinet with Sliding Doors, Natural Oak - Instruction Manual

EYYTHUNG C77

EYYTHUNG Fluted Wall Cabinet with Sliding Doors, Natural Oak - Instruction Manual

Model: C77 | Brand: EYYTHUNG

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your EYYTHUNG Fluted Wall Cabinet with Sliding Doors. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The EYYTHUNG Fluted Wall Cabinet, showcasing its natural oak finish and sliding doors, adorned with a vase and books.

SAFETY INFORMATION

- Always assemble the product on a clean, flat, and soft surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use.
- Do not overtighten screws, as this may damage the material.
- Use appropriate wall anchors for your specific wall type to ensure secure mounting. Consult a professional if unsure.
- Do not exceed the recommended weight capacity: Top surface 22 lbs (10 kg), each shelf 11 lbs (5 kg).
- Keep small parts away from children during assembly.

PARTS LIST

Before assembly, verify that all components listed below are present and undamaged. Refer to the assembly video for visual identification of parts.

Component	Quantity	Description
Top Panel	1	Main top surface of the cabinet.
Bottom Panel	1	Main bottom surface of the cabinet.
Side Panels	2	Left and right vertical sides.
Back Panel	1	Rear panel for structural integrity.
Sliding Doors	2	Fluted design doors for enclosed storage.
Drawer Slides	Set	Hardware for smooth drawer operation.
Wall Mounting Cleat	1	Wooden cleat for secure wall attachment.
Hardware Pack	1	Screws, dowels, and other fasteners.

ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your wall cabinet. An official assembly video is provided below for visual guidance.

Your browser does not support the video tag.


Video: Official EYYTHUNG Wall Cabinet Assembly Guide. This video demonstrates the step-by-step process of assembling the cabinet, including attaching components and installing the sliding doors.

1. Step 1: Prepare Components

Unpack all parts and lay them out on a soft, clean surface. Identify each component using the provided parts list and the assembly video. Ensure all hardware is accounted for.



Wall-mounting Free Up Space Beneath



Deep Storage

Fluted Panel Design

Image: A close-up view highlighting the fluted panel design and the deep storage capacity of the cabinet.

2. Step 2: Assemble the Main Frame

Attach the side panels to the bottom panel using the designated screws and dowels from the hardware pack. Ensure the pre-drilled holes align correctly. Gently tighten the screws.

3. Step 3: Install Drawer Slides (if applicable)

If your model includes a drawer, attach the drawer slides to the inner sides of the cabinet frame as shown in the assembly video. Ensure they are level and securely fastened.

4. Step 4: Attach the Top Panel

Place the top panel onto the assembled sides and secure it with screws. Verify that all edges are flush and the frame is square.

5. Step 5: Install the Back Panel

Slide the back panel into the grooves on the rear of the cabinet. Secure it with the small nails or screws provided, ensuring the panel is flush with the back edges.

6. Step 6: Insert Sliding Doors

Carefully insert the fluted sliding doors into their respective tracks on the top and bottom panels. Test the sliding mechanism to ensure smooth operation.



Image: Detailed view of the natural wood grain, the modern metal handle, and the smooth functionality of the sliding doors.

7. Step 7: Wall Mounting

Identify the desired location on your wall. Use the provided wall mounting cleat as a template to mark the drill holes. Drill pilot holes and insert appropriate wall anchors (not always included, may need to be purchased separately based on wall type). Secure the cleat to the wall. Then, align the cabinet with the cleat and slide it down to lock into place. Ensure the cabinet is level and stable.

Important: For optimal stability and safety, it is recommended to use robust drywall anchors or mount directly into wall studs. The provided anchors may not be suitable for all wall types or heavy loads.

OPERATING INSTRUCTIONS

Sliding Doors

The fluted doors are designed to slide smoothly along the tracks. Gently push or pull the doors using the integrated handles to access the enclosed storage compartments. Avoid forcing the doors to prevent damage to the tracks or panels.

Cable Management

The cabinet features a pre-drilled hole in the back panel for convenient cable management. This allows you to neatly route power cords for devices such as phone chargers, alarm clocks, or small lamps, keeping

your tabletop clutter-free.

Elevate Your Living Space with Sleekness



Recommended Load

Top: 22lbs

Each shelf: 11lbs

Inner Dimensions

29.92" (W) x 11.81" (D) x 11.81" (H)

Image: A diagram illustrating the precise dimensions of the EYYTHUNG Fluted Wall Cabinet, including width, height, and depth.

MAINTENANCE

To maintain the appearance and longevity of your EYYTHUNG Fluted Wall Cabinet, follow these simple care instructions:

- **Cleaning:** Wipe the surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Spills:** Immediately wipe up any spills with a clean, dry cloth to prevent staining or water damage.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood finish.
- **Humidity:** Maintain a stable humidity level in the room to prevent warping or cracking of the wood.

TROUBLESHOOTING

- **Cabinet feels unstable after mounting:** Recheck all wall mounting hardware. Ensure appropriate anchors were used for your wall type and that they are securely fastened. If possible, mount directly into wall studs.
- **Sliding doors are stiff or stick:** Check the tracks for any debris or obstructions. Ensure the doors are properly seated in both the top and bottom tracks. A small amount of silicone spray (not oil-based) can be applied to the tracks if needed, but test in an inconspicuous area first.
- **Parts missing or damaged:** Contact EYYTHUNG customer support with your model number and a description of the issue for assistance.

SPECIFICATIONS

Feature	Detail
Model Number	C77
Brand	EYYTHUNG
Material	Engineered Wood
Color	Natural Oak
Product Dimensions (L x W x H)	11.81 x 30 x 11.81 inches
Item Weight	19 pounds
Number of Drawers	1 (sliding door compartment)
Number of Shelves	1 (open compartment)
Max Load Capacity (Top)	22 lbs (10 kg)
Max Load Capacity (Shelf)	11 lbs (5 kg)

WARRANTY AND SUPPORT

For warranty information or further assistance, please refer to the product packaging or contact EYYTHUNG customer support directly. Keep your purchase receipt for any warranty claims. You can visit the official EYYTHUNG store for more products and support: [EYYTHUNG Store](#)