



[Manuals.plus](#) /

› [CHWARES](#) /

› CHWARES Digital Coffee Scale CH0028XS User Manual

## CHWARES CH0028XS

# CHWARES Digital Coffee Scale CH0028XS User Manual

Model: CH0028XS

### PRODUCT OVERVIEW

---

The CHWARES Digital Coffee Scale CH0028XS is a high-precision rechargeable scale designed for coffee enthusiasts. It features a 3kg capacity with 0.1g increments, multiple unit options, and integrated manual and automatic timing functions. Its compact design and easy-to-clean features make it suitable for various brewing methods, including pour-over and espresso.



Image: The CHWARES Digital Coffee Scale, showcasing its sleek design and LED display.

## SETUP

---

### Charging the Scale

Before first use, fully charge the scale using the provided Type-C charging cable. The charging indicator lights will illuminate during charging and turn off when fully charged. Ensure you use the original charging cable for optimal performance and battery longevity.




Image: The coffee scale connected to its Type-C charging cable, illustrating the charging process.

## Initial Placement

Place the scale on a flat, stable surface to ensure accurate readings. Avoid placing it near strong electromagnetic fields or vibrating equipment.

## OPERATING INSTRUCTIONS

---

### Power On/Off

- To power on, press the **Power/Tare (U/T)** button briefly.
- To power off, press and hold the **Power/Tare (U/T)** button for a few seconds.

### Unit Conversion

Press the **UNIT** button to cycle through the available measurement units: grams (g), milliliters (ml), ounces (oz), pounds (lb), pounds:ounces (lb:oz), and fluid ounces (fl'oz).

# Precise Result & Multi-units



Image: The scale displaying weight in grams, highlighting its precise measurement and multi-unit capability.

## Tare Function

The tare function allows you to subtract the weight of a container or previously added ingredients. Place the empty container on the scale, then briefly press the **Power/Tare (U/T)** button. The display will reset to zero, allowing you to measure ingredients accurately.

# Tare Function

Accurate weighing brings you a perfect brewing experience



Image: A step-by-step illustration of using the tare function to zero out the weight of a container before adding coffee beans.

## Timing Modes (Manual/Automatic)

The scale offers both manual and automatic timing modes for brewing.

- **Manual Timing Mode:** Press the **MODE** button to select manual timing. Press the **Timer** button (clock icon) to start or stop the timer.
- **Automatic Timing Mode:** Press the **MODE** button to select automatic timing. The timer will automatically start when water is poured onto the scale and stop when the brewing device is removed.

# Timing Mode

Touch the MODE button to switch between manual timing mode and auto timing mode



Image: The scale displaying both manual and automatic timing modes during espresso preparation and pour-over brewing.

## Sound Switch (Mute Mode)

To toggle the sound (e.g., button presses, timer alerts) on or off, press and hold the **MODE** button for approximately 3 seconds.

## MAINTENANCE

---

### Cleaning

The scale features a detachable silicone protective pad. Remove the pad for easy cleaning. Wash the silicone pad with mild soap and water, then wipe the scale surface with a damp cloth. Ensure all parts are dry before reassembling and using the scale.



## Easy to Clean & Maintain

Removable waterproof, anti-skid  
scratch-proof and heat-insulating silicone pads

Image: A hand removing the silicone pad from the scale, demonstrating its easy-to-clean design.

### Storage

Store the scale in a dry place away from extreme temperatures and direct sunlight. Its compact size allows for convenient storage in drawers or cabinets.



Image: The compact dimensions of the scale are highlighted, emphasizing its portability and ease of storage.

## TROUBLESHOOTING

- **Scale not turning on or displaying "Low Battery":** Ensure the scale is fully charged using the provided Type-C cable. If the issue persists, try a different compatible Type-C cable and power adapter.
- **Inaccurate readings:** Ensure the scale is placed on a flat, stable, and level surface. Avoid placing it near sources of vibration or drafts. Recalibrate if necessary (refer to specific calibration instructions if available in a separate guide, as this model does not detail user calibration).
- **Tare function not working:** Make sure no weight is on the scale before pressing the tare button, or that the weight of the container is stable before taring.
- **Timer not starting/stopping automatically:** In automatic timing mode, ensure the brewing process involves pouring liquid onto the scale. The sensor detects changes in weight to trigger the timer.

## SPECIFICATIONS

Feature	Detail
Model Number	CH0028XS
Weight Limit	3000 Grams (3kg)
Readout Accuracy	0.1 Grams
Display Type	LED
Units	g, ml, oz, lb, lb:oz, fl'oz
Special Features	Auto Shut Off, Backlit Display, Non-Slip Platform, Portable, Tare Function, Manual/Auto Timing
Material	ABS Plastic, Silicone
Product Dimensions	17 x 13 x 2.8 cm (6.69 x 5.12 x 1.10 inches)
Item Weight	0.63 Pounds (approx. 10.1 ounces)
Power Source	Rechargeable (Type-C Charging Cable)

## OFFICIAL PRODUCT VIDEO

---

Your browser does not support the video tag.

Video: An official product video demonstrating the features and usage of the CHWARES Digital Coffee Scale, including sensitive measurement, unit conversion, sound switch, tare function, manual and auto timing modes, charging, and compact design.

## WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the product packaging or contact CHWARES customer service directly. Keep your purchase receipt for any warranty claims.

© 2026 CHWARES. All rights reserved.