Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- 1Mii /
- > 1Mii SafeFly Min+ Bluetooth Transmitter and Receiver User Manual

1Mii SafeFly Min+

1Mii SafeFly Min+ Bluetooth Transmitter and Receiver User Manual

Model: SafeFly Min+

1. Introduction

The 1Mii SafeFly Min+ is a versatile 2-in-1 Bluetooth audio adapter designed to enhance your audio experience. It functions as both a Bluetooth transmitter (TX) and a Bluetooth receiver (RX), allowing you to wirelessly stream audio from non-Bluetooth devices to Bluetooth headphones/speakers, or to connect your Bluetooth-enabled phone/tablet to wired audio systems.

This manual provides detailed instructions for setting up, operating, and maintaining your SafeFly Min+ device. Please read it carefully before use.



Image: The 1Mii SafeFly Min+ device.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1Mii SafeFly Min+ Bluetooth Transmitter Receiver
- 3.5mm to 3.5mm Female Adapter
- Dual Prong Airplane Adapter
- USB Charging Cable
- User Manual



Image: All items included in the product package.

3. PRODUCT OVERVIEW

Familiarize yourself with the device's components and controls:



Image: Labeled diagram of the SafeFly Min+ device and its accessories.

- 3.5mm Audio Connection: Integrated audio jack for connecting to source/destination devices.
- OLED Screen: Displays connection status, volume, and mode.
- Volume Down (<): Decreases volume.
- Multi-function Button (OK/Power/Play/Pause/Pairing): Powers on/off, plays/pauses audio, and initiates pairing.

- Volume Up (>): Increases volume.
- TX/RX Switching: Slide switch to select Transmitter or Receiver mode.
- Reset Button: Independent button to resolve connection issues.
- Type C Charging Port: For charging the internal battery.

4. GETTING STARTED

4.1. Charging the Device

Before first use, fully charge the SafeFly Min+ using the provided USB charging cable. Connect the USB-C end to the device's charging port and the USB-A end to a standard USB power adapter (not included) or a computer's USB port.

- A full charge takes approximately 2 hours.
- The device offers up to 25 hours of playtime on a single charge.



Image: Charging the SafeFly Min+ device.

4.2. Power On/Off

- Power On: Press and hold the Multi-function (OK) button for 3 seconds. The OLED screen will light up.
- Power Off: Press and hold the Multi-function (OK) button for 3 seconds. The OLED screen will turn off.

4.3. Switching Modes (Transmitter TX / Receiver RX)

The SafeFly Min+ features a slide switch on the side to toggle between Transmitter (TX) and Receiver (RX) modes. Ensure the device is in the correct mode for your intended use.



Image: Visual representation of TX and RX modes.

5. Transmitter (TX) Mode Operation

In TX mode, the SafeFly Min+ transmits audio from a non-Bluetooth source to your Bluetooth headphones or speakers.

5.1. Connecting to an Audio Source

- 1. Slide the switch to the **TX** position.
- 2. Connect the 3.5mm audio jack of the SafeFly Min+ to the audio output port of your device (e.g., airplane entertainment system, TV, gym equipment).
- 3. For airplane use, if the audio jack is a dual-prong type, use the included Dual Prong Airplane Adapter.



Image: SafeFly Min+ in use on an airplane.



Image: SafeFly Min+ connected to a TV for wireless audio.

5.2. Pairing with Bluetooth Headphones/Speakers

- 1. Ensure the SafeFly Min+ is in TX mode and powered on. The OLED screen will display "Searching...".
- 2. Put your Bluetooth headphones or speaker into pairing mode. Refer to your audio device's manual for specific instructions.
- 3. The SafeFly Min+ will automatically search for and connect to nearby Bluetooth devices. The OLED screen will show the connected device's name (e.g., "BT Headphone 1").
- 4. If multiple devices are found, use the < and > buttons to navigate and the OK button to select your desired device.

5.3. Dual Link Functionality

The SafeFly Min+ supports connecting to two Bluetooth headphones/speakers simultaneously.

- 1. After successfully pairing the first device (e.g., "BT Headphone 1"), put your second Bluetooth device into pairing mode.
- 2. Press the Multi-function (OK) button twice quickly on the SafeFly Min+ to initiate pairing for the second device. The OLED screen will show "Searching B...".
- 3. Once connected, the OLED screen will display both connected devices (e.g., "BT Headphone 1" and "BT Headphone 2").

6. RECEIVER (RX) MODE OPERATION

In RX mode, the SafeFly Min+ receives audio from your Bluetooth-enabled phone/tablet and outputs it to a wired audio system.

6.1. Connecting to a Wired Audio System

- 1. Slide the switch to the **RX** position.
- 2. Connect the 3.5mm audio jack of the SafeFly Min+ to the AUX input port of your wired audio system (e.g., car stereo, home stereo, wired headphones/speakers).

3. If your wired system has a female 3.5mm input, use the included 3.5mm to 3.5mm Female Adapter.



Image: SafeFly Min+ in use with a wired speaker and car stereo.

Your browser does not support the video tag.

Video: Demonstrates the 1Mii SafeFly Min+ in Receiver Mode, connecting a phone to a car stereo via the AUX input.

6.2. Pairing with a Bluetooth Device (Phone/Tablet)

- 1. Ensure the SafeFly Min+ is in RX mode and powered on. The OLED screen will display "Searching...".
- 2. On your phone or tablet, enable Bluetooth and search for new devices.
- 3. Select "1Mii SafeFly Min+" from the list of available devices to pair.
- 4. Once connected, the OLED screen will display the name of your paired device (e.g., "A: Phone").

7. VOLUME CONTROL AND RESET FUNCTION

7.1. Volume Adjustment

- Use the < button to decrease the volume.
- Use the > button to increase the volume.
- The OLED screen will display the current volume level.

7.2. Reset Function

If you encounter connection issues or unexpected behavior, use the independent "RESET" button. Pressing this button will clear all previous pairing records and restart the device, often resolving compatibility or reconnection problems.

8. SPECIFICATIONS

Feature	Description
Model	SafeFly Min+
Bluetooth Version	5.3
Audio Codecs	aptX Low Latency, aptX HD, aptX Adaptive (device must also support)
Operating Modes	Transmitter (TX), Receiver (RX)
Dual Link Support	Connects up to two Bluetooth headphones/speakers in TX mode
Audio Interface	3.5mm AUX audio jack
Display	OLED Screen
Battery Life	Up to 25 hours playtime
Charging Time	Approx. 2 hours
Charging Port	USB Type-C
Dimensions (LxWxH)	1.38 x 0.59 x 1.97 inches
Weight	0.705 ounces (20g)



Image: Dimensions and weight of the SafeFly Min+.

9. SAFETY INFORMATION

To ensure safe operation and prolong the life of your device, please observe the following:

- Use only authorized chargers and batteries.
- Keep the device away from water, moisture, and extreme temperatures.
- Do not open, disassemble, or attempt to repair the device yourself. This may void the warranty and pose safety risks.
- Avoid dropping or subjecting the device to strong impacts.

10. TROUBLESHOOTING

If you encounter issues with your SafeFly Min+, try the following solutions:

- **Device not powering on:** Ensure the device is fully charged. Connect it to a power source using the USB charging cable.
- · Cannot pair with Bluetooth device:
 - Ensure the SafeFly Min+ is in the correct mode (TX for transmitting, RX for receiving).
 - Make sure your target Bluetooth device (headphones/speaker/phone) is in pairing mode.
 - Bring the devices closer together.
 - Press the "RESET" button on the SafeFly Min+ to clear previous connections and try pairing again.
 - Restart both the SafeFly Min+ and your Bluetooth device.
- No audio or poor audio quality:
 - Check that the 3.5mm audio cable is securely connected to both the SafeFly Min+ and the audio source/system.
 - Adjust the volume on both the SafeFly Min+ and the connected audio device/source.
 - Ensure there are no obstructions between the SafeFly Min+ and your Bluetooth headphones/speakers.
 - Verify that your Bluetooth headphones/speakers support the aptX codecs if you expect high-quality audio.
- Battery level display inaccuracy: The battery icon may not always reflect precise percentages. It is recommended to charge the device when the indicator shows a low level to avoid unexpected power off.

11. CUSTOMER SUPPORT

For further assistance, technical support, or warranty inquiries, please visit the official 1Mii website or contact their customer service directly. Contact information can typically be found on the 1Mii product packaging or their official website.

© 2024 1Mii. All rights reserved.

Related Documents - SafeFly Min+

Control of the Contro

1Mii SafeFly Min Quick Guide: Connecting Bluetooth Headphones

A quick guide to using the 1Mii SafeFly Min Bluetooth transmitter to connect headphones to airplanes, TVs, PCs, and other devices. Includes instructions for pairing two headphones, resetting the device, and troubleshooting common issues.

1Mii ML300 Bluetooth Transmitter and Receiver 2-in-1 User Manual Comprehensive user manual for the 1Mii ML300, a 2-in-1 Bluetooth transmitter and receiver. Includes setup instructions for TX and RX modes, pairing guides, and important warnings.
1Mii B03 Bluetooth 5.3 Transmitter Receiver User Manual User manual for the 1Mii B03 Bluetooth 5.3 Transmitter Receiver, detailing its features, operation, and troubleshooting for home stereo audio transmission with aptX Low Latency and HD support.
1Mii ML201 Wireless Audio Receiver User Manual Comprehensive user manual for the 1Mii ML201 Bluetooth Wireless Audio Receiver, detailing setup, operation, pairing, specifications, and troubleshooting.
1Mii B03Pro Wireless Transmitter Receiver User Manual User manual for the 1Mii B03Pro, a 2-in-1 wireless audio transmitter and receiver. Learn how to connect, operate, and troubleshoot your device for seamless audio streaming.
1Mii ML300 2-in-1 Bluetooth Audio Transmitter and Receiver User Manual Comprehensive user manual for the 1Mii ML300, a versatile 2-in-1 Bluetooth audio transmitter and receiver. Learn about setup, operation, features, and specifications for seamless wireless audio.