

[Manuals.plus](#) /

› [Catch&Hunt](#) /

› Catch&Hunt Professional Slingshot Rifle User Manual

Catch&Hunt MTY

Catch&Hunt Professional Slingshot Rifle User Manual

Model: MTY | Brand: Catch&Hunt

1. INTRODUCTION

Thank you for choosing the Catch&Hunt Professional Slingshot Rifle. This powerful and well-constructed slingshot is designed for outdoor hunting and shooting practice for adults. Its ergonomic design, featuring a front handle and rear drag, enhances stability and accuracy. This manual provides essential information for safe and effective use, including setup, operation, maintenance, and troubleshooting.

Important Safety Warnings:

- This product is intended for adult use only. Keep out of reach of children.
- Always wear appropriate eye protection and other protective gear when operating the slingshot rifle.
- Never aim or shoot at people, animals, or property. Always ensure a clear and safe backstop.
- Use only the recommended ammunition (0.3in steel ammo).
- Inspect the rubber bands and all components for wear or damage before each use. Do not use if damaged.
- Be aware of your surroundings and potential ricochets.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- Slingshot Rifle x 1
- Flat Rubber Band x 3
- 0.3in Steel Ammo x 100
- Green Laser x 1
- Target Paper x 3
- Screwdriver x 1



Figure 2.1: Complete package contents of the Slingshot Rifle.

3. SETUP AND ASSEMBLY

Follow these steps to assemble your slingshot rifle:

1. **Attach the Rubber Bands:** Carefully secure the flat rubber bands to the slingshot fork. Ensure they are firmly attached and centered. The design allows for widened high rebound rubber bands.
2. **Install the Green Laser:** Mount the green laser sight onto the designated rail on the slingshot rifle. Use the provided screwdriver to tighten the mounting screws. Ensure the laser is securely fastened.
3. **Adjust Rifle Length (Retractable Body):** The slingshot rifle features a retractable body for adjusting speed and range. To extend, pull the rear section away from the main body. To retract, push the rear section towards the main body. Adjust to a comfortable and effective length between 35.4 and 48 inches.



Figure 3.1: Retractable body mechanism and dimensions.



Figure 3.2: Detailed view of key components.

4. OPERATING INSTRUCTIONS

Always ensure you are in a safe environment and wearing protective gear before operating the slingshot rifle.

1. **Loading Ammunition:** Place a single 0.3in steel ammo into the center of the rubber band pouch. Ensure it is seated properly.
2. **Drawing the Band:** Firmly grasp the handle and pull the rubber band pouch back towards the rear of the rifle. The trigger mechanism will engage and hold the band in place when fully drawn.
3. **Aiming:** Use the green laser sight to assist with aiming. Align the laser dot with your target. Maintain a stable stance and firm grip.
4. **Firing:** Once your target is acquired and the area is clear, gently squeeze the trigger to release the rubber band and fire the ammunition.
5. **Reloading:** After firing, repeat the steps for loading and drawing the band for the next shot.



Figure 4.1: Proper grip and handling of the slingshot rifle.



Figure 4.2: Demonstrations of shooting postures.



Figure 4.3: Aiming the slingshot rifle.

Product Video:

Your browser does not support the video tag.

Video 4.1: A short demonstration showcasing the product's appearance and basic operation, including loading and firing.

5. MAINTENANCE

Proper maintenance will ensure the longevity and performance of your slingshot rifle:

- **Cleaning:** After each use, wipe down the metal parts of the slingshot rifle with a clean, dry cloth to remove dirt and moisture. For stubborn grime, a slightly damp cloth can be used, followed by thorough drying.
- **Rubber Band Inspection:** Regularly inspect the flat rubber bands for any signs of wear, tears, cracks, or stretching. Worn bands can affect performance and safety. Replace them immediately if any damage is observed.
- **Storage:** Store the slingshot rifle in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure it

is unloaded and disassembled if necessary for storage.

- **Laser Battery:** If the green laser's brightness diminishes or it stops working, replace its battery. Refer to the laser's specific instructions for battery type and replacement procedure.

6. TROUBLESHOOTING

If you encounter issues with your Catch&Hunt Professional Slingshot Rifle, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Laser sight not working or dim.	Low or dead battery; loose connection; faulty laser.	Check battery orientation and replace if necessary. Ensure laser is securely mounted. If issues persist, contact customer support.
Ammunition not firing consistently or lacking power.	Worn or damaged rubber bands; improper loading; trigger mechanism issue.	Inspect rubber bands for damage and replace if needed. Ensure ammunition is correctly seated in the pouch. Verify the trigger mechanism engages and releases smoothly.
Difficulty retracting/extending the rifle body.	Dirt or debris in the sliding mechanism; misalignment.	Clean the retractable parts thoroughly. Ensure no foreign objects are obstructing movement. Apply a small amount of silicone lubricant if needed (avoiding rubber bands).

7. SPECIFICATIONS

Brand:	Catch&Hunt
Model Name:	MTY
Material:	Aluminium Alloy (Frame), Metal (Barrel)
Air Gun Power Type:	Manual
Rounds Included:	100 (0.3in Steel Ammo)
Retractable Length:	35.4 - 48 inches
Item Package Dimensions:	26.3 x 5.9 x 3.4 inches
Package Weight:	1.79 Kilograms
UPC:	768531647193

8. WARRANTY AND SUPPORT

The Catch&Hunt Professional Slingshot Rifle comes with a **180-day warranty** from the date of purchase, covering manufacturing defects. This warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For technical support, warranty claims, or any questions regarding your product, please contact Catch&Hunt customer service through the retailer where you purchased the product or visit the official Catch&Hunt store page on Amazon:

[Catch&Hunt Store](#).

© 2024 Catch&Hunt. All rights reserved.

Please use this product responsibly and in accordance with all local laws and regulations.