

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [MilleLoom](#) /

> [MilleLoom Shoe Cabinet \(Model IKdtzVUMhHG04HXINdokQgaS\) Instruction Manual](#)

MilleLoom IKdtzVUMhHG04HXINdokQgaS

MilleLoom Shoe Cabinet Instruction Manual

MODEL: LKDTZVUMhHG04HXLNDOkQGAS

Brand: MilleLoom

INTRODUCTION

Thank you for purchasing the MilleLoom Shoe Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new shoe cabinet. Please read these instructions carefully before beginning assembly and retain them for future reference.

This shoe cabinet features three rotating doors and two top drawers, designed to provide organized storage for 18-24 pairs of shoes while protecting them from dust.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly.
- Assemble on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly.
- Keep small parts away from children during assembly.
- For stability, place the cabinet on a flat, level surface.

SETUP AND ASSEMBLY

The MilleLoom Shoe Cabinet requires self-assembly. Detailed instructions and hardware are supplied with the product. Please follow the step-by-step guide provided in the packaging for proper assembly.

Required Tools (Not Included):

- Phillips Head Screwdriver
- Hammer (optional, for dowels)

Assembly Tips:

- Identify all components and hardware before starting.

- Work in a spacious area to avoid damage.
- Do not discard packaging until assembly is complete and all parts are accounted for.



Figure 1: Overall dimensions of the MilleLoom Shoe Cabinet. The cabinet measures 31.5 inches deep, 9.25 inches wide, and 47.24 inches high. The top drawers are 5.9 inches high and 15 inches wide. The rotating shoe compartments have varying depths and heights for shoe storage.

OPERATING INSTRUCTIONS

Using the Rotating Shoe Drawers:

1. Gently pull the handle on the front of each shoe compartment. The door will tilt forward and down, revealing the shoe racks.
2. Place shoes onto the internal racks. The design accommodates various shoe sizes and types.
3. To close, push the door upwards and inwards until it securely latches into place. This keeps shoes out of sight and protected from dust.



Figure 2: Detail of the rotating shoe compartment mechanism. Shoes are placed on the angled shelves, which rotate forward for access and back into the cabinet for storage. The internal dimensions for shoe placement are approximately 9.45 inches deep and 4.13 inches high.

Using the Top Drawers:

- The two top drawers are designed for smaller items such as keys, wallets, or shoe care accessories.
- Pull the handles to open and push to close.

The cabinet is designed to store approximately 18-24 pairs of shoes, depending on shoe size and style.

CARE AND MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the finish.
- **Dusting:** Regularly dust the cabinet with a dry, soft cloth to prevent dust buildup.
- **Spills:** Clean spills immediately with a dry cloth to prevent staining or damage to the wood/MDF material.
- **Placement:** Avoid placing the cabinet in direct sunlight or near heat sources to prevent warping or discoloration.
- **Hardware:** Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Uneven floor; loose screws.	Ensure the cabinet is on a level surface. Check and tighten all assembly screws.
Drawer does not open/close smoothly.	Obstruction; misaligned runners; overtightened screws.	Check for any items blocking the drawer. Verify that drawer runners are correctly installed and screws are not overtightened.
Parts missing or damaged.	Packaging error; shipping damage.	Refer to the parts list in your assembly manual. Contact customer support for replacement parts.

If you encounter issues not listed here, please refer to the contact information in the Support section.

PRODUCT SPECIFICATIONS

Brand: MilleLoom

Model Name: IKdtzVUMhHG04HXINdokQgaS

Product Dimensions (D x W x H): 31.5" x 9.25" x 47.24"

Color: White + Oak

Main Material: MDF

Item Weight: 50.6 pounds

Storage Capacity: Approximately 18-24 pairs of shoes

Mounting Type: Floor Mount

Assembly Required: Yes

Room Type: Hallway, Entryway

WARRANTY AND SUPPORT

This product is covered by a 30-day easy returns policy. For any questions regarding assembly, missing parts, or product functionality, please contact MilleLoom customer support.

Customer Support: Please refer to your purchase documentation or the seller's contact information for direct support channels.