

CUSIMAX CMIP-B09

Cusimax CMIP-B09 1800W Double Infrared Burner Hot Plate User Manual

Model: CMIP-B09

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the Cusimax CMIP-B09 Double Infrared Burner Hot Plate. Retain this manual for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always place the hot plate on a stable, heat-resistant, and dry surface.
- Do not touch hot surfaces. Use handles or knobs. The appliance surfaces remain hot for a period after use.
- To protect against electrical hazards, do not immerse the cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for assistance.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control to 'off', then remove the plug from the wall outlet.
- Do not use the appliance for other than intended household use.
- Ensure adequate ventilation around the appliance during operation.

- The heating light may cycle on and off during operation; this is normal and indicates temperature regulation.

2. PRODUCT OVERVIEW

The Cusimax CMIP-B09 is an 1800W double infrared burner hot plate designed for versatile cooking. It features two independent heating zones with adjustable temperature controls, suitable for various cookware types.



Image 1: The Cusimax CMIP-B09 Double Infrared Burner Hot Plate, showcasing its two heating elements and control knobs. A frying pan with cooked food is placed on the left burner.

Key Features:

- **Dual 900W Burners:** Total 1800W power for efficient cooking.
- **Adjustable Temperature Control:** Individual wheel-shaped knobs for precise heat settings on each burner.
- **Universal Cookware Compatibility:** Works with all types of pots and pans, including glass, copper, cast iron, aluminum, and non-magnetic stainless steel, up to 7.4 inches in size.
- **Durable Construction:** Made with a matte stainless steel casing.
- **Portable Design:** Features hidden handles for easy transport and storage.
- **Safety Certified:** ETL certified, complying with safety standards.

1800W High Power and 30% Energy Saving



Image 2: Visual representation of the hot plate's 1800W power, uniform heating, temperature control, and heat dissipation function.

Compatible with all Cookware

Pots and pans with maximum size of 7.1 inches



Image 3: Illustration demonstrating the hot plate's compatibility with different cookware materials such as iron, copper, glass, stainless steel, casserole, aluminum, barbecue, and ceramics.

3. SETUP AND INSTALLATION

1. **Unpacking:** Carefully remove the hot plate from its packaging. Retain packaging for storage or return if necessary.
2. **Placement:** Place the hot plate on a flat, stable, dry, and heat-resistant surface. Ensure there is sufficient space around the unit for proper ventilation (at least 4 inches from walls or other appliances).
3. **Power Connection:** Ensure the voltage of your power outlet matches the appliance's requirements (120V, 60Hz). Plug the power cord into a grounded electrical outlet.
4. **Initial Use:** Before first use, operate the hot plate at maximum setting for approximately 5 minutes without cookware. This will burn off any manufacturing residues and odors. A slight smoke or odor is normal during this initial process. Ensure the area is well-ventilated.

Electric BURNER CERAMIC Hot Plate



Image 4: The Cusimax hot plate positioned on a kitchen countertop, ready for use with various dishes and ingredients nearby.

4. OPERATING INSTRUCTIONS

1. **Placing Cookware:** Place your desired pot or pan (up to 7.4 inches in diameter) centrally on the heating element. Ensure the cookware is flat-bottomed for optimal heat transfer.
2. **Power On:** Plug the hot plate into a suitable electrical outlet.
3. **Adjusting Temperature:** Turn the control knob for the desired burner clockwise to select the heat setting. The indicator light for that burner will illuminate, indicating it is heating.
4. **Heat Settings:** The knobs allow for variable temperature control, from low to high. Adjust as needed for simmering, boiling, frying, or keeping food warm.
5. **Temperature Regulation:** The indicator light will cycle on and off during operation. This signifies that the thermostat is maintaining the selected temperature.
6. **Power Off:** After cooking, turn the control knob counter-clockwise to the 'OFF' position. Unplug the appliance from the wall outlet.
7. **Cool Down:** Allow the hot plate to cool completely before moving or cleaning. The surface will remain hot for some time after being turned off.

ENJOY YOUR COOKING TIME



Stir Fry



Deep Fry



Simmer



Grill



Sear

Image 5: A visual guide illustrating the range of heat settings from low to high, suitable for various cooking methods such as stir-frying, deep-frying, simmering, grilling, and searing.

MAKE VARIOUS CUISINE

Cooking With Less Effort

With different cooking method setting, you can sear, boil, simmer, deep fry, saute, slow cooking, melt, or simply reheat or keep food warm.



Image 6: Examples of different cuisines and cooking methods that can be performed on the hot plate, including reheating, barbecue, frying eggs, frying steak, spaghetti, sauteing, and boiling.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your hot plate.

1. **Always Unplug:** Before cleaning, ensure the hot plate is unplugged from the power outlet and has completely cooled down.
2. **Wipe Surfaces:** Use a soft, damp cloth to wipe the matte stainless steel casing and the heating plate surfaces. For stubborn stains, a mild detergent can be used.
3. **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the surface finish.
4. **Do Not Immerse:** Never immerse the hot plate, cord, or plug in water or any other liquid.
5. **Storage:** Once clean and dry, the hot plate can be stored in a cool, dry place. The hidden handles facilitate easy movement and storage.

6. TROUBLESHOOTING

If you encounter issues with your Cusimax hot plate, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Hot plate does not turn on.	Not plugged in; power outlet malfunction; control knob not turned on.	Ensure the unit is securely plugged into a working outlet. Turn the control knob to a heat setting. Check the circuit breaker.
Hot plate heats slowly or not hot enough.	Low heat setting selected; cookware not suitable or too large; insufficient power.	Increase the heat setting. Ensure cookware has a flat bottom and is within the recommended size (up to 7.4 inches). Verify the power supply. Note that initial heating may take a few minutes.

Problem	Possible Cause	Solution
Indicator light cycles on and off.	Normal temperature regulation.	This is normal operation. The thermostat is maintaining the set temperature.
Smoke or odor during first use.	Manufacturing residues burning off.	This is normal for initial use. Ensure good ventilation. It should dissipate after a few minutes.
Unit remains hot after turning off.	Residual heat from heating elements.	This is normal. Allow the unit to cool completely before handling or cleaning.

If the problem persists after attempting these solutions, please contact Cusimax customer service.

7. PRODUCT SPECIFICATIONS



Image 7: Detailed product dimensions of the Cusimax hot plate, showing its length, width, and height.

- **Model Number:** CMIP-B09
- **Brand:** CUSIMAX
- **Power:** 1800W (900W + 900W)
- **Voltage:** 120 Volts
- **Frequency:** 60Hz
- **Heating Elements:** 2 Infrared Burners
- **Control Type:** Knob
- **Material:** Stainless Steel
- **Color:** Matte Black
- **Product Dimensions:** 20.7"W x 8.9"D x 2.7"H (52.6 cm x 22.6 cm x 6.9 cm)
- **Item Weight:** 7.24 pounds (3.28 kg)
- **Cookware Compatibility:** All types, up to 7.4 inches diameter
- **Certifications:** ETL

8. WARRANTY AND CUSTOMER SUPPORT

Cusimax is committed to providing quality products and customer satisfaction.

- **Return Policy:** Cusimax offers a 30-day hassle-free return policy.
- **Product Certification:** All Cusimax products, including the CMIP-B09, have passed ETL certification and comply with relevant safety standards.
- **Contact Support:** For any issues, questions, or concerns regarding your hot plate, please contact Cusimax customer service. Our team is available to assist with troubleshooting, replacements, or any other product-related inquiries.
- **Online Resources:** For additional support and product information, visit the official Cusimax website or Amazon store page.