

MadeiraMadeira Zurique

MadeiraMadeira Zurique TV Panel for TVs up to 75 inches, Tauari/Off White Gloss - Instruction Manual

Model: Zurique

[Introduction](#)

[Safety Information](#)

[Components](#)

[Setup & Assembly](#)

[Operating Instructions](#)

[Warranty &](#)

[Support](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your MadeiraMadeira Zurique TV Panel. Please read this manual thoroughly before beginning assembly or use to ensure proper installation and safe operation. Keep this manual for future reference.

The Zurique Home Panel is a furniture unit designed for living rooms. It has a width of 2 meters and is suitable for TVs up to 75 inches. The panel incorporates chamfered details and integrated LED lighting. A suspended top, also with a chamfered finish, complements the design. The overall aesthetic features chamfered finishes and rounded details.



Figure 1.1: The MadeiraMadeira Zurique TV Panel, Tauari/Off White Gloss, installed in a modern living room setting. This image provides an overview of the product's appearance and scale.

2. SAFETY INFORMATION

- **Read all instructions:** Before assembly and use, carefully read and understand all instructions.
- **Assembly by adults:** This product requires assembly by competent adults.
- **Use appropriate tools:** Ensure you have the correct tools for assembly as specified in the instructions.
- **Secure mounting:** The TV panel must be securely mounted to a suitable wall structure. Consult a professional if unsure about wall type or mounting methods.
- **Weight limits:** Do not exceed the recommended weight limits for the TV panel and shelves. Refer to the specifications section.
- **Cable management:** Ensure all cables are neatly organized and secured to prevent tripping hazards or damage.
- **LED lighting:** If equipped with LED lighting, ensure proper electrical connection and avoid direct prolonged eye

exposure to the light source.

- **Children and pets:** Keep children and pets away from the assembly area. Small parts can be a choking hazard.
- **Stability:** Regularly check all connections and fasteners to ensure the panel remains stable and secure.

3. COMPONENTS AND PARTS LIST

Before starting assembly, verify that all components and hardware listed in the packaging are present and undamaged. Refer to the included assembly diagram for visual identification of parts.



Figure 3.1: Exploded view of the MadeiraMadeira Zurique TV Panel components, showing individual parts and hardware required for assembly. This image helps in identifying all pieces before starting the installation process.

Note: A detailed list of screws, dowels, and other small parts will be provided in the physical assembly manual included with your product.

4. SETUP AND ASSEMBLY

Assembly of the MadeiraMadeira Zurique TV Panel is required. It is recommended that two adults perform the assembly. Please follow the step-by-step instructions provided in the physical assembly manual that accompanies your product. Below are general guidelines and important considerations.

4.1. Preparation

- **Clear the area:** Ensure a spacious and clean area for assembly.
- **Tools required:** Gather necessary tools such as a screwdriver (Phillips and flathead), hammer, measuring tape, level, and drill (for wall mounting).
- **Identify parts:** Lay out all components and hardware and compare them with the parts list to ensure everything is present.

4.2. Assembly Steps (General)

1. Assemble the main panel structure according to the diagram.
2. Attach the suspended top and bottom console sections.
3. Install any internal shelves or drawers.
4. Mount the LED lighting strip (if applicable) and connect it to the power source.
5. Carefully lift and mount the assembled panel to the wall using appropriate wall anchors and screws. Ensure the wall can support the weight of the panel and your TV.
6. Secure your TV to the designated mounting area on the panel.



Figure 4.1: Dimensional view of the MadeiraMadeira Zurique TV Panel, showing its height (173 cm), width (200 cm), and depth (32 cm). This image is crucial for planning the installation space.



Figure 4.2: Front view of the assembled MadeiraMadeira Zurique TV Panel, showcasing its design and the space for a television. This image provides a visual reference for the completed product.

5. OPERATING INSTRUCTIONS

The MadeiraMadeira Zurique TV Panel is primarily a furniture piece designed to hold your television and media accessories. Its operation mainly involves the use of its integrated LED lighting.

5.1. LED Lighting

- **Power Connection:** Ensure the LED lighting power adapter is securely plugged into a functional wall outlet.
- **Switch Operation:** Locate the power switch for the LED lighting (typically a small inline switch on the power cord or a button on the panel itself). Toggle the switch to turn the lights ON or OFF.
- **Ambiance:** The LED lighting is designed to provide ambient illumination, enhancing the aesthetic of your living space.



Figure 5.1: A detailed view of the integrated LED lighting strip located above the suspended shelf, illustrating its placement and how it illuminates the panel.

5.2. Storage Compartments

- **Access:** The panel features storage compartments, some with doors, for organizing media devices, remote controls, and other items.
- **Weight Distribution:** Distribute weight evenly within the compartments and avoid overloading to maintain stability.



Figure 5.2: The MadeiraMadeira Zurique TV Panel with its storage compartments open, revealing space for media devices, books, or decorative items.

6. MAINTENANCE

Proper care and maintenance will ensure the longevity and appearance of your MadeiraMadeira Zurique TV Panel.

6.1. Cleaning

- **Dusting:** Regularly dust the panel with a soft, dry cloth.
- **Stains:** For light stains, wipe with a damp cloth and mild soap, then dry immediately with a clean, soft cloth.
- **Avoid harsh chemicals:** Do not use abrasive cleaners, solvents, or polishes that may damage the finish.

6.2. General Care

- **Check fasteners:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Avoid direct sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration.
- **Protect from moisture:** Avoid placing hot or wet items directly on the surface. Use coasters or protective mats.
- **LEDs:** If LED lights fail, consult the manufacturer or a qualified electrician for replacement or repair. Do not attempt to repair electrical components yourself.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your TV panel.

7.1. Assembly Issues

- **Missing parts:** Double-check the packaging and parts list. Contact customer support if parts are genuinely missing.
- **Difficulty aligning parts:** Ensure all components are oriented correctly as per the assembly diagram. Do not force parts together.
- **Panel feels unstable:** Verify all wall mounts are securely fastened and all internal connections are tightened. Ensure the wall structure is adequate.

7.2. LED Lighting Issues

- **Lights not turning on:**
 - a. Check if the power adapter is securely plugged into a working electrical outlet.
 - b. Ensure the inline power switch is in the "ON" position.
 - c. Inspect the cable for any visible damage.
- **Lights flickering:**
 - a. Ensure all connections are secure.
 - b. Try plugging the adapter into a different outlet.

If you encounter issues not covered here, please refer to the Warranty & Support section for assistance.

8. SPECIFICATIONS

Feature	Detail
Model Name	Zurique
Brand	MadeiraMadeira
Color	Tauari/Off White Gloss
Dimensions (H x W x D)	173 cm x 200 cm x 32 cm (68.1 in x 78.7 in x 12.6 in)
Product Weight	67.15 kg (148.04 lbs)

Feature	Detail
Maximum TV Size Supported	Up to 75 inches
Assembly Required	Yes
Room Type	Living Room
Style	Modern
Special Features	Chamfered details, Integrated LED lighting, Suspended top

9. WARRANTY AND SUPPORT

9.1. Warranty Information

The MadeiraMadeira Zurique TV Panel comes with a **3-month warranty** against manufacturing defects. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper assembly, misuse, accidents, modifications, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

9.2. Customer Support

For assistance with assembly, missing parts, or warranty claims, please contact MadeiraMadeira customer support. You can find more information and contact details on the official MadeiraMadeira store page:

[Visit MadeiraMadeira Store](#)

