

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [BLISSRIDE](#) /
- › [BLISSRIDE 24V Kids ATV 4 Wheeler Instruction Manual](#)

BLISSRIDE 24V Kids ATV 4 Wheeler (Model: B0DFQBBCD9)

BLISSRIDE 24V Kids ATV 4 Wheeler Instruction Manual

Model: B0DFQBBCD9 | Brand: BLISSRIDE

1. INTRODUCTION

Thank you for choosing the BLISSRIDE 24V Kids ATV 4 Wheeler. This electric ride-on toy is designed to provide a thrilling and safe driving experience for children aged 3-8 years. Featuring a powerful 400W motor, a long-lasting 9AH battery, and a comfortable 2-seater design, this ATV is built for adventure. Please read this manual thoroughly before assembly and operation to ensure proper use and maximum enjoyment.



Image: The BLISSRIDE 24V Kids ATV 4 Wheeler in black, with two children enjoying a ride. Protective gear and keys are also displayed.

2. IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in serious injury or death.

- Always read the user manual before using the 24V kids ATV quad.
- This ride-on ATV is a toy vehicle designed for recreational use only and is not intended for use on public roads or as a means of transportation.
- Riders should always wear a helmet, knee pads, and elbow pads while riding. A protective gear set is included for your child's safety.
- Constant parental supervision is required during use. Ensure an adult is always present to monitor and assist the rider.

- Do not exceed the maximum weight capacity of 110 lbs.
- Ensure all components are securely fastened before each use.



Image: Overview of the ATV's safety features, including spring suspension and soft start technology, alongside the provided protective gear.

3. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 X 24V Ride on ATV Quad
- 1 X Protective Gear Set (Knee pads, Elbow pads)
- 1 X User Manual

4. ASSEMBLY AND INITIAL SETUP

Assembly of the BLISSRIDE ATV is straightforward. Follow these steps carefully:

1. Unpack all components and lay them out. Ensure no parts are missing.
2. Attach the wheels according to the instructions provided in the detailed assembly guide (refer to the separate assembly sheet if included).
3. Connect the battery. Ensure the connection is secure.
4. Before first use, fully charge the battery for 8-12 hours. Do not overcharge.
5. Perform a quick safety check: ensure all screws are tightened, wheels are secure, and the steering operates smoothly.



Image: The BLISSRIDE ATV with its overall dimensions highlighted, providing a visual reference for its size.

5. OPERATING YOUR BLISSRIDE ATV

5.1 Power and Speed

The ATV is equipped with a powerful 400W motor and a 24V 9AH battery, offering adjustable speed settings for different skill levels.

- **Key Start:** Insert the key and turn to power on the ATV.
- **Speed Settings:** Select between two speed modes: Low Speed (1.8-3 mph) and High Speed (3-5 mph). This allows for thrilling yet safe driving.
- **Soft Start Technology:** Ensures gradual acceleration for a smooth and comfortable ride, preventing sudden jolts.
- **Battery Life:** A full charge provides up to 2 hours of continuous playtime.

DUAL 200W MOTOR

The dual 200W motors provide powerful and smooth acceleration, offering a dynamic and thrilling driving experience for the children's electric vehicle.

 **Swichable Speed Mode:**

High Speed 3~5.0Mph

Low Speed 1.8~3Mph

400W POWER ENGINE



Image: Visual representation of the ATV's 400W motor and adjustable speed settings.

5.2 Entertainment Features

Enhance the riding experience with the built-in multifunctional media panel.

- **Bluetooth Connectivity:** Easily connect your smartphone or other Bluetooth-enabled devices to stream music wirelessly.
- **Music Player:** Enjoy pre-installed tunes or play your own via USB/AUX ports.
- **USB/AUX Ports:** For MP3 playback and other audio connections.
- **Realistic Engine Sounds:** Adds to the immersive driving experience.



Image: The ATV's entertainment panel, highlighting Bluetooth, USB, and AUX connectivity for music playback.

5.3 Driving and Maneuvering

The BLISSRIDE ATV is designed for versatile terrain and easy handling.

- **All-Terrain Wheels:** Equipped with four large 14.4-inch wheels and advanced spring suspension, it handles various surfaces including grass, dirt, and gravel.
- **2-Seater Design:** The 16.5-inch wide seat comfortably accommodates two children (ages 3-8, up to 110 lbs), making it ideal for shared adventures.
- **Easy-Drag Feature:** A rear handle allows parents to easily tow the ATV when not in use, saving effort.



Image: Detail of the large, durable off-road wheels designed for various terrains.



Image: Demonstration of the easy-drag handle for convenient towing of the ATV.

6. CARE AND MAINTENANCE

Proper care will extend the life and performance of your BLISSRIDE ATV.

- **Cleaning:** Wipe the ATV with a soft, damp cloth. Do not use abrasive cleaners or solvents. Avoid direct water spray on electrical components.
- **Battery Care:** Recharge the battery after each use. If storing for an extended period, charge the battery every 30 days to maintain its health. Do not allow the battery to fully discharge for long periods.
- **Storage:** Store the ATV in a dry, cool place away from direct sunlight and moisture.
- **Inspection:** Regularly check for loose screws, damaged wires, or worn parts. Replace any damaged components immediately.

7. TROUBLESHOOTING GUIDE

This section addresses common issues you might encounter with your ATV.

Problem	Possible Cause	Solution
ATV does not move	Battery is low or dead Loose battery connection Power switch is off Motor issue	Charge the battery fully Check and secure battery terminals Ensure power switch is ON Contact customer support
Short playtime	Battery not fully charged Old battery Overloaded vehicle	Charge battery for 8-12 hours Consider battery replacement Ensure weight limit is not exceeded
Lights or music not working	Loose wiring Media panel issue	Check all wire connections Contact customer support
Unusual noises	Loose parts Motor or gear issue	Inspect for loose components and tighten Contact customer support

8. PRODUCT SPECIFICATIONS

Feature	Specification
Product Dimensions	44 x 26 x 31 inches
Item Weight	50 pounds
ASIN	B0DFQBBCD9
Manufacturer Recommended Age	3 - 8 years
Motor	400W (Dual 200W motors)
Battery	24V 9AH
Max Speed	Up to 5 mph
Playtime per Charge	Up to 2 hours
Max Load Capacity	110 lbs
Wheel Size	14.4 inches
Seating Capacity	2 children
Manufacturer	BLISSRIDE

9. WARRANTY AND CUSTOMER SUPPORT

BLISSRIDE is committed to providing high-quality products and excellent customer service. Your BLISSRIDE ATV comes with a standard manufacturer's warranty covering defects in materials and workmanship. For specific warranty details, please refer to the warranty card included with your product or contact us directly.

For any questions, concerns, or technical support, please do not hesitate to contact our customer service team:

Email: BLISSRIDE.US@GMAIL.COM

Our support team is available to assist you with assembly, operation, troubleshooting, and parts replacement.

© 2025 BLISSRIDE. All rights reserved.
This manual is subject to change without notice.