

[Manuals.plus](#) /

> [Wisoqu](#) /

> Wisoqu Portable Robot Shape Speaker (Model ZY-010) Instruction Manual

## Wisoqu ZY-010

# Wisoqu Portable Robot Shape Speaker (Model ZY-010) Instruction Manual

Please read this manual thoroughly before operating your device.

## 1. PRODUCT OVERVIEW

---

The Wisoqu Portable Robot Shape Speaker (Model ZY-010) is a compact and versatile audio device designed for high-definition sound. Featuring a unique robot design, built-in microphone for hands-free calls, and a long-lasting battery, it is suitable for various indoor and outdoor activities. This speaker supports Bluetooth 5.0 for easy connectivity and offers a dual speaker connection system for an enhanced stereo experience.



Image: Front view of the Wisoqu Portable Robot Shape Speaker.

## 2. PACKAGE CONTENTS

---

Please check the package for the following items:

- Wisoqu Portable Robot Shape Speaker (Model ZY-010)
- USB Charging Cable
- User Manual (this document)



Image: The speaker shown with its included USB charging cable.

### 3. CONTROLS AND INDICATORS

---

Familiarize yourself with the speaker's controls and ports:



Image: Rear view of the speaker, highlighting the control panel and charging port.

- **Power Button:** Press and hold to power on/off. Short press for Play/Pause.
- **Volume Up / Next Track Button (+):** Short press to increase volume. Long press to skip to the next track.
- **Volume Down / Previous Track Button (-):** Short press to decrease volume. Long press to go to the previous track.
- **USB Charging Port:** For connecting the USB charging cable.
- **LED Indicator:** Displays connection status and charging status.
- **Microphone:** Built-in for hands-free calling.

## 4. CHARGING THE SPEAKER

Before first use, fully charge the speaker. A full charge provides approximately 6-7 hours of playback time.

1. Connect the small end of the USB charging cable to the charging port on the back of the speaker.
2. Connect the larger end of the USB charging cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show the charging status. It will typically turn off or change color once fully charged.



*Long battery life  
1000mAh high capacity battery,  
6-7 hours of long battery life  
Not just stop at the power of sound,  
but it brings the continuation of music  
Built in microphone  
Built in microphone, you can answer calls  
directly through it, no need to wait for the call.  
HD call, easy to grasp the whole situation*

Image: The speaker illustrating its long battery life capability.

## 5. SETUP AND CONNECTION

### 5.1 Powering On/Off

- **To Power On:** Press and hold the Power button until the LED indicator lights up and you hear an audible prompt.
- **To Power Off:** Press and hold the Power button until the LED indicator turns off and you hear an audible prompt.

### 5.2 Bluetooth Pairing (Single Speaker)

1. Ensure the speaker is powered on and the LED indicator is flashing, indicating it is in pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "ZY-010" from the list of devices.
4. Once connected, the LED indicator will stop flashing and remain solid, and you will hear a confirmation sound.

### 5.3 Dual Speaker Connection (TWS)

For an immersive stereo experience, you can connect two Wisoqu ZY-010 speakers together.

1. Power on both speakers. **Do not connect either speaker to your phone yet.**
2. Choose one of the speakers and **double-click its Power button**. This speaker will attempt to pair with the other.
3. Once successfully connected, you will hear a beep, and the LED indicator on both speakers will flash in a synchronized manner, or one will be solid and the other flashing.
4. Now, on your device, enable Bluetooth and search for **"ZY-010"**. Connect to it. Both speakers will now play audio simultaneously.



#### *Clear Bass*

*The mono speaker improves bass performance, making it clear and smooth while maintaining a compact form factor.*

*Upgraded sound quality, more powerful bass*

*Dual Speaker Connectivity*

*Dual Wireless Tandem System*

*Open the two speakers, do not connect the phone first, choose any one to double-click the boot button for pairing, so that the two speakers are connected, the connection will be a successful indicator light flashes, and there is a beep! Then the phone selects a "ZY-010" connection can be played at the same time two speakers*



Image: The speaker highlighting its clear bass and dual speaker connection feature.

## 6. OPERATING THE SPEAKER

### 6.1 Music Playback

- **Play/Pause:** Short press the Power button.
- **Volume Up:** Short press the "+" button.
- **Volume Down:** Short press the "-" button.
- **Next Track:** Long press the "+" button.
- **Previous Track:** Long press the "-" button.

## 6.2 Hands-Free Calling

With the built-in microphone, you can answer calls directly through the speaker when connected to your phone via Bluetooth.

- **Answer Call:** Short press the Power button when an incoming call rings.
- **End Call:** Short press the Power button during a call.
- **Reject Call:** Long press the Power button when an incoming call rings.

## 7. MAINTENANCE

To ensure the longevity and optimal performance of your speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, charge the speaker regularly, even if not in use for extended periods. Avoid fully discharging the battery frequently.
- **Water Resistance:** This speaker is not waterproof. Avoid exposure to water or excessive moisture.

## 8. TROUBLESHOOTING

If you encounter issues with your speaker, refer to the following common problems and solutions:

Problem	Possible Solution
Speaker does not power on.	Ensure the speaker is fully charged. Connect it to a power source using the USB cable.
Cannot pair with Bluetooth device.	Ensure the speaker is in pairing mode (LED flashing). Turn off and on Bluetooth on your device. Move the speaker closer to your device. Forget "ZY-010" from your device's Bluetooth list and try pairing again.
No sound or low volume.	Increase the volume on both the speaker and your connected device. Ensure the speaker is properly paired. Check if the audio source is playing.
Dual speaker connection fails.	Ensure both speakers are powered on and not connected to any other device. Double-click the power button on one speaker to initiate TWS pairing. Try resetting both speakers by powering them off and on.
Poor sound quality.	Move the speaker closer to your device to reduce interference. Ensure there are no obstructions between the speaker and the device. Check the audio source quality.

## 9. SPECIFICATIONS

- **Brand:** Wisoqu
- **Model Name:** ZY-010 (Internal Model Number: Wisoqum62ibpgzvd-12)
- **Connectivity Technology:** Bluetooth 5.0, USB (for charging)

- **Battery Capacity:** 1000mAh
- **Playback Time:** Approximately 6-7 hours
- **Sound Output:** Mono speaker with enhanced bass
- **Microphone:** Built-in for hands-free calls
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Item Weight:** 5.2 ounces
- **Package Dimensions:** 3.94 x 3.54 x 2.36 inches
- **Mounting Type:** Tabletop Mount
- **Special Features:** Dual Speaker Connection (TWS)

## 10. WARRANTY AND SUPPORT

---

Wisoqu products are designed and manufactured to the highest quality standards. This product is covered by a limited warranty from the date of purchase. For detailed warranty information, product support, or to report any issues, please contact Wisoqu customer service through your retailer or the official Wisoqu website.

Please retain your proof of purchase for warranty claims.