

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [KIDISLE](#) /

> [KIDISLE 6-in-1 Automatic Nut Milk Maker Blender HBB608K User Manual](#)

KIDISLE HBB608K

KIDISLE 6-in-1 Automatic Nut Milk Maker Blender HBB608K User Manual

Model: HBB608K

Introduction	Safety Instructions	Product Overview	Setup	Operation	Maintenance
	Troubleshooting	Specifications	Warranty & Support		

1. INTRODUCTION

Thank you for choosing the KIDISLE 6-in-1 Automatic Nut Milk Maker Blender. This appliance is designed to simplify the process of creating fresh, homemade plant-based milks, juices, and other beverages. With its versatile functions, including nut milk, oat milk, soy milk, juice, boil water, and self-cleaning, it offers convenience and efficiency for your kitchen. Please read this manual thoroughly before first use to ensure safe and optimal operation.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions.

- Read all instructions before using the appliance.
- Do not immerse the motor base, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.

- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Exercise extreme caution when moving an appliance containing hot liquid.
- The lid will be hot and steam will be present during and after operation. Handle with care.
- Ensure the lid is securely closed before operating.
- This appliance features overheating protection. If the unit overheats, it will automatically shut off. Allow it to cool down before resuming use.



Image: Diagram illustrating the internal overheating protection mechanism.

3. PRODUCT OVERVIEW

The KIDISLE HBB608K is a compact and efficient appliance designed for making various plant-based milks and beverages. Familiarize yourself with its components:



Image: Front view of the KIDISLE HBB608K Nut Milk Maker, showing the control panel and overall design.

Components:

- **Main Unit:** Contains the motor base, heating element, and control panel.
- **Pitcher/Container:** Stainless steel interior with measurement markings (SUS 304).
- **Lid:** Securely covers the container during operation.
- **Control Panel:** Touchscreen interface for function selection and operation.
- **Blades:** 8 stainless steel blades for efficient blending.
- **Handle:** Ergonomically designed for safe pouring.

Included Accessories:

- Measuring Cup
- Cleaning Brush
- Fine Mesh Strainer
- Nut Milk Bag
- Power Cable
- Warranty Card

Image: All included accessories: Cleaning Brush, Power Cable, Measuring Cup, Fine Mesh Strainer, Nut Milk Strainer Bag, and the Nut Milk Maker itself.



Image: Close-up of the SUS 304 stainless steel interior with Max/Min fill lines.



Image: View of the lid and the interior, showing the maximum fill line.



Image: Close-up of the handle and pour spout with alignment indicators.

8 Stainless Steel Blades

Enhanced Blending for Creamier Nut Milk



4-sided spoiler column

Increases food collision, reduces cutting blind spots, and achieves a more delicate and smooth taste.

Image: Detailed view of the 8 stainless steel blades and the 4-sided spoiler column for enhanced blending.

4. SETUP AND FIRST USE

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Before first use, wash the interior of the pitcher and the lid with warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the appliance on a stable, flat, and dry surface, away from heat sources and water.
4. **Power Connection:** Ensure the power cable is securely connected to the appliance and then plug it

into a grounded electrical outlet.



Image: Visual guide for initial setup: 1. Add ingredients, 2. Add water, 3. Select program and start.

5. OPERATING INSTRUCTIONS

The KIDISLE Nut Milk Maker features an intuitive touchscreen interface for easy operation. Ensure the appliance is plugged in and the lid is securely in place before starting any function.



6-in-1 Multi-Function

Craft fresh and natural plant based milk and juice



Soy milk



Nut Milk



Oat Milk



Juice



Boiled Water



Self-Clean

Image: Close-up of the control panel showing the six function options: Soy milk, Nut Milk, Oat Milk, Juice, Boil Water, and Self-Clean.

General Operation Steps:

1. Add your desired ingredients to the pitcher.
2. Add water, ensuring it is between the MIN and MAX fill lines indicated inside the pitcher.
3. Securely close the lid.
4. Plug in the appliance. The display will illuminate.
5. Select your desired function (e.g., "Nut Milk", "Soy milk", "Oat Milk", "Juice", "Boil Water", "Self-

Clean") by touching the corresponding icon on the control panel.

6. Press the "Start/Cancel" button to begin the selected program. The display will show the remaining time.
7. Once the program is complete, the appliance will beep. Unplug the unit and carefully pour out the contents.

Specific Functions:

- **Nut Milk / Soymilk / Oat Milk:** These functions are designed to process raw ingredients into smooth, plant-based milks. Follow recommended ingredient-to-water ratios for best results. Use the included mesh strainer or nut milk bag for a smoother consistency if desired.
- **Juice:** This function blends fruits and vegetables into fresh juice. No heating is involved.
- **Boil Water:** Heats water to boiling temperature. Useful for tea or other hot beverages.
- **Self-Clean:** For automated cleaning of the pitcher. Refer to the Maintenance section for details.

Delay Start Function:

The Delay Start function allows you to program the appliance to begin operation at a later time, up to 12 hours in advance. This is useful for preparing ingredients the night before and having fresh milk ready in the morning.

1. Add ingredients and water to the pitcher.
2. Secure the lid.
3. Select your desired function (e.g., "Nut Milk").
4. Press the "Delay Start" button. The display will show a default delay time.
5. Adjust the delay time using the appropriate controls (refer to the control panel for specific buttons, usually the same function buttons or dedicated +/- buttons).
6. Press "Start/Cancel" to confirm the delay start. The appliance will count down the delay time and then automatically begin the selected program.



Image: Illustration of the 12-hour Delay Start function, showing ingredients added at 8 PM for milk ready at 8 AM.

Keep Warm Function:

After certain hot programs (e.g., Soymilk, Boil Water), the appliance may automatically enter a 2-hour Keep Warm mode to maintain the beverage at an ideal serving temperature.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your KIDISLE Nut Milk Maker.

Self-Cleaning Function:

1. After use, rinse the pitcher to remove large food particles.

2. Add water to the pitcher, up to the MAX fill line. A few drops of mild dish soap can be added for enhanced cleaning.
3. Secure the lid.
4. Select the "Self-Clean" function on the control panel.
5. Press "Start/Cancel" to begin the cleaning cycle.
6. Once complete, carefully discard the water and rinse the pitcher thoroughly with clean water.



Image: The appliance performing its self-cleaning cycle with hot water, indicated by steam and a temperature icon.

Manual Cleaning:

- Always unplug the appliance before cleaning.
- Use the provided cleaning brush to clean around the blades and the interior of the pitcher.

- Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or scourers.
- The lid can be washed with warm, soapy water.
- Ensure all parts are completely dry before storing or next use.
- **Note:** The main unit (motor base) is not dishwasher safe and should never be immersed in water.

7. TROUBLESHOOTING

If you encounter issues with your appliance, please refer to the following table before contacting customer service.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; lid not properly secured.	Check power connection; ensure lid is correctly aligned and closed; check household circuit breaker.
Error code (e.g., E1) displayed.	Overheating; insufficient water/ingredients; sensor malfunction.	Unplug and let cool for 15-30 minutes; ensure ingredients and water are within MIN/MAX lines; if issue persists, contact customer support.
Milk is not smooth enough.	Insufficient blending time; too many ingredients; hard ingredients not pre-soaked.	Ensure correct program is selected; reduce ingredient quantity; pre-soak hard nuts/grains for several hours or overnight. Use the included strainer/bag.
Burning smell during operation.	Overheating; motor overload; food stuck to heating element.	Immediately unplug the unit. Allow to cool completely. Clean the interior thoroughly. Ensure ingredients are not exceeding MAX line. If smell persists, discontinue use and contact support.
Lid is difficult to open after use.	Pressure buildup from hot contents.	Allow the unit to cool down for a few minutes before attempting to open the lid. Use caution as steam may escape.

8. SPECIFICATIONS

Feature	Detail
Model Name	HBB608K
Brand	KIDISLE
Capacity	20 oz (approximately 1.3 lbs)
Wattage	600 watts
Material	Stainless Steel (SUS 304 interior)

Feature	Detail
Product Dimensions	5"W x 8"H (approximate, based on image)
Special Features	6-in-1 Functionality, Automatic Cleaning, Delay Start (up to 12 hours), 2-Hour Keep Warm, Overheating Protection
Power Source	AC
Item Weight	3.83 Pounds



Image: Visual representation of the product dimensions, showing height and width.

9. WARRANTY AND CUSTOMER SUPPORT

KIDISLE provides a lifetime service for this product. If you experience any issues or have questions, please contact our professional after-sales service team.

For support, please refer to the contact information provided on your warranty card or visit the official KIDISLE website.

Please retain your proof of purchase for warranty claims.

© 2025 KIDISLE. All rights reserved.