



[Manuals.plus](#) /

› [Pounur](#) /

› Pounur H9 Wireless Earbuds User Manual

Pounur H9

Pounur H9 Wireless Earbuds User Manual

Model: H9

INTRODUCTION

Thank you for choosing the Pounur H9 Wireless Earbuds. This manual provides detailed instructions for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

PACKAGE CONTENTS

Verify that all items are present in your package:

- Pounur H9 Wireless Earbuds (Left and Right)
- Wireless Charging Case
- USB Charging Cable
- Multiple Sizes of Ear Tips (S, M, L)
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components of your Pounur H9 Wireless Earbuds.



Image: Poounur H9 Wireless Earbuds and Charging Case. The image displays the earbuds inside the open charging case, showing an LED battery display. It also illustrates the individual earbud weight (4.7g) and dimensions (30*39*25 mm), and the charging case weight (47.4g) and dimensions (74*50*31 mm). Playtime is indicated as 40 hours with the charging case and 10 hours for earbuds alone.

Hi-Fi Stereo Sound

Provide authentic sound and powerful bass performance



Image: Exploded view of a Poounur H9 earbud, highlighting internal components such as the driver and sound chamber. Icons indicate Bluetooth 5.3, 13MM drivers, and bass sound capabilities.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge both the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB charging cable to the charging port on the case and to a power source. The LED display on the charging case will indicate the charging status and battery level. A full charge typically takes 1-2 hours.

2. Powering On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on. Alternatively, press and hold the touch control area on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid; they will power off automatically. Alternatively, press and hold the touch control area on both earbuds for 5 seconds.

3. Bluetooth Pairing

1. Ensure the earbuds are charged and powered on.
2. Open the charging case. The earbuds will enter pairing mode, indicated by a flashing LED light on one of the earbuds.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "Poonur H9" from the list of devices.
5. Once connected, the LED indicator on the earbud will turn off or flash slowly, and you will hear a confirmation tone.

The earbuds will automatically reconnect to the last paired device when powered on, if the device's Bluetooth is active and within range.



Image: An illustration of a Poounur H9 earbud highlighting the Bluetooth 5.3 chip and stable signal transmission up to 15 meters. This demonstrates the advanced connectivity technology.

4. Fitting the Earbuds

For optimal sound quality and comfort, choose the ear tips that best fit your ears. Gently insert the earbuds into your ear canal and rotate them slightly until they feel secure and comfortable. The ear hooks should rest over your ears for added stability.

Ergonomic Design for Sports

Take out and put on, boost energy and burn calorie



Secure-Fit



S



M



L

Image: A woman wearing the Pounur H9 earbuds, demonstrating their ergonomic design and secure fit. The image also shows available ear tip sizes (S, M, L) to ensure a comfortable and stable fit for various users.

OPERATING INSTRUCTIONS

The Pounur H9 earbuds feature touch controls for various functions.

Music Playback

- **Play/Pause:** Single tap the touch control area on either the Left (L) or Right (R) earbud.
- **Next Track:** Double tap the touch control area on the Right (R) earbud.
- **Previous Track:** Double tap the touch control area on the Left (L) earbud.
- **Volume Up:** Triple tap the touch control area on the Right (R) earbud.
- **Volume Down:** Triple tap the touch control area on the Left (L) earbud.

Call Management

- **Answer/End Call:** Single tap the touch control area on either earbud.
- **Reject Call:** Press and hold the touch control area on either earbud for 2 seconds.

Voice Assistant

- **Activate Voice Assistant:** Press and hold the touch control area on either earbud for 2 seconds (when not on a call).

MAINTENANCE

Proper maintenance ensures the longevity and performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents. For ear tips, remove them and clean with a mild soap solution, then rinse and dry thoroughly before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place away from extreme temperatures.
- **Water Resistance:** The earbuds are IP7 waterproof, meaning they are protected against immersion in water up to 1 meter for up to 30 minutes. However, they are not designed for swimming or prolonged submersion. Ensure the charging port is dry before charging.

IP7 Waterproof

With the nano coating, the sports running headphones supports IPX7 Waterproof, can prevent from sweat or splash



Image: An illustration showing the Poounur H9 earbuds with water droplets, indicating their IP7 waterproof rating. Icons represent resistance to rainy days, sweat, and splashes, highlighting their suitability for sports and outdoor activities.

TROUBLESHOOTING

If you encounter issues with your Poounur H9 earbuds, refer to the following common solutions:

Problem	Solution
Earbuds not pairing with device.	<ul style="list-style-type: none">• Ensure earbuds are charged and powered on.• Turn off and on Bluetooth on your device.• Forget "Poounur H9" from your device's Bluetooth list and try pairing again.• Ensure earbuds are within 10 meters of your device.

Problem	Solution
No sound from one or both earbuds.	<ul style="list-style-type: none">• Check the volume level on both your device and the earbuds.• Ensure earbuds are properly connected to your device.• Try resetting the earbuds (place them in the case, close, then reopen).
Earbuds not charging.	<ul style="list-style-type: none">• Ensure the charging cable is securely connected to both the case and the power source.• Check if the charging contacts on the earbuds and inside the case are clean and free of debris.• Try a different charging cable or power adapter.
Poor call quality.	<ul style="list-style-type: none">• Ensure the earbuds are positioned correctly in your ears.• Move closer to your connected device to improve signal strength.• Avoid noisy environments if possible.

SPECIFICATIONS

Key technical specifications for the Poonur H9 Wireless Earbuds:

- **Model Name:** H9
- **Brand:** Poonur
- **Connectivity Technology:** Wireless
- **Wireless Communication Technology:** Bluetooth 5.3
- **Ear Placement:** In Ear
- **Form Factor:** In Ear
- **Control Type:** Touch, Media Control
- **Special Feature:** Noise Cancellation (Microphone-based for calls)
- **Material:** Plastic
- **Color:** Black
- **Item Weight (Earbud):** Approximately 2 Grams (0.071 ounces)
- **Product Dimensions:** 0.79 x 0.79 x 0.79 inches (earbud)
- **Battery:** 1 Lithium Polymer battery (included)
- **Playback Time:** Up to 10 hours (earbuds), up to 40 hours (with charging case)
- **Waterproof Rating:** IP7

WARRANTY AND SUPPORT

Poonur products are designed for reliability and performance. For warranty information or technical support, please refer to the warranty card included in your package or contact Poonur customer service through the retailer where the product was purchased. Please retain your proof of purchase for warranty claims.

