KRPTQJoo Joo5002

KRPTQJoo Remote Control Instruction Manual

For Alpine CDE-151E, CDE-152E, CDE-153EBT, CDE-152 Car CD Receivers

Introduction

This manual provides instructions for the setup, operation, and maintenance of your KRPTQJoo replacement remote control. This remote is designed for use with specific Alpine car CD receiver models: CDE-151E, CDE-152E, CDE-153EBT, and CDE-152. Please read this manual thoroughly before use to ensure proper functionality.

1. Setup

1.1 Battery Installation

The remote control requires two (2) AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Battery compartment with cover removed. Insert two AAA batteries as shown.

1.2 Compatibility Check

This remote control is specifically designed for Alpine car CD receiver models CDE-151E, CDE-152E, CDE-153EBT, and CDE-152. Before use, confirm that your car stereo model is listed. If your original remote control differs significantly in appearance or button layout, this replacement remote may not be fully compatible or some buttons may not function as expected. Refer to your car stereo's original manual for specific remote control compatibility details.

2. Operating Instructions

Familiarize yourself with the remote control's buttons and their functions:



Figure 2: Front view of the remote control.

- **POWER** (Blue Button): Turns the car stereo system on or off.
- **SOURCE**: Cycles through available audio sources (e.g., CD, Radio, USB, AUX).
- **BAND**: Changes radio bands (e.g., FM1, FM2, AM).
- **VOLUME** (Up/Down Arrows): Adjusts the audio output level.
- **PLAY/PAUSE** (▶/‖): Starts or pauses playback of media.
- **SKIP/TRACK** (/): Skips to the previous or next track/station.
- **A.PROC.**: Accesses audio processing or sound adjustment menus.
- **MUTE**: Silences the audio output.

Point the remote control directly at the infrared receiver on your Alpine car stereo for optimal performance. Ensure there are no obstructions between the remote and the stereo.

3. Maintenance

3.1 Battery Replacement

Replace the batteries when the remote control's range decreases or it stops responding. Always replace both AAA

batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.

3.2 Cleaning

Wipe the remote control with a soft, dry cloth to remove dust and dirt. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

3.3 Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

4. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are installed correctly with the correct polarity.
  - Replace the batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the car stereo's infrared receiver.
  - Verify that your car stereo model is one of the compatible Alpine models (CDE-151E, CDE-152E, CDE-153EBT, CDE-152).
- **Limited range or intermittent response:**
  - Replace the batteries.
  - Ensure you are within the maximum operating range of 8 meters (approximately 26 feet).
  - Point the remote directly at the stereo's IR receiver.
- **Some buttons do not work:**
  - This remote is a replacement and may not support all functions of your original stereo's remote, especially if your original remote had a different button layout or advanced features. Refer to your car stereo's manual to confirm supported remote functions.

5. Specifications

Brand	KRPTQJoo
Model Number	Joo5002
Compatible Devices	Alpine CDE-151E, CDE-152E, CDE-153EBT, CDE-152 Car CD Receivers
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (Alkaline recommended)
Maximum Range	8 meters (approx. 26 feet)
Color	Black

6. Warranty and Support

6.1 Warranty Information

This product comes with a 90-day warranty from the date of purchase, covering manufacturing defects. This warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

6.2 Customer Support

If you encounter any issues or have questions regarding your KRPTQJoo remote control, please contact the seller directly. They aim to respond to inquiries within 12 hours to assist with any problems you may experience.

© 2024 KRPTQJoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question