



Manuals.plus /

- › First Ride On /
- › First Ride On 12V Licensed Porsche 718 Spyder Electric Car Instruction Manual

First Ride On PS001

First Ride On 12V Licensed Porsche 718 Spyder Electric Car Instruction Manual

Model: PS001

INTRODUCTION

Thank you for choosing the First Ride On 12V Licensed Porsche 718 Spyder Electric Car. This manual provides essential information for the safe assembly, operation, and maintenance of your new ride-on toy. Please read it thoroughly before use and retain it for future reference.

PORSCHE 718 SPYDER

Enhance playtime with an officially licensed Porsche ride-on, embodying iconic design.



Image: Front view of the white First Ride On Porsche 718 Spyder Electric Car.

SAFETY INFORMATION

Important Safety Warnings:

- Always supervise children while using this ride-on car.
- Ensure the safety belt is fastened and doors are locked before operation.
- Use only on flat, stable surfaces. Avoid slopes, uneven terrain, or public roads.
- Regularly check for any damage to the vehicle, including wheels, steering, and electrical components. Discontinue use if any issues are found.
- Suitable for ages 3-8 years, with a maximum weight of 66 lbs and maximum height of 49 inches.

CRAFTED WITH PRECISION

Admire the realistic tires and bright lights, capturing Porsche's true essence.



Seat Belt



Lockable Doors



Shock-absorbing Design

Image: Detailed view highlighting the seatbelt, lockable doors, and shock-absorbing design for enhanced safety.

WHAT'S IN THE BOX

Upon opening the package, please verify that all components are present:

- Car Body
- Charging Box
- Instruction Manual

Additional parts for assembly, such as wheels, steering wheel, and small accessories, will be found within the packaging.

Video: A child and adult unboxing and assembling the Porsche 718 Spyder ride-on car, showing various components and the assembly process.

SETUP AND ASSEMBLY

Follow these steps to assemble your Porsche 718 Spyder Electric Car:

1. **Wheel Installation:** Attach the wheels to the axles. Ensure they are securely fastened with the provided nuts and washers. The drive wheels (rear) may differ slightly from the steering wheels (front).
2. **Steering Wheel Attachment:** Connect the steering wheel's electrical connector to the corresponding port in the dashboard. Carefully align and push the steering wheel onto the steering column until it clicks into place.
3. **Seat Installation:** Connect the battery terminals (red to red, black to black). Place the seat into the car body, aligning the tabs with the slots. Secure the seat with the provided screws or locking pins.
4. **Windshield and Mirrors:** Attach the windshield and side mirrors by snapping them into their designated slots.
5. **Control Panel:** Insert the mock control panel into its designated slot on the dashboard.

Video: A detailed guide on assembling the Porsche 718 Spyder, including wheel, seat, and steering wheel installation.

Video: An in-depth assembly process for the ride-on car, demonstrating how to attach various parts and connect electrical components.

OPERATING INSTRUCTIONS

Your Porsche 718 Spyder offers interactive driving modes for both children and parental control.

Powering On/Off

- Locate the power button on the dashboard. Press to turn the car on or off.

Driving Modes

The car supports two driving modes: Manual (child-operated) and Remote (parental control).

- **Manual Mode:** The child uses the foot pedal for acceleration and the steering wheel to steer.
- **Remote Control Mode:** Parents can use the remote control to steer, accelerate, and brake the car. This is ideal for younger children or for safety supervision.

DUAL DRIVING DELIGHT

Easily adjust speed and control with the parental remote for a safe ride.



Image: A parent operating the remote control while a child sits in the ride-on car, demonstrating dual control functionality.

Speed Control

- The car features adjustable speeds up to 3.8 mph. Use the speed selector on the dashboard or remote control to choose between 3 speed options.

Media Features

The car includes various entertainment options:

- **Built-in Music:** Access pre-loaded songs via the music button.
- **Bluetooth:** Connect your device wirelessly to play custom audio.
- **USB/MP3:** Plug in a USB drive or MP3 player for additional music options.
- **Radio:** Tune into available radio stations.
- **Storytelling Mode:** Engage with pre-recorded stories for an educational experience.

PLAYTIME FAVORITES



-  Radio
-  Music
-  Stories
-  MP3
-  USB
-  Startup Sound
-  Speaker

Image: Close-up of the car's dashboard, displaying the media console with buttons for music, stories, USB, MP3, Bluetooth, and radio functions.

LED Lights

- Functional headlights and taillights enhance realism and visibility. Activate them via the designated switch on the dashboard.

Video: A white Porsche 718 Spyder ride-on car being operated via remote control indoors, demonstrating its movement and responsiveness.

Video: A child driving the Porsche 718 Spyder ride-on car outdoors, showcasing its performance on various terrains.

MAINTENANCE

- **Cleaning:** Wipe the car body with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Battery Care:** Charge the 12V battery fully before first use (typically 8-12 hours). Do not overcharge. For optimal battery life, charge after each use and at least once a month during periods of non-use.
- **Storage:** Store the car in a dry, cool place away from direct sunlight and moisture.

- **Inspection:** Periodically inspect all nuts, bolts, and electrical connections to ensure they are secure.

TROUBLESHOOTING

If you encounter any issues, refer to the following common solutions:

- **Car not moving:** Check battery connection, ensure the car is charged, and verify the manual/remote mode switch is correctly set.
- **Remote control not working:** Ensure batteries are installed correctly in the remote and that the remote is paired with the car (refer to remote pairing instructions in the full manual).
- **Reduced power/speed:** The battery may need charging, or it could be nearing the end of its lifespan.
- **Unusual noises:** Inspect wheels and axles for obstructions or loose parts.

SPECIFICATIONS

Feature	Detail
Product Dimensions	42.52 x 25.2 x 17.32 inches
Item Weight	30.9 pounds
Item Model Number	PS001
Manufacturer Recommended Age	3 - 8 years
Battery Type	12V (1 Nonstandard Battery required)
Max Weight Capacity	66 lbs
Max Height Capacity	49 inches
Speeds	3 adjustable speeds (up to 3.8 mph)

PRODUCT DIMENSIONS



66 LBS
Max Weight



Image: Diagram illustrating the key product dimensions of the ride-on car.

WARRANTY AND SUPPORT

For warranty information, technical support, or replacement parts, please contact First Ride On customer service. Keep your purchase receipt and product model number (PS001) handy for faster service.