

[Manuals.plus](#) /

› [North Bayou](#) /

› North Bayou NB-P5 Full Motion TV Wall Mount Instruction Manual

North Bayou NB-P5

North Bayou NB-P5 Full Motion TV Wall Mount Instruction Manual

Model: NB-P5

Brand: North Bayou

1. INTRODUCTION

This manual provides detailed instructions for the safe and proper installation, operation, and maintenance of your North Bayou NB-P5 Full Motion TV Wall Mount. This mount is designed for LCD/LED televisions ranging from 32 to 60 inches and supports a maximum weight of 36.4 kg (80 lbs). It features a dual-arm design for enhanced strength and stability, offering full motion capabilities including tilt, swivel, and extension for optimal viewing angles. Please read this manual thoroughly before installation and keep it for future reference.



Image 1: North Bayou NB-P5 Full Motion TV Wall Mount packaging highlighting features.

2. SAFETY INFORMATION

WARNING: Failure to read and follow all instructions may result in personal injury, property damage, or voiding of your warranty. If you have any questions, please contact customer support.

- Ensure the mounting surface can safely support the combined weight of the mount and your TV.
- Do not exceed the maximum weight capacity of 36.4 kg (80 lbs).
- Always use the provided hardware and follow the installation steps precisely.
- This product is intended for indoor use only.
- Keep children and pets away during installation.
- Periodically check all screws and connections to ensure they remain secure.

3. PACKAGE CONTENTS

Please verify that all components are present and undamaged before beginning installation. If any parts are missing or damaged, do not proceed with installation and contact customer support.

- Wall Plate Assembly
- TV Bracket Arms (x2)
- Mounting Hardware Kit (screws, anchors, washers, spacers)
- Cable Management Clips
- Instruction Manual

4. SPECIFICATIONS

Model Number	NB-P5
Compatible TV Sizes	32 - 60 inches
Weight Capacity	36.4 kg (80 lbs)
VESA Compatibility	100x100mm to 600x400mm
Tilt Angle	+3° to -5°
Swivel Angle	Up to 180° (depending on TV size)
Material	Aluminum
Color	Black
Item Weight	4 kg
Manufacturer	Marion Trade

5. SETUP AND INSTALLATION

Before you begin, ensure you have the necessary tools: a drill, stud finder, level, screwdriver, and pencil. It is recommended to have two people for installation.

Step 5.1: Determine Mounting Location

1. Use a stud finder to locate the center of a wooden stud in your desired mounting location. Mark the center of the stud.
2. Ensure the chosen location is at an appropriate viewing height and free from electrical wires or plumbing.

Step 5.2: Attach Wall Plate to Wall



Image 2: Rear view of the mount, illustrating the wall plate and arm structure.

1. Hold the wall plate against the wall at the marked location. Use a level to ensure it is perfectly horizontal.
2. Mark the pilot hole locations through the wall plate onto the wall.
3. Drill pilot holes into the wall. For wood studs, drill appropriate size holes. For concrete/brick, use a masonry drill bit and insert wall anchors.
4. Secure the wall plate to the wall using the provided lag bolts and washers. Tighten firmly, but do not overtighten.

Step 5.3: Attach TV Brackets to TV



Image 3: The full motion TV mount with its articulating arms.

1. Lay your TV face down on a soft, clean surface to prevent scratches.
2. Identify the VESA mounting holes on the back of your TV.
3. Select the correct size screws, washers, and spacers from the hardware kit that fit your TV's mounting holes.
4. Attach the two TV bracket arms to the back of your TV. Ensure they are centered and securely fastened. The hooks on the bracket arms should face upwards.

Step 5.4: Hang TV on Wall Plate

1. With assistance, carefully lift the TV with the attached brackets.
2. Hook the TV bracket arms onto the wall plate. Ensure both hooks are securely seated on the wall plate.
3. Engage the safety locking screws (if applicable) on the bottom of the TV bracket arms to prevent accidental dislodgement.

6. OPERATING INSTRUCTIONS

The NB-P5 mount offers full motion capabilities to optimize your viewing experience.

- **Tilt Adjustment:** Loosen the tilt adjustment knobs or bolts on the TV bracket arms, adjust the TV to your desired vertical angle (+3° to -5°), and then securely tighten the knobs/bolts.
- **Swivel Adjustment:** Gently push or pull the TV to swivel it horizontally up to 180 degrees. The friction joints are designed to hold the position.
- **Extension/Retraction:** Extend or retract the TV from the wall by gently pulling or pushing the TV. The dual arms allow for smooth movement.
- **Cable Management:** Use the integrated cable management clips on the arms to route and secure your TV cables for a neat and organized appearance.

7. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your TV wall mount.

- **Cleaning:** Wipe the mount with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Periodic Checks:** Every few months, check all mounting screws and connections to ensure they are still tight and secure. Re-tighten if necessary.
- **Lubrication:** The articulating joints are designed for smooth movement and generally do not require lubrication. If movement becomes stiff, contact customer support.

8. TROUBLESHOOTING

If you encounter any issues with your TV wall mount, refer to the following common problems and solutions:

- **TV is not level:** Check the wall plate installation with a level. If the wall plate is level, adjust the TV bracket arms if they have a leveling feature, or re-adjust the TV's position on the brackets.
- **Mount feels loose:** Immediately remove the TV from the mount. Re-check all wall mounting screws and TV bracket screws. Ensure they are securely tightened. Verify the wall structure is sound.
- **Difficulty adjusting tilt/swivel:** Ensure any locking knobs or bolts for tilt adjustment are loosened before attempting to adjust. For swivel, ensure no cables are snagged.
- **Missing parts:** Do not proceed with installation. Contact customer support for replacement parts.

9. WARRANTY AND SUPPORT

This North Bayou NB-P5 Full Motion TV Wall Mount comes with a standard warranty from North Bayou. Please refer to the warranty card included in your package or contact the manufacturer for specific terms and conditions.

For technical support, missing parts, or warranty claims, please contact Marion Trade, the manufacturer, or your local distributor. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question