



Manuals.plus /

› FENTON /

› FENTON F-900051 Men's Analog Wrist Watch User Manual

FENTON F-900051

FENTON F-900051 Men's Analog Wrist Watch User Manual

Model: F-900051

INTRODUCTION

Thank you for choosing the FENTON F-900051 Men's Analog Wrist Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read it carefully to ensure optimal performance and longevity of your watch.



Figure 1: FENTON F-900051 Men's Analog Wrist Watch. This image shows the watch from an angled perspective, highlighting its unique black dial with Arabic numerals and the silver-tone stainless steel bracelet.

WATCH COMPONENTS

Familiarize yourself with the main components of your FENTON F-900051 watch:

- **Case:** The main body of the watch, made of alloy steel.
- **Dial:** Black analog display with unique hour markers and central minute/second disc.
- **Crown:** Used for setting the time. Located on the right side of the case.
- **Bracelet:** Stainless steel metal band with a deployant clasp.
- **Case Back:** Engraved with "STAINLESS STEEL BACK" and "FENTON TIME COLLECTION".
- **Crystal:** Mineral glass protecting the dial.



Figure 2: Rear view of the FENTON F-900051 watch. This image displays the stainless steel case back with brand engravings and the metal bracelet with its deployant clasp mechanism.

SETUP AND TIME SETTING

Your FENTON F-900051 watch is powered by a precise quartz movement and requires minimal setup.

1. **Unpacking:** Carefully remove the watch from its packaging.
2. **Time Setting:**
 - Locate the crown on the right side of the watch case.
 - Gently pull the crown outwards to the time-setting position. You may feel a slight click.
 - Rotate the crown clockwise or counter-clockwise to adjust the hour and minute indicators to the correct time. The watch features a unique dial design where the outer ring indicates hours and the central disc indicates minutes and seconds.
 - Once the correct time is set, push the crown back into its original position against the watch case. This will

start the watch movement.

3. **Bracelet Adjustment:** If the stainless steel bracelet is too loose or too tight, it may need adjustment. This typically involves removing or adding links. It is recommended to have this done by a professional watchmaker or jeweler to avoid damage.



Figure 3: Front view of the FENTON F-900051 watch, illustrating its dimensions (47mm case diameter). The crown for time adjustment is visible on the right side.

OPERATING YOUR WATCH

Your FENTON F-900051 watch is designed for straightforward operation.

- **Time Display:** The watch displays time using a unique analog system. The outer ring with Arabic numerals indicates the hours, while the central rotating disc indicates minutes and seconds.
- **Power Source:** The watch is powered by a battery. When the watch stops or the movement becomes erratic, it may be time to replace the battery.

- **Water Resistance:** This watch has a water resistance depth of 30 meters (3 ATM). This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water. It is **not** suitable for swimming, diving, or showering. Avoid operating the crown while the watch is wet.



Figure 4: The FENTON F-900051 watch worn on a wrist, demonstrating its appearance and fit.

CARE AND MAINTENANCE

Proper care will help maintain the appearance and functionality of your FENTON watch.

- **Cleaning:** Wipe the watch case and bracelet regularly with a soft, dry cloth to remove dust and dirt. For the stainless steel bracelet, a slightly damp cloth can be used, followed by immediate drying.
- **Avoid Chemicals:** Do not expose the watch to harsh chemicals, solvents, or detergents, as these can damage the case, crystal, or bracelet.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes, which can affect the battery life and movement accuracy.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields (e.g., speakers, refrigerators, mobile phones) as

they can interfere with the quartz movement.

- **Battery Replacement:** When the battery needs replacement, it is recommended to take the watch to a qualified watch repair professional to ensure proper sealing and maintain water resistance.
- **Storage:** When not wearing the watch, store it in a dry, cool place, away from direct sunlight.

TROUBLESHOOTING

If you encounter any issues with your FENTON F-900051 watch, please refer to the following common solutions:

Problem	Possible Cause	Solution
Watch has stopped or is running slow.	Depleted battery.	Replace the battery. It is recommended to have this done by a professional.
Time is incorrect.	Crown is not fully pushed in, or time was not set correctly.	Ensure the crown is fully pushed in. Re-set the time as per the "Setup and Time Setting" section.
Condensation under the crystal.	Exposure to extreme temperature changes or moisture ingress.	Immediately take the watch to a professional watchmaker for inspection and drying to prevent internal damage.
Bracelet feels uncomfortable.	Incorrect bracelet size.	Adjust the bracelet size by adding or removing links. Professional assistance is recommended.

If the problem persists after attempting these solutions, please contact FENTON customer support or a certified watch repair center.

SPECIFICATIONS

Feature	Detail
Model Number	F-900051 (FENTON-900051)
Brand	FENTON
Movement Type	Quartz
Display Type	Analog
Case Material	Alloy Steel
Case Diameter	47 mm
Case Thickness	10 mm
Band Material	Stainless Steel
Band Width	22 mm
Band Colour	Silver
Dial Colour	Black
Crystal Material	Mineral Glass
Water Resistance Depth	30 Metres (3 ATM)
Item Weight	50 Grams
Special Features	Lightweight, Scratch-Resistant, Shock Resistant

WARRANTY INFORMATION

Your FENTON F-900051 watch comes with a **Limited Warranty**. Please retain your proof of purchase for any warranty claims. The warranty typically covers manufacturing defects in materials and workmanship under normal use. It generally does not cover:

- Battery life.
- Normal wear and tear (e.g., scratches on case, crystal, or bracelet).
- Damage resulting from improper handling, lack of care, accidents, or unauthorized repairs.
- Water damage if the watch was exposed to conditions beyond its specified water resistance (30 meters / 3 ATM).

For specific terms and conditions of your warranty, please refer to the warranty card included with your purchase or contact FENTON customer support.

CUSTOMER SUPPORT

For further assistance, inquiries, or service requests regarding your FENTON F-900051 watch, please contact FENTON customer support. When contacting support, please have your model number (F-900051) and proof of purchase readily available.

Contact information for FENTON customer support is typically found on the product packaging or the official FENTON website.

