

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Wanish](#) /

› [Wanish Electric Warming Tray FWT-1000 User Manual](#)

Wanish FWT-1000

Wanish Electric Warming Tray FWT-1000 User Manual

Model: FWT-1000 (Extra Long 40"x12")

INTRODUCTION

Thank you for choosing the Wanish Electric Warming Tray FWT-1000. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new appliance. Please read these instructions thoroughly before first use and keep them for future reference.

SAFETY INFORMATION

Your safety is our utmost concern. Please observe the following safety measures:

- Always place the warming tray on a stable, heat-resistant surface.
- Ensure the power cord is not damaged and is properly plugged into a grounded outlet.
- Do not immerse the appliance in water or any other liquid.
- Avoid touching the heating surface directly when the unit is on or hot. Use the cool-touch handles for repositioning.
- Keep out of reach of children and pets.
- Do not use the appliance for purposes other than warming food.
- Unplug the unit when not in use and before cleaning.
- The warming tray features overheat protection; it will not exceed 284°F (140°C).
- Constructed with V0 flame-retardant materials and ETL certified for safety.

PRODUCT FEATURES

- **Elegant Design:** Features a black heat-resistant tempered glass surface with gold metal edges.

- **Generous Size:** Extra long 40"x12" (101.6 cm x 30.48 cm) heating surface.
- **Efficient Heating:** Utilizes PTC heating technology for fast and uniform full-surface heating.
- **Two Temperature Modes:** Select between Low (approx. 158°F / 70°C) and High (approx. 284°F / 140°C) settings.
- **Universal Compatibility:** Suitable for 99% of tableware types, including glass, ceramic, and metal.
- **No Assembly Required:** Ready to use straight out of the box.
- **Extended Power Cord:** A 78" (198 cm) power cord provides flexible placement options.
- **Integrated Thermostat:** Maintains consistent temperature and prevents overheating.
- **Cool-Touch Handles:** Allows for safe movement of the tray even when hot.
- **Multi-functional Use:** Beyond food warming, it can be used for defrosting, heating masks, or promoting dough fermentation.




Image: The Wanish Electric Warming Tray FWT-1000 showcasing its sleek design and capacity to hold multiple dishes.

SETUP

1. Unpack the Wanish Electric Warming Tray from its packaging.
2. Place the warming tray on a flat, stable, and heat-resistant surface, such as a countertop or tabletop. Ensure there is adequate space around the unit for ventilation.
3. Plug the 78-inch power cord into a standard 110V electrical outlet.
4. The unit is now ready for operation.



Image: Visual guide demonstrating the simple setup and use of the warming tray.

OPERATING INSTRUCTIONS

The Wanish Electric Warming Tray is designed for straightforward use:

1. After plugging in the unit, locate the power switch on the side of the tray.
2. Slide the switch to the 'Low' or 'High' position to activate heating. The 'Warm Indicator Light' will illuminate.
3. **Low Setting:** Ideal for keeping already warm food at serving temperature (approximately 158°F / 70°C).
4. **High Setting:** Suitable for warming up cooler dishes or maintaining higher temperatures (approximately 284°F / 140°C).
5. Place your heat-safe dishes directly onto the tempered glass surface. The full-surface heating ensures even warmth distribution.
6. To turn off the warming tray, slide the switch to the 'Off' position. The indicator light will turn off.

Temperature Adjustable, Easy To Operate

OURS



- ✓ 2 Temperature Modes
- ✓ High 284°F/ Low 158°F
- ✓ 2 temperature settings are sufficient for most uses.
- ✓ Button operation is simple and easy for the elderly.
- ✓ Side button design avoids dishes, avoid accidental touch. Doesn't block the sight of temperature adjustment.
- ✓ Mechanical buttons with long service life.

OTHERS



- ✗ Easy to lose touch sensitivity
- ✗ Easy to accidentally touch and cause functional changes during use
- ✗ Large temperature control panel occupies heating area
- ✗ Difficult to control with wet hands
- ✗ Easy to forget to unlock the child lock mode
- ✗ Complex modes are not user-friendly for the elderly
- ✗ Easy to hide under dishes, difficult to operate

Image: Detail of the simple two-mode temperature adjustment switch.

Video: Official Wanish video demonstrating the Gold Edge Warming Mat in use, showing its elegant appearance and functionality.

MAINTENANCE

Proper care will ensure the longevity of your warming tray:

- Always unplug the appliance and allow it to cool completely before cleaning.
- Wipe the tempered glass surface with a soft, damp cloth. For stubborn stains, a mild glass cleaner can be used.
- Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the surface.
- Wipe the gold metal edges with a soft, dry cloth.
- Ensure the unit is completely dry before storing or next use.
- Store in a cool, dry place.

TROUBLESHOOTING

If you encounter any issues, please refer to the following common solutions:

Problem	Possible Cause	Solution
Warming tray does not turn on.	Not plugged in; power switch is off; power outage.	Ensure the power cord is securely plugged in. Slide the power switch to 'Low' or 'High'. Check your household's power supply.
Food is not warming sufficiently.	Incorrect temperature setting; cold food placed on low setting.	Ensure the switch is on 'High' for colder items or if faster warming is desired. Allow sufficient time for the tray to heat up.
Surface is too hot to touch.	This is normal for the heating surface.	Always use the cool-touch handles for moving the tray. Avoid direct contact with the main heating surface.

SPECIFICATIONS

Attribute	Detail
Model Number	FWT-1000
Brand	Wanish
Product Dimensions	40"L x 12"W x 1.18"H (101.6 cm x 30.48 cm x 3 cm)
Item Weight	5 pounds (2.27 kg)
Voltage	110 Volts
Wattage	300 watts
Maximum Temperature	284°F (140°C)
Material	Heat-resistant Tempered Glass, Premium Rose Gold Edges
Power Source	Corded Electric
Certifications	ETL Certified

WARRANTY AND SUPPORT

Wanish offers a **365-day trouble-free replacement guarantee**. If any quality issues affect your purchase within the first 365 days from the date of purchase, we will provide a seamless replacement. No repairs, just a swift exchange for a worry-free experience.

For further assistance or inquiries, please contact Wanish customer support through the retailer's platform or visit the official Wanish website.

