Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > OMOTON /
- > OMOTON Bluetooth Wireless Backlit Keyboard FR-Layout User Manual

OMOTON FR-Layout

OMOTON Bluetooth Wireless Backlit Keyboard FR-Layout User Manual

Model: FR-Layout

Introduction

This manual provides detailed instructions for the OMOTON Bluetooth Wireless Backlit Keyboard (FR-Layout). Designed for versatility and ease of use, this keyboard offers multi-system compatibility, a comfortable typing experience with large, silent keys, and adjustable backlighting. Please read this manual thoroughly to ensure proper setup and operation of your device.

PRODUCT OVERVIEW

The OMOTON Bluetooth keyboard features a compact design with an integrated phone stand, making it suitable for various mobile setups. Its keys are designed for comfort and efficiency.





Image: OMOTON Bluetooth Wireless Backlit Keyboard with integrated phone stand.

Key Features

- Large Keycap Design: Keys are 12% larger than standard, improving typing accuracy and comfort.
- Silent Scissor-Type Key Structure: Provides a quiet and responsive typing experience with a lifespan of 3 million keystrokes.
- **7-Color Adjustable Backlight:** Customize your typing environment with 7 backlight colors and 3 brightness levels.
- Multimedia Shortcut Keys: 12 dedicated shortcut keys for quick access to functions.
- Ultra-Thin and Portable: Lightweight and compact for easy transport.

Rétro-éclairage 7 couleurs réglable

3 niveaux de luminosité

















Image: Comparison illustrating the OMOTON keyboard's larger keycap design for enhanced usability.




Image: Detailed view of the silent scissor-type key mechanism, highlighting its construction.



Image: The OMOTON keyboard being stored in a bag, emphasizing its ultra-thin and portable design.

SETUP

Charging the Keyboard

Before first use, fully charge the keyboard. Connect the provided Type-C charging cable to the keyboard's charging port and a USB power source. The charging indicator light will show the charging status.

- Charging Time: Approximately 2-3 hours.
- Working Hours (backlight off): Up to 200 hours.
- Working Hours (backlight on): 3-5 hours.

Structure silencieuse de type ciseaux



Image: The OMOTON keyboard connected to a power source for charging, showing estimated charging and working times.

Bluetooth Pairing

Follow these steps to connect your keyboard via Bluetooth:

- 1. Turn on the keyboard using the power switch located on the top right.
- 2. Press the 'Connect' button (usually near the power switch) to enter pairing mode. The Bluetooth indicator light will flash.
- 3. On your device (tablet, smartphone, PC), go to Bluetooth settings and enable Bluetooth.
- 4. Search for available devices. The keyboard will appear as 'OMOTON Keyboard' or similar.
- 5. Select the keyboard to pair. Your device may prompt you to enter a code displayed on the screen, then press Enter on the keyboard.
- 6. Once paired, the Bluetooth indicator light will stop flashing.

System Compatibility and Switching

The keyboard is compatible with iOS, Android, and Windows operating systems. To optimize key functions for your specific device, switch the keyboard mode:

• For iOS devices: Press Fn + A

• For Android devices: Press Fn + D

• For Windows devices: Press Fn + S



Image: Visual guide for switching keyboard modes between iOS, Android, and Windows using Fn key combinations.



Image: The OMOTON keyboard demonstrating wide compatibility with iOS, Android, and Windows devices.

OPERATING INSTRUCTIONS

Backlight Control

The keyboard features an adjustable backlight for typing in low-light conditions.

1. Press the **lightbulb icon key** once to turn on the backlight.

- 2. Press the **lightbulb icon key** a second time to activate breathing light mode.
- 3. Press the lightbulb icon key a third time to turn off the backlight.

To change backlight colors (7 available colors) when the backlight is on, pressFn + lightbulb icon key.

To adjust backlight brightness (3 levels), press **Fn** + **Up Arrow** (increase) or **Fn** + **Down Arrow** (decrease).




Image: The OMOTON keyboard showcasing its 7-color adjustable backlight feature.



Image: A diagram illustrating the steps to operate and adjust the keyboard's backlight settings.

Multimedia Shortcut Keys

The top row of keys (F1-F12) provides quick access to multimedia and system functions. These functions are typically accessed by pressing the **Fn** key simultaneously with the desired function key.

• Fn + F1: Home

• Fn + F2: Search

• Fn + F3: Select All

• Fn + F4: Copy

• Fn + F5: Paste

• Fn + F6: Cut

• Fn + F7: Previous Track

• Fn + F8: Play/Pause

• Fn + F9: Next Track

• Fn + F10: Mute

• Fn + F11: Volume Down

• Fn + F12: Volume Up

CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your OMOTON keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution. Avoid harsh chemicals, abrasives, or excessive moisture.
- Storage: Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- Handling: Avoid dropping the keyboard or exposing it to strong impacts. Do not place heavy objects on it.
- **Liquid Exposure:** Prevent liquids from entering the keyboard. In case of accidental spills, immediately power off the keyboard and allow it to dry completely before reuse.

TROUBLESHOOTING

If you encounter issues with your keyboard, refer to the following common problems and solutions:

- · Keyboard not connecting via Bluetooth:
 - Ensure the keyboard is charged and powered on.
 - Make sure Bluetooth is enabled on your device.
 - Press the 'Connect' button on the keyboard to enter pairing mode.
 - Forget the keyboard from your device's Bluetooth settings and attempt to re-pair.
 - Restart both the keyboard and your device.
- · Keys not responding or incorrect characters:
 - Verify that the keyboard is set to the correct operating system mode (Fn+A for iOS, Fn+D for Android, Fn+S for Windows).
 - Check your device's language and keyboard layout settings to ensure they match the FR-Layout.
 - Ensure the keyboard is fully charged.

• Backlight not working:

- Press the lightbulb icon key to cycle through backlight modes (on, breathing, off).
- Ensure the keyboard has sufficient battery charge.

• Battery life shorter than expected:

- Using the backlight continuously will significantly reduce battery life. Turn off the backlight when not needed.
- Ensure the keyboard is fully charged before use.

TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	OMOTON
Item Model Number	FR-Layout
Color	Black
Keyboard Description	Multifunctional
Power Source Type	Battery Powered
Connector Type	Bluetooth
Hand Orientation	Ambidextrous
Device Compatibility	Laptop, PC, Smartphone, Tablet
Special Features	Portable, Rechargeable, Backlit
Material	Plastic
Recommended Uses	Daily Use
Connectivity Technology	Bluetooth
ASIN	B0DFWKHBPK
Date First Available	February 24, 2025

Grand design du capuchon de touche 12% Plus grand G G OMOTON Autres F G H C V B N

Image: Technical drawing showing the dimensions of the OMOTON Bluetooth Keyboard.

Autres

WARRANTY AND SUPPORT

OMOTON

Manufacturer Warranty

This OMOTON product comes with a 1-year manufacturer's warranty from the date of purchase. Please retain your proof of purchase for warranty claims.

Customer Support

For further assistance, technical support, or warranty inquiries, please refer to the contact information provided with your product packaging or visit the official OMOTON website.

Related Documents - FR-Layout



OMOTON KB505 Wireless Keyboard User Manual

User manual for the OMOTON KB505 Wireless Keyboard, detailing technical specifications, product overview, LED indicators, hot keys, pairing instructions, backlight usage, power saving, troubleshooting, and safety precautions.

OMOTON KB515 Wireless Keyboard User Manual User manual for the OMOTON KB515 wireless keyboard, detailing specifications, features, pairing instructions, troubleshooting, and safety precautions.
OMOTON KB508 Wireless Keyboard User Manual User manual for the OMOTON KB508 Wireless Keyboard, detailing specifications, pairing steps, power saving mode, keys and functions, LED indicators, charging instructions, and troubleshooting.
OMOTON KB515 Wireless Keyboard User Manual and Specifications Comprehensive guide for the OMOTON KB515 wireless keyboard, covering setup, pairing, features, troubleshooting, and safety precautions for Mac and other compatible systems.
OMOTON WK006 Wireless Keyboard User Manual User manual for the OMOTON WK006 Wireless Keyboard, detailing specifications, package contents, product overview, operation methods, power management, and troubleshooting.
OMOTON KB166 Wireless Keyboard User Manual User manual for the OMOTON KB166 Wireless Keyboard, detailing specifications, package contents, setup instructions, multimedia functions, power saving, charging, and safety precautions.