

TecTake 405334

tectake Swivel Dining Chair

Model: 405334

INTRODUCTION

Thank you for choosing the tectake Swivel Dining Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read these instructions carefully before use and retain them for future reference.

This elegant swivel armchair features a fine velvet cover, designed for comfort and style in your dining room or living area.

SAFETY INSTRUCTIONS

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the chair on a soft, clean surface to prevent scratches.
- Tighten all screws and bolts securely. Periodically check and re-tighten fasteners to ensure stability.
- Do not stand on the chair or use it as a step stool.
- Do not exceed the maximum weight recommendation of 120 kg (approximately 264 lbs).
- Keep children away from small parts during assembly.
- Avoid exposing the chair to direct sunlight or extreme temperatures to prevent material degradation.
- Use only mild cleaning agents and avoid abrasive materials that could damage the velvet upholstery.

PACKAGE CONTENTS

Please verify that all components listed below are included in your package:

- 1 x Chair Seat (Velvet Upholstered)
- 1 x Swivel Base Mechanism
- 4 x Chair Legs (Black Powder-Coated Steel)
- 1 x Hardware Pack (Screws, Washers, Allen Key)
- 4 x Adjustable Foot Pads

SETUP AND ASSEMBLY

Follow these steps to assemble your tectake Swivel Dining Chair:

1. Step 1: Prepare the Components

Unpack all components and lay them out on a soft, clean surface to prevent damage. Identify the chair seat, swivel base, legs, and hardware pack.



Image: Front view of the fully assembled tectake Swivel Dining Chair, showcasing its grey velvet upholstery and black metal legs.

2. Step 2: Attach the Swivel Mechanism to the Seat

Carefully place the chair seat upside down. Align the swivel base mechanism with the pre-drilled holes on the underside of the seat. Secure it using the provided screws and washers from the hardware pack. Ensure the mechanism is centered and firmly attached.



Image: Close-up view of the underside of the chair seat, showing the circular swivel mechanism attached to the base.

3. **Step 3: Attach the Legs to the Swivel Base**

Attach each of the four chair legs to the designated points on the swivel base. Use the remaining screws and the Allen key provided. Tighten each screw firmly, but do not overtighten. The legs should splay outwards slightly for stability.



Image: Detail of the black metal chair legs, showing the square profile and the adjustable foot pads at the bottom.

4. Step 4: Install Adjustable Foot Pads

Screw the adjustable foot pads into the bottom of each leg. These pads help protect your floor and allow for minor leveling adjustments on uneven surfaces.

5. Step 5: Final Check

Once all components are assembled, gently turn the chair upright. Test its stability by applying light pressure. Ensure all connections are secure. If the chair wobbles, adjust the foot pads until it is stable.

OPERATING INSTRUCTIONS

The tectake Swivel Dining Chair is designed for comfortable seating and ease of movement.

- **Swivel Function:** The chair seat is equipped with a 360-degree swivel mechanism, allowing you to rotate freely without moving the base. This is ideal for dynamic environments or easy conversation.
- **Seating:** Sit centrally on the chair to distribute weight evenly and ensure stability.



Image: The tectake Swivel Dining Chair positioned in a modern living space next to a large window, demonstrating its aesthetic appeal and functional design.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your chair:

- **Velvet Upholstery:**
 - Regularly vacuum the velvet fabric using a soft brush attachment to remove dust and debris.
 - For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain and damage the pile.
 - For deeper cleaning, use a mild, water-free solvent or dry-cleaning product specifically designed for velvet. Test on an inconspicuous area first.
 - Avoid using harsh chemicals, bleach, or abrasive cleaners.
- **Metal Legs:** Wipe the metal legs with a soft, damp cloth. Dry immediately to prevent water spots or rust.
- **General:** Periodically check all screws and bolts and re-tighten them as necessary to maintain structural integrity.




Image: A detailed close-up of the grey velvet fabric, showing its soft texture and subtle sheen.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Chair wobbles	Uneven floor or loose connections.	Adjust the foot pads on the bottom of the legs. Check and tighten all screws and bolts.
Swivel mechanism is stiff	Dust accumulation or lack of lubrication.	Clean around the swivel mechanism. Apply a small amount of silicone-based lubricant if necessary (avoid oil-based lubricants on fabric).
Fabric appears flattened or matted	Prolonged pressure or natural wear.	Gently brush the velvet pile with a soft brush in the direction of the nap. Light steaming can also help restore the pile.

SPECIFICATIONS

Feature	Detail
Brand	TecTake
Model Number	405334
Color	Grey
Material	Wood, Polyester, Polyurethane, Powder-coated Steel
Product Dimensions (L x W x H)	58 x 58 x 82 cm (22.8 x 22.8 x 32.3 inches)
Item Weight	7.3 kg (16.1 lbs)
Maximum Weight Recommendation	120 kg (264 lbs)
Style	Scandinavian
Back Style	Soft backrest

WARRANTY AND SUPPORT


Your tectake Swivel Dining Chair is covered by a **30-day return policy** from the date of purchase. This policy covers manufacturing defects and issues arising from normal use.

For warranty claims, missing parts, or technical support, please contact the seller directly:

Seller: tectake nederland

Please have your purchase details and model number (405334) ready when contacting support to expedite the process.

For more information, you may visit the seller's page on Amazon:[tectake nederland Seller Page](#)



[pdf] Parts List

405333 405334 405335 2024 10 29 V2 DELL mail@tectake co uk Ansprechpartner tectake GmbH Tauberweg 41 97999 Igersheim Telefon 49 7931 991 920 de E Mail sie2b8ca7d e18d 5731 a803 cb73df8191dde2b8ca7d cb73df8191ddd otto files e2b8ca7d cb73df8191dd |||

C240924014-V2 - 1- ATENCIN - 2- PARTS LIST/STCKLISTE/PARTS LIST/LISTA DE PIEZAS/LISTA DEI PEZZI L Warning Tight all the screws to 60 first then tight to 100 . Warnung Whrend der Montage alle Schrauben zuerst 60 anziehen, dann zu 100 . Attention Atencin Serrez toutes les vis 60 ... lang:it score:22 filesize: 2.24 M page_count: 7 document date: 2024-10-29