

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [DunRock](#) /

› [DunRock Pop In-Ear Bluetooth 5.2 Earbuds User Manual](#)

DunRock DRPB

DunRock Pop In-Ear Bluetooth 5.2 Earbuds User Manual

Model: DRPB

INTRODUCTION

Thank you for choosing the DunRock Pop In-Ear Bluetooth 5.2 Earbuds. This manual provides essential information on how to set up, operate, and maintain your earbuds to ensure optimal performance and longevity. Please read this manual carefully before use.

WHAT'S IN THE BOX

- 2x In-Ear Earbuds
- 1x Charging Case (320 mAh)
- 1x USB-C Charging Cable
- 3x Pairs of Silicone Ear Tips (S/M/L)
- 1x User Manual



Ideali per lo sport

Le DunRock Pop si adattano in modo sicuro e comodo con i cuscinetti in silicone e sono protette IPX4 da sudore e schizzi d'acqua – il tuo compagno perfetto per l'allenamento.

Image: Contents of the DunRock Pop Earbuds package, including earbuds, charging case, USB-C cable, and ear tips.

PRODUCT OVERVIEW

The DunRock Pop earbuds are designed for an immersive audio experience with advanced features:

- **Hybrid Active Noise Cancellation (ANC):** Reduces ambient noise for focused listening.
- **Transparency Mode:** Allows you to hear your surroundings without removing the earbuds.
- **6 ENC Microphones:** Ensures clear voice calls by reducing background noise.
- **Smart Touch Controls:** Manage music, calls, and ANC modes directly from the earbuds.
- **DunRock App:** Customize sound, controls, and ANC levels via the dedicated mobile application.
- **IPX4 Water Resistance:** Protects against sweat and light splashes, suitable for workouts.




Image: Illustration highlighting the ANC and ENC noise-cancelling capabilities of the DunRock Pop earbuds.




Image: Visual guide to the smart touch controls on the DunRock Pop earbuds, including play/pause, skip, volume, call management, and voice assistant.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

- Place the earbuds into the charging case.

- Connect the USB-C charging cable to the charging port on the case and to a power source.
- The indicator light on the case will show charging status. Once fully charged, the light will change or turn off.

A full charge provides up to 8 hours of playback for the earbuds, with the charging case extending total playtime to 32 hours.




Image: The DunRock Pop earbuds in their charging case, illustrating the USB-C charging port and the total 32-hour playtime.

2. Pairing with Your Device

1. Open the charging case. The earbuds will automatically enter pairing mode (indicator lights will flash).
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "DunRock Pop" in the list of available Bluetooth devices and select it to connect.
4. Once connected, a voice prompt will confirm successful pairing.

3. Installing the DunRock App

For full customization and advanced features, download the DunRock app from the App Store (iOS) or Google Play Store (Android).

- Search for "DunRock" in your device's app store.
- Download and install the app.
- Open the app and follow the on-screen instructions to connect your DunRock Pop earbuds.



Image: The DunRock app interface displayed on a smartphone, showing options for bass, equalizer, ANC, transparency mode, and battery percentages.

4. Choosing the Right Ear Tips

Select the ear tips that provide the best seal and comfort for your ears. A proper fit is crucial for optimal sound quality and effective noise cancellation.

- Try different sizes (S, M, L) to find the most comfortable and secure fit.
- Gently insert the earbuds into your ear canal and twist slightly to ensure a snug seal.

32 Hours Playtime

Quick Charge 10MIN = 2H
24 Hours Charging Case
8 Hours earphones



Image: DunRock Pop earbuds displayed with a selection of different sized silicone ear tips.

OPERATING THE EARBUDS

Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging.

Touch Controls

The DunRock Pop earbuds feature intuitive touch controls. Specific functions can be customized via the DunRock app.

Action	Function
--------	----------

Action	Function
Single Tap (Left/Right)	Play/Pause music, Answer/End call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (Left/Right)	Activate Voice Assistant
Long Press (Left/Right)	Switch ANC Modes (ANC On / Transparency / ANC Off)
Long Press (during call)	Reject Call

ANC and Transparency Modes

Cycle through the noise control modes by long-pressing the touch area on either earbud:

- **Active Noise Cancellation (ANC):** Reduces external noise for an immersive listening experience.
- **Transparency Mode:** Allows ambient sounds to pass through, keeping you aware of your surroundings.
- **Normal Mode:** No active noise cancellation or transparency.

Making Calls

The 6 built-in ENC microphones ensure clear communication during calls, even in noisy environments.

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Long press on either earbud.

MAINTENANCE

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with water and mild soap if necessary. Ensure they are completely dry before reattaching.
- Use a cotton swab or a small, soft brush to gently clean the speaker mesh and charging contacts.


Storage

- When not in use, always store the earbuds in their charging case to protect them and keep them charged.
- Store the device in a cool, dry place, away from extreme temperatures and direct sunlight.

Water Resistance

The DunRock Pop earbuds are IPX4 rated, meaning they are resistant to splashes of water and sweat. They are not waterproof and should not be submerged in water.

- Avoid exposing the earbuds to heavy rain or submerging them in water.
- If they get wet, wipe them dry immediately with a soft cloth before placing them back in the charging case.



Hybrid ANC & Modalità Trasparenza

Elimina i rumori ambientali fastidiosi con la tecnologia Hybrid Active Noise Cancelling oppure attiva la Modalità Trasparenza per sentire chiaramente voci e ambiente circostante.

Image: DunRock Pop earbuds shown with water splashes, highlighting their IPX4 dust and water resistance certification.

TROUBLESHOOTING

No Sound or Intermittent Connection

- Ensure both earbuds are charged.
- Check that Bluetooth is enabled on your device and the earbuds are connected.
- Move closer to your device to avoid interference.
- Try unpairing and re-pairing the earbuds with your device.
- Restart your device.

Earbuds Not Charging

- Ensure the charging cable is securely connected to both the case and the power source.
- Check the charging contacts on the earbuds and inside the case for any debris or obstruction. Clean if necessary.
- Try a different USB-C cable or power adapter.

ANC Not Working Effectively

- Ensure the ear tips provide a good seal in your ear canal. Try different sizes.
- Confirm that ANC mode is activated via touch control or the DunRock app.

Touch Controls Unresponsive

- Ensure your fingers are clean and dry.
- Try restarting the earbuds by placing them in the case and closing the lid, then reopening.
- Check the DunRock app for any custom control settings that might affect responsiveness.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Name	Pop
Model Number	DRPB
Connectivity Technology	Wireless (Bluetooth 5.2)
Earbud Type	In-Ear
Noise Control	Hybrid Active Noise Cancellation, Transparency Mode
Microphones	6 (ENC for clear calls)
Battery Life (Earbuds)	Up to 8 hours
Total Battery Life (with Case)	Up to 32 hours
Charging Port	USB-C
Control Method	Touch, App
Water Resistance Rating	IPX4 (Splash-resistant)
Earbud Weight	Approx. 4.4g per earbud
Compatible Devices	Tablets, Mobile Phones, Laptops

WARRANTY AND SUPPORT

Warranty Information

DunRock products are covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included in your package or visit the official DunRock website for detailed warranty terms and conditions.

Customer Support

If you encounter any issues or have questions regarding your DunRock Pop earbuds, please contact our customer support team. Contact information can be found on the DunRock website or in the warranty documentation.