DOMICON MK-25

DOMICON MK-25 47-Inch Gaming Desk User Manual

Model: MK-25

Important Safety Instructions

WARNING: Always ensure that the desk is properly assembled and stable before use. Do not overload the desk or the drawers with heavy items. Be cautious when using the integrated power outlets and keep them dry and away from any liquids. Always follow the manufacturer's instructions for proper use and maintenance. Failure to follow these instructions may result in injury or damage to the product.

Product Overview

The DOMICON MK-25 Gaming Desk is designed to provide a functional and ergonomic workspace for gaming, office, or study needs. It features integrated LED lighting, a charging station with power outlets and USB ports, three storage drawers, and an adjustable monitor stand.




Figure 1: Fully assembled DOMICON MK-25 Gaming Desk with LED lights and accessories.

Key Features:

- **RGB LED Ambiance:** Remote-controlled LED lights with 12 scene modes and over 6,000 colors for customizable lighting.
- **Adjustable Monitor Stand:** Fits two displays and offers three height settings (7.3", 5.5", 5") for ergonomic viewing.
- **Integrated Charging Station:** Features 4 AC outlets and 2 USB-A ports for convenient device charging.
- **Ample Storage:** Includes 3 reinforced fabric drawers, 2 shelves, and a side fabric organizer.
- **Durable Construction:** 47" L x 19.7" W carbon-textured top (scratch/heat-resistant), eco-friendly thickened boards, and a reinforced metal frame.

Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer service.

- Desk Top Panel
- Desk Legs (Metal Frame Components)
- Monitor Stand Components
- 3 Fabric Drawers
- Side Organizer
- LED Light Strip with Remote Control
- Charging Station (4 AC outlets, 2 USB-A ports)
- Assembly Hardware (Screws, Allen Wrench, etc.)
- Instruction Manual

Setup Guide

Follow these steps carefully to assemble your DOMICON MK-25 Gaming Desk. It is recommended to have a second person assist with assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Main Frame:** Attach the desk legs to the main desk panel using the provided screws and tools. Ensure all connections are secure.
3. **Install Drawers:** Insert the three fabric drawers into their designated slots. The metal supports should be properly aligned.
4. **Attach Side Organizer:** Secure the side fabric organizer to the desk frame as indicated in the detailed diagram.
5. **Mount Monitor Stand:** Assemble the monitor stand components and attach it to the desk top. Ensure it is stable.
6. **Install Charging Station:** Secure the charging station to the designated area on the desk. Plug the power cord into a wall outlet.
7. **Apply LED Light Strip:** Adhere the LED light strip to the underside of the monitor stand or desk edge as desired. Connect it to the power source.
8. **Final Check:** Verify that all screws are tightened and the desk is stable before placing any items on it.




Figure 2: Assembly detail showing monitor stand height options (7.3", 5.5", 5").




Figure 3: Reinforced support points for drawer stability.

Operating Instructions

LED Lights Operation:

The integrated LED light strip is controlled via a remote control.

- **Power On/Off:** Press the **Power** button on the remote to turn the lights on or off.
- **Change Colors:** Use the color palette buttons to select from over 6,000 static colors.
- **Scene Modes:** Select from 12 pre-programmed scene modes for dynamic lighting effects.
- **Adjust Brightness:** Use the **Brightness +/-** buttons to increase or decrease the light intensity.
- **Music Mode:** Activate music mode for lights to react to sound.
- **Timing Mode:** Set a timer for the lights to automatically turn off.



Figure 4: LED light strip and remote control for ambiance customization.

Charging Station Usage:

The desk includes a built-in charging station with 4 AC outlets and 2 USB-A ports.

- **AC Outlets:** Plug in laptops, monitors, or other AC-powered devices.
- **USB-A Ports:** Connect USB cables to charge smartphones, tablets, or other USB-powered accessories.
- **Safety:** Ensure devices are compatible with the power output. Avoid spilling liquids near the outlets.




Figure 5: Integrated charging station for convenient power access.

Adjustable Monitor Stand:

The monitor stand can be adjusted to three different heights to suit your ergonomic needs.

- **Height Settings:** Choose between 7.3 inches, 5.5 inches, or 5 inches from the desk surface.
- **Adjustment:** Refer to the assembly instructions for specific steps on how to reconfigure the stand's height. This typically involves repositioning support rods.

Maintenance

Proper care will extend the life and appearance of your DOMICON Gaming Desk.

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Immediately wipe up any spills to prevent damage to the carbon-textured top and electrical components.
- **Drawer Care:** The fabric drawers can be spot cleaned with a mild detergent. Ensure they are completely dry before

reinserting.

- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight and secure.

Troubleshooting

If you encounter any issues with your desk, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
LED lights not turning on.	Power connection loose; remote battery dead; light strip damaged.	Check power connections. Replace remote battery. Contact customer service if strip is damaged.
Charging station not working.	Desk power cord unplugged; device not properly connected; power surge.	Ensure desk is plugged into a live outlet. Reconnect devices. Check household circuit breaker.
Desk feels wobbly.	Loose screws; uneven floor.	Tighten all assembly screws. Use shims under desk feet if floor is uneven.
Drawers not sliding smoothly.	Overloaded; misaligned.	Reduce weight in drawers. Ensure drawers are inserted correctly and not obstructed.

Specifications




Figure 6: Detailed product dimensions.

Brand: DOMICON

Model Number: MK-25

Color: White

Product Dimensions (L x W x H): 119.4 cm x 50 cm x 74.9 cm (47 inches x 19.7 inches x 29.5 inches)

Item Weight: 13.6 kg (29.98 lbs)

Material: Engineered Wood, Alloy Steel (Base)

Special Features: Built-In USB Outlet, Monitor Stand, Scratch Resistant, LED Lights

Desk Design: Computer Desk

Shape: Oblong

Finish Type: Painted

Warranty and Customer Support

DOMICON provides professional customer service. If you have any quality problems with the desk, are missing parts, or require assistance with assembly or operation, please do not hesitate to contact us.
Please refer to your purchase documentation or the DOMICON official website for specific warranty details and contact information.

© 2024 DOMICON. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question