

[Manuals.plus](#) /

› [WantJoin](#) /

› WantJoin Commercial Electric Crepe Maker 16 Inch 110V Non-Stick 1700W Electric Crepe Machine Adjustable Temperature Control 403 Stainless Steel Cooking Base 1700W User Manual

WantJoin WZ-BJL410

WantJoin Commercial Electric Crepe Maker User Manual

Model: WZ-BJL410

Brand: WantJoin

1. INTRODUCTION

Thank you for choosing the WantJoin Commercial Electric Crepe Maker. This appliance is designed for efficient and versatile cooking, ideal for preparing crepes, pancakes, fried eggs, and more. This manual provides essential information for safe operation, proper maintenance, and troubleshooting to ensure optimal performance and longevity of your crepe maker. Please read all instructions carefully before first use.



Figure 1: WantJoin Commercial Electric Crepe Maker with various food items and accessories.

This image displays the WantJoin Commercial Electric Crepe Maker, showcasing its 16-inch non-stick cooking surface. Various prepared foods such as crepes, a fried egg, and sausages are shown on the cooking plate, demonstrating the appliance's versatility. Included wooden spreading and turning tools are also visible, highlighting the complete set for crepe making. Below the main unit, a plate of crepes with fruit topping further illustrates potential culinary creations.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical hazards, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.

- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

3. PRODUCT OVERVIEW

The WantJoin Commercial Electric Crepe Maker features a robust design with a 16-inch cooking surface and a powerful 1700W heating element for rapid and uniform heating.

- **16-inch Cooking Plate:** Large diameter for efficient cooking, designed with multiple heat dissipation holes for extended service life.
- **High-Quality Construction:** Shell made of 403 stainless steel, cooking surface of thickened cast iron with PTFE non-stick coating for high temperature resistance and easy cleaning.
- **Adjustable Temperature Control:** Knob with temperature range of 122°F - 572°F (50°C - 300°C).
- **Indicator Lights:** Red light indicates preheating, green light indicates target temperature reached.
- **Unique Handle Design:** Outer handrail for enhanced safety, protecting against burns and offering a secure grip for easy transfer and storage.

HUMANILITY DESIGN

Enjoy every bites in any moments

Food Grade

403SS
Rustproofing

Non- Stick

PTFE
Coating

Safety Handle

Hold for Make
a Round Crepe

360°

Figure 2: Humanized Design Features.

This image highlights the

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question