

[Manuals.plus](#) /

› [Bewinner](#) /

› Bewinner RC Fishing Bait Boat User Manual - Model Bewinneruznyrxgf5h

Bewinner Bewinneruznyrxgf5h

Bewinner RC Fishing Bait Boat User Manual

Model: Bewinneruznyrxgf5h

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, setup, and maintenance of your Bewinner RC Fishing Bait Boat. This remote-controlled bait boat is designed to assist in fishing activities by delivering bait to desired locations with precision and ease. It features dual motors, a 2kg bait capacity, GPS functionality, and a 500m control range.



Image 1.1: Top-down view of the Bewinner RC Fishing Bait Boat, showing the bait compartments and antenna.

2. SAFETY INFORMATION

- Always operate the bait boat in open water, away from swimmers, other boats, and obstacles.
- Do not operate the boat in strong currents or extreme weather conditions. The boat is designed to withstand winds and waves of 7-8 levels.

- Ensure the battery is fully charged before each use to prevent loss of control due to low power.
- Keep the remote control dry and away from water.
- Supervise children when they are operating or near the bait boat.
- Avoid direct contact with propellers when the boat is powered on.
- Do not modify the boat or its components, as this may void the warranty and compromise safety.



Image 2.1: The bait boat navigating through water, demonstrating its stability in moderate conditions.

3. PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- 1 x Fishing Boat
- 1 x Remote Controller
- 1 x Battery
- 1 x Charging Cable

- 2 x Propeller (Spare)
- 1 x Screw
- 1 x Antenna
- 1 x Instruction Manual (This document)



Image 3.1: The complete package contents, including the bait boat, remote control, battery, charging cable, and other accessories.

4. SETUP

4.1. Charging the Boat Battery

1. Locate the charging port on the fishing boat.
2. Connect the provided charging cable to the boat's charging port and to a suitable USB power adapter (not included).
3. The battery indicator lights on the boat will show charging status. A full charge provides up to 4 hours of operation.
4. Disconnect the charger once fully charged.



Image 4.1: Illustration of the boat's battery indicator and charging process, showing a 7.4V battery.

4.2. Installing Remote Control Batteries

1. Open the battery compartment on the back of the remote controller.
2. Insert 2 AAA batteries (not included), ensuring correct polarity.
3. Close the battery compartment securely.

4.3. Attaching the Antenna

Screw the provided antenna onto the designated port on the fishing boat. Ensure it is securely fastened for optimal signal reception.

4.4. Initial Power On

After installing batteries and attaching the antenna, turn on the power switch on both the fishing boat and the remote controller. The devices will automatically pair.

5. OPERATING INSTRUCTIONS

5.1. Basic Control

- Use the joysticks on the remote control to steer the boat forward, backward, left, and right.
- The dual motors provide enhanced power and maneuverability.
- Maintain a control distance within 500 meters for optimal performance.



Image 5.1: The bait boat demonstrating high-speed sailing capabilities.

5.2. Bait Delivery System

1. Open the three independently controlled bait compartments on the boat.
2. Load up to 2kg of bait into the compartments.
3. Navigate the boat to your desired bait drop location.
4. Use the corresponding buttons on the remote control to open each bait compartment individually, releasing the bait. The anti-dehooking design helps prevent line tangles.

Newly upgraded 3 bait tanks 3 independently controllable bait tanks



Image 5.2: Close-up view of the three bait tanks, showing bait being released.

5.3. Night Lights Operation

The boat is equipped with front and rear two-color searchlights. These lights can be activated via the remote control to aid in steering and enhance visibility during nighttime operation, allowing for accurate bait placement in low-light conditions.

Powerful night light

Helps to set the point at a long distance

Front and rear night lights increase the range of vision and ensure accurate bait placement when used at night.




Image 5.3: The bait boat operating at night, illuminated by its powerful front light.

5.4. GPS Functionality

The integrated BDS+GPS dual satellite module allows for advanced navigation:

- **Positioning Points:** You can set multiple positioning points (up to 40) using the remote control.
- **Automatic Navigation:** The boat can automatically navigate between these preset positioning points. Refer to the remote control's LCD display for specific instructions on setting and activating navigation routes.
- **Auto Return:** The boat features an automatic return function. This will activate if the battery level becomes critically low or if the signal connection with the remote control is interrupted.

BDS+GPS DUAL SATELLITE MODULE

**MULTIPLE POSITIONING POINTS CAN BE SET,
AUTOMATIC NAVIGATION BETWEEN POSITIONING POINTS**



Image 5.4: Graphic illustrating the BDS+GPS dual satellite module for precise positioning and navigation.

6. MAINTENANCE

- **Cleaning:** After each use, wipe down the boat with a soft, damp cloth to remove any water, dirt, or debris. Ensure all compartments are dry before storage.
- **Propellers:** Regularly check the propellers for any fishing lines, weeds, or other obstructions. Clean them carefully to maintain optimal performance.
- **Battery Care:** Store the boat battery in a cool, dry place. For long-term storage, it is recommended to charge the battery to about 50% capacity.
- **Remote Control:** Keep the remote control clean and dry. Remove batteries if storing for extended periods to prevent leakage.
- **Storage:** Store the bait boat and remote control in a safe, dry environment, away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--|--|---|
| Boat does not power on. | Boat battery is depleted or not connected. | Charge the boat battery fully. Ensure the battery is properly installed and connected. |
| Remote control does not power on. | AAA batteries are depleted or incorrectly installed. | Replace AAA batteries, ensuring correct polarity. |
| Boat does not respond to remote control. | Out of range, signal interference, or pairing issue. | Bring the boat closer to the remote control (within 500m). Ensure both devices are powered on and paired. Avoid areas with strong electromagnetic interference. |
| Bait compartments do not open. | Mechanism jammed or remote command not received. | Check for any obstructions in the bait compartments. Ensure the boat is within control range and the remote button is pressed firmly. |
| Boat returns automatically unexpectedly. | Low battery or signal loss. | This is a safety feature. Recharge the boat battery. Ensure the boat remains within the 500m control range. |

8. SPECIFICATIONS

| | |
|---|--------------------------|
| Brand | Bewinner |
| Model | Bewinneruznyrxgf5h |
| Fishing Boat Battery Type | Built-in Rechargeable |
| Fishing Boat Battery Capacity | 12000mAh |
| Remote Control Battery Type | AAA batteries (Excluded) |
| Number of Remote Control Batteries | 2 pcs |
| Control Distance | 500m / 1640.4ft |
| Load Capacity | 2kg |
| Parcel Dimensions | 52.2 x 32.3 x 27.2 cm |
| Item Weight | 2.76 kg |

MAIN FUNTION



**GPS
Positoning**



**Automatic
Return**



**40 Positioning
Points**



**Three Bait
Tanks**



**Controllable
LED Light**



**Fixed-Speed
Driving**



**500M Control
Distance**



**LCD Remote
Control**



**Anti-Storm
Level 7-8**



**Low Battery
Alarm**



Dual Motors



**Lost Signal
Return**

Image 8.1: Overview of the main functions and features of the bait boat, including GPS positioning, auto return, 40 positioning points, three bait tanks, controllable LED light, fixed-speed driving, 500m control distance, LCD remote control, anti-storm level 7-8, low battery alarm, dual motors, and lost signal return.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Bewinner website. Keep your proof of purchase for any warranty claims.