

[Manuals.plus](#) /

› [URintells Cuising](#) /

› URintells Cuising Espresso Machine EM5220-US Instruction Manual

## URintells Cuising EM5220-US

# URintells Cuising Espresso Machine EM5220-US Instruction Manual

MODEL: EM5220-US

## Introduction

---

This manual provides detailed instructions for the safe and efficient operation of your URintells Cuising EM5220-US Espresso Machine. Please read all instructions carefully before first use and retain this manual for future reference. This semi-automatic espresso machine features a 20-bar pressure system, 1350W fast heating, a colorful touchscreen control panel, and a powerful milk frothing system, allowing you to prepare a variety of coffee beverages.

## Product Components

---

Your URintells Cuising Espresso Machine comes with the following components:

- 1 x Espresso Machine with Milk Frother
- 1 x 40.58 oz Removable Water Tank
- 1 x 51mm One Cup Filter
- 1 x 51mm Two Cup Filter
- 1 x Portafilter
- 1 x Tamper with Spoon
- 1 x Instruction Manual

# 40oz Removable Water Tank

Espresso Machine Weight: 7.7 Pounds



Figure 1: Exploded view of the URintells Cusing Espresso Machine and its included accessories. This image shows the main unit, water tank, portafilter, single and double shot filters, and the coffee spoon with tamper.

## Setup

1. **Unpacking:** Carefully remove all components from the packaging. Remove any protective films or stickers.
2. **Cleaning:** Before first use, wash the water tank, portafilter, and filters with warm soapy water. Rinse thoroughly and dry. Wipe the exterior of the machine with a damp cloth.
3. **Water Tank Installation:**  
Remove the 40.58 oz (1.2 Liters) removable water tank from the back of the machine. Fill it with fresh, cold water up to the MAX line. Ensure the tank is securely placed back into position. Only water should be added to the water tank.

# Colorful Touch Screen Control Panel



One Touch Brewing



Easy To Operate



Stylish & Modern



Figure 2: A hand demonstrates removing the transparent water tank from the rear of the espresso machine for filling or cleaning.

#### 4. Initial System Flush (Before First Use):

To release air from the water pump and ensure smooth coffee flow:

- Fill the water tank and turn on the power button.
- Press the ON/OFF button on the touchscreen.
- Once preheated, turn the Steam/Hot Water knob on the side to the "ON" position.
- Observe water flowing out of the steam wand.
- Turn the knob to the "OFF" position once water flows consistently.



Figure 3: Visual guide for the initial system flush, showing steps to fill the water tank, power on, open the steam knob, and observe water flow.

## Operating Instructions

### 1. Power On & Pre-heating:

Plug the machine into a 120V AC outlet. Press the Power button on the touchscreen. The machine will begin pre-heating (approx. 30 seconds). The indicator lights on the touchscreen will stop blinking when pre-heating is complete.




Figure 4: Close-up of the colorful touchscreen control panel, showing options for Espresso, Americano, Espresso Cool, and Steam.

## 2. Preparing Espresso/Americano:

- Select the desired filter (1-cup or 2-cup) and place it into the portafilter.
- Add ground coffee to the filter. Use the included tamper to press the coffee evenly.
- Attach the portafilter to the machine by aligning it and turning it firmly to the right until locked.
- Place your cup(s) on the drip tray beneath the portafilter. The drip tray is detachable to accommodate taller cups.
- Select "Espresso" for a single shot or "Espresso x 2" for a double shot on the touchscreen. For Americano, select "Americano".
- The machine will automatically brew and stop.



Figure 5: A visual guide illustrating the process of filling the water tank, adding and tamping coffee grounds, and selecting a brewing mode on the touchscreen for espresso or Americano.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the use of the touchscreen espresso maker to prepare Americano and Cold Brew beverages. This video highlights the ease of use and various drink options.

## 3. Making Iced Coffee ("Espresso Cool"):

- Add ice cubes or iced water directly into the water tank.
- Touch the "Espresso Cool" button on the touchscreen. The machine will brew without heating the water.
- *Tip:* To avoid waiting for the machine to cool down, brew iced coffee before hot coffee or frothing milk.

# Make Ice Espresso In Seconds

Room temperature water with ice cubes  
Or Ice water be filled in the water tank are available  
Espresso with ice will faster



Figure 6: A hand interacts with the touchscreen, selecting the 'Espresso Cool' option to prepare iced coffee. The image shows the machine brewing into a glass with ice.

## 4. Milk Frothing:

- Ensure the machine is preheated.
- Fill a milk frothing pitcher with cold milk.
- Press the "Steam" button on the touchscreen. The light will blink while heating and become solid when ready.
- Turn the Steam/Hot Water knob to the "ON" position to release any residual water from the steam wand. Turn it off.
- Immerse the steam wand into the milk and turn the Steam/Hot Water knob to "ON" again.
- Adjust the steam wand position to create desired microfoam. Turn the knob to "OFF" when done.

# 1350W Fast Heating System

Preheat in minutes and make a barista-quality coffee




Figure 7: A detailed view of the powerful milk steam wand in action, frothing milk in a metal pitcher. Insets show features like strong steam, 360° flexibility, and a detachable nozzle.

## Maintenance

### 1. Cleaning the Drip Tray:

The drip tray is removable for easy cleaning. Simply slide it out, empty any accumulated liquid, and wash with warm soapy water. It is recommended to clean the drip tray regularly.



Figure 8: The detachable drip tray is shown, highlighting its ease of removal for cleaning and its adjustability for different cup heights.

### 2. Cleaning the Water Tank:

The 40.58 oz (1.2 Liters) transparent water tank is fully removable for easy filling and cleaning. Wash it with warm soapy water and rinse thoroughly.

### 3. **Cleaning the Steam Wand:**

After each use, wipe the steam wand with a damp cloth to remove any milk residue. The steam nozzle is detachable for deeper cleaning.

### 4. **Descaling:**

Regular descaling is recommended to maintain machine performance and extend its lifespan. Refer to the "DESCALE" indicator on the touchscreen and consult the full instruction manual for detailed descaling procedures.

## Troubleshooting

---

If you encounter issues, please refer to the following common solutions:

- **No water coming out:** Ensure the water tank is filled and correctly positioned. Perform an initial system flush if it's the first use or if the machine hasn't been used for a long time.
- **No steam coming out:** Ensure the machine is preheated and the steam function is selected. Check if the steam wand is blocked.
- **Coffee not brewing:** Verify the portafilter is securely locked in place and the water tank is filled.
- **Water leftover in tank:** It is normal for some water to remain in the tank after use, as the machine is inspected and tested before shipment.

## Specifications

---

Feature	Detail
Brand	URintells Cuising
Model Name	EM5220-US
Pressure System	20 Bar Professional Pump
Power	1350 W
Water Tank Capacity	40.58 oz (1.2 Liters)
Interface	Colorful Touchscreen Control Panel
Special Features	Milk Steam Wand, Espresso Cool (Iced Coffee), Americano, Auto Shut-Off, Cup Warmer, Removable Water Tank
Product Dimensions	12.48"D x 6.14"W x 12.59"H
Item Weight	7.71 pounds

## Warranty & Support

---

For detailed warranty information, please refer to the warranty card included in your product packaging. For any questions, additional instructional videos, or support, please visit the official URintells Cuising store on Amazon or contact customer service.

You can find more instructional videos by visiting the [URintells Cuising Store](#).

