

## KEMEI KM-2292

# KEMEI Professional Hair Clippers KM-2292 User Manual

Model: KM-2292

## 1. INTRODUCTION

---

Thank you for choosing the KEMEI Professional Hair Clippers Model KM-2292. This device is designed for precise hair cutting and grooming, offering cordless convenience and a powerful motor. Please read this manual thoroughly before first use to ensure safe and effective operation and to maximize the lifespan of your product.

## 2. SAFETY INSTRUCTIONS

---

- Always unplug the hair clipper when not in use, before cleaning, or before performing any maintenance.
- Do not use the hair clipper on infants or children without proper supervision and care.
- Keep the hair clipper away from water sources. Do not use it near bathtubs, showers, basins, or other vessels containing water. If the appliance falls into water, do not reach for it. Unplug immediately.
- Always follow the recommended cleaning and maintenance procedures outlined in this manual.
- Use the hair clipper only for its intended purpose as described in this manual.
- Do not operate the appliance with a damaged cord or plug, or if it malfunctions or has been dropped or damaged. Contact customer support for assistance.
- Keep the cord away from heated surfaces.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Ensure the voltage specified on the appliance matches the local power supply before charging.


## 3. PACKAGE CONTENTS

---

Please check the package for the following items:

- KEMEI Professional Hair Clipper (Model KM-2292)

- Cutting Combs (3mm, 4.5mm, 6mm, 9mm, 12mm)
- USB Charging Cable
- Cleaning Brush
- User Manual



## Cutterhead Adjustment

Precise length control, Easy adjust levels of cutting tools

Image: KEMEI KM-2292 Hair Clipper with its included accessories, including various guide combs, USB charging cable, and cleaning brush.

### 4. PRODUCT OVERVIEW

---

The KEMEI KM-2292 is a professional-grade hair clipper designed for precision and ease of use. Key features include:

- **Sharp Blade:** DLC (Diamond-Like Carbon) coating process for sharp cutting without jamming, ensuring durability.
- **Cutterhead Adjustment:** A precise lever for easy adjustment of cutting lengths.
- **Powerful Motor:** Strong power with low noise, designed for smooth and efficient cutting without pulling hair.
- **High Capacity Battery & USB Charging:** Cordless operation with a 2500mAh battery, offering multiple charging options (computer, plug, car charger, mobile power).
- **Smart Light Indicator:** An LED indicator to monitor battery level and charging status.

- **Hanging Ring Design:** Features a magnetic pull ring for convenient storage, allowing it to be hung on a wall for cleanliness and space-saving.



Image: Close-up view of the KEMEI KM-2292 clipper's sharp blade, highlighting its DLC coating for smooth cutting.




Image: The KEMEI KM-2292 clipper demonstrating the adjustable cutterhead lever for precise length control.




Image: An illustrative view of the KEMEI KM-2292's powerful motor, emphasizing its smooth and quiet operation.

## 5. SETUP

1. **Unpack:** Carefully remove all components from the packaging.

2. **Inspect:** Check the clipper and accessories for any signs of damage. Do not use if damaged.
3. **Initial Charge:** Before first use, fully charge the clipper. Refer to the 'Charging' section for details.

## 6. CHARGING

---

The KEMEI KM-2292 features a high-capacity 2500mAh Lithium-Ion battery for cordless operation. It supports USB charging for convenience.

- **Charging Time:** Approximately 3.5 hours for a full charge.
- **Usage Time:** Up to 180 minutes of continuous use on a full charge.
- **Charging Process:** Connect the USB charging cable to the clipper's charging port and plug the other end into a compatible USB power source (e.g., computer, wall adapter, car charger, power bank).
- **Indicator Light:** The smart light indicator will show the charging status. It typically illuminates during charging and may change color or turn off when fully charged.



Image: The KEMEI KM-2292 clipper connected via USB, illustrating various charging methods and its 2500mAh battery capacity.

## 7. OPERATING INSTRUCTIONS

---

### 7.1. Blade Adjustment

The clipper features an adjustable lever on the side to change the cutting length of the blade itself, independent of guide combs. This allows for fine-tuning and blending.

- Move the lever up for a shorter cut (closer to the skin).
- Move the lever down for a longer cut.

# High Capacity Battery & USB Charging

Multiple charging options for easy charging



Computer




plug



Car  
Charger



Mobile  
Power



**3.5** Hours  
Charging Time

**180** Minutes  
Usage Time

**2500mAh**  
Battery capacity

Image: A hand demonstrating the adjustment of the blade lever on the KEMEI KM-2292 hair clipper.

## 7.2. Attaching Guide Combs

To achieve desired hair lengths, attach one of the provided guide combs:

1. Select the desired comb size (3mm, 4.5mm, 6mm, 9mm, or 12mm).
2. Align the comb with the clipper blade and push it firmly until it clicks into place.
3. To remove, gently pull the comb away from the blade.



Image: The KEMEI KM-2292 hair clipper shown alongside its six different limit combs, ranging from 1.5mm to 12mm.

### 7.3. Hair Cutting

1. Ensure hair is clean and dry.
2. Attach the desired guide comb.
3. Turn on the clipper using the power switch.
4. Start cutting from the bottom of the head, moving upwards against the direction of hair growth.
5. Use smooth, even strokes.
6. Regularly clear hair from the comb and blade during use to maintain cutting efficiency.

## 8. MAINTENANCE AND CLEANING

---

Proper maintenance ensures the longevity and performance of your hair clipper.

1. **After Each Use:** Turn off and unplug the clipper. Use the provided cleaning brush to remove loose hairs from the blades and comb.
2. **Oiling Blades:** Periodically apply a few drops of clipper oil (not included, but recommended) to the blades to keep them lubricated and sharp. Turn the clipper on for a few seconds to distribute the oil.
3. **Storage:** Store the clipper in a dry place, away from moisture and direct sunlight. The hanging ring design allows for convenient storage.



Image: The KEMEI KM-2292 hair clipper demonstrating its hanging ring design for clean and space-saving storage.

## 9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is depleted.	Charge the clipper fully.
Clipper pulls hair or cuts poorly.	Blades are dull, dirty, or not oiled. Hair buildup in blades.	Clean and oil the blades. Ensure blades are free of hair. Consider professional sharpening if blades are dull.
Clipper makes unusual noise.	Blades are not properly aligned or lubricated.	Clean and oil the blades. Check blade alignment. If problem persists, contact customer support.
Battery indicator not working.	Faulty indicator or battery issue.	Ensure proper charging. If issue persists, contact customer support.

## 10. SPECIFICATIONS

---

- **Model:** KM-2292
- **Product Dimensions:** 7.68 x 2.17 x 1.57 inches
- **Item Weight:** 1.27 Pounds (577 Grams)
- **Power Source:** Battery Powered
- **Battery Type:** 1 Lithium Ion battery (included)
- **Blade Material:** Metal (DLC Coated)
- **Manufacturer:** KEMEI

## 11. WARRANTY AND SUPPORT

---

KEMEI products are manufactured to high-quality standards. For warranty information, please refer to the documentation included with your purchase or contact KEMEI customer support. If you encounter any issues or have questions regarding your KM-2292 hair clipper, please reach out to our customer service team for assistance.