

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ANPABO](#) /

› [ANPABO 24V Ride on Toy \(Blue Shark\) Instruction Manual](#)

ANPABO B0DFXX77WT

ANPABO 24V Ride on Toy (Blue Shark) Instruction Manual

Model: B0DFXX77WT

1. IMPORTANT SAFETY INFORMATION

Please read this manual thoroughly before assembly and operation. Keep these instructions for future reference. Failure to follow these safety guidelines may result in serious injury or death.

- **Adult Supervision Required:** This product is intended for children aged 3-12 years. Constant adult supervision is mandatory during operation.
- **Weight Limit:** Do not exceed the maximum weight capacity of 110 lbs (50 kg).
- **Seat Belts:** Always ensure both independent seat belts are securely fastened before operation.
- **Operating Environment:** Use on flat, dry surfaces. Avoid slopes, uneven terrain, public roads, and areas near water, pools, or other hazards.
- **Protective Gear:** Children should wear appropriate safety gear, such as helmets, during operation.
- **Battery Safety:** Only use the provided charger and battery. Do not modify the electrical system.
- **Assembly:** Adult assembly is required. Ensure all parts are correctly installed and secured before first use.

2. PRODUCT OVERVIEW

The ANPABO 24V Ride on Toy (Blue Shark) is designed for children aged 3-12, offering an engaging driving experience with advanced features. This 2-seater vehicle is powered by four 200W motors, reaching speeds up to 5.1 MPH. It features durable EVA rubber tires and a 4-wheel suspension system for a smooth ride on various terrains.

Key Features:

- **Powerful Performance:** Four 24V 200W motors for speeds up to 5.1 MPH.
- **All-Terrain Capability:** Equipped with sturdy EVA rubber tires and shock absorbers for various surfaces.
- **Spacious 2-Seater Design:** 21-inch wide seat with 15.7 inches of legroom, suitable for one child aged 3-12 or two children aged 3-6, with independent seat belts.

- **Safety Features:** Low center of gravity design and parental remote control for added security.
- **Entertainment:** Built-in music, Bluetooth connectivity, and bright front lights.



Image: The ANPABO 24V Ride on Toy in Blue Shark design, showcasing its robust build and dual seating.

3. PACKAGE CONTENTS

The package includes the main car body and various components required for assembly. Please ensure all parts are present before beginning assembly.

- Car body
- Wheels (4x)
- Steering wheel
- Seats (2x)
- Fenders (front and rear)
- Shock absorbers
- Axles and connecting rods
- Motors (4x)
- Battery and charger
- Remote control
- Assembly hardware (screws, washers, nuts)
- Instruction Manual



Image: All components of the ANPABO 24V Ride on Toy laid out, including the main body, wheels, steering wheel, seats, and various hardware.

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. Refer to the installation video for visual guidance.

Assembly Video:

Video: Official ANPABO Shark Car Installation Video, providing step-by-step visual instructions for assembling the ride-on toy.

Step-by-Step Guide:

1. **Unboxing:** Carefully open the packaging and remove all components. Place the main car body upside down on a stable surface.
2. **Connect Front Axle:** Attach the front axle assembly to the underside of the car body using the provided screws and nuts. Ensure all connections are secure.
3. **Install Rear Shock Absorbers:** Secure the rear shock absorbers to the designated points on the car body and rear axle.
4. **Attach Motors:** Connect the drive motors to the rear wheel hubs. Ensure electrical connections are properly plugged in.
5. **Install Wheels:** Slide the wheels onto the axles. Secure them with washers and nuts, then attach the hubcaps.
6. **Connect Steering Column:** Insert the steering column into its slot and connect the electrical wires for the steering wheel functions. Secure the steering wheel.
7. **Attach Fenders:** Secure the front and rear fenders to the car body using the provided screws.
8. **Connect Battery:** Locate the battery compartment (usually under the seat). Connect the battery terminals (red to red, black to black).
9. **Install Seats:** Place the seats into position and secure them with screws. Ensure seat belts are accessible.

5. BATTERY CHARGING AND CARE

The ANPABO 24V Ride on Toy is powered by a 24V 7AH battery, providing 1 to 2 hours of playtime. Proper charging and care are essential for battery longevity.

Charging Instructions:

- **Initial Charge:** Before first use, charge the battery for 8-12 hours. Do not exceed 18 hours.
- **Regular Charging:** After each use, recharge the battery for 8-12 hours.
- **Charging Port:** The charging port is typically located under the seat or on the dashboard. Plug the charger into the port and then into a standard wall outlet.
- **Indicator:** The charger may have an indicator light (e.g., red for charging, green for fully charged).
- **Avoid Overcharging:** Do not leave the battery charging for extended periods beyond the recommended time.

Battery Care:

- Store the vehicle and battery in a cool, dry place when not in use.
- If storing for an extended period, charge the battery once a month to maintain its health.
- Do not allow the battery to completely drain before recharging.

6. OPERATING INSTRUCTIONS

Familiarize yourself with the controls and operating modes for a safe and enjoyable experience.

Dashboard Controls:



Image: The multi-function simulation dashboard with labels for the start button, light switch, high/low speed switch, forward/back joystick, foot pedal accelerator, and music panel.

- **Start Button:** Press to power on/off the vehicle.
- **High/Low Speed Switch:** Select desired speed mode.
- **Forward/Back Joystick:** Controls the driving direction (Forward, Park, Reverse).
- **Foot Pedal Accelerator:** Press to accelerate in manual mode.
- **Light Switch:** Activates the front lights.
- **Music Panel:** Features built-in music and Bluetooth connectivity for external audio.

Driving Modes:

- **Manual Mode:** For older children (or those with adult supervision) to operate using the steering wheel and foot pedal.
- **Parental Remote Control Mode:** Allows parents to control the vehicle's direction and speed, and to stop it urgently. Ideal for younger children or for safety monitoring.

Driving Tips:

- Always start in low speed until the child is comfortable with the controls.
- Ensure the driving surface is clear of obstacles.
- The EVA tires provide superior grip on various terrains, including grass, rocky roads, and dirt tracks.



MANUAL & REMOTE MODE



Image: Illustration of the ANPABO 24V Ride on Toy demonstrating both parental remote control mode and manual driving mode.

FUN JOURNEY WITH MUSIC



Image: A child enjoying the music function and bright front lights of the ANPABO 24V Ride on Toy.

7. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your ANPABO 24V Ride on Toy.

- **Cleaning:** Wipe the vehicle with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners. Do not spray water directly onto electrical components.
- **Battery:** Follow the charging and care instructions in Section 5.
- **Tires:** Regularly inspect EVA tires for wear and tear. Ensure they are free from debris that could affect performance.
- **Connections:** Periodically check all screws, nuts, and electrical connections to ensure they are tight and secure.
- **Storage:** Store the vehicle indoors in a dry, protected area away from extreme temperatures.

8. TROUBLESHOOTING

If you encounter issues with your ride-on toy, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vehicle does not move	Low battery; Loose battery connection; Blown fuse	Charge battery; Check battery terminals; Check/replace fuse
Vehicle moves slowly	Low battery; Overloaded vehicle; Operating on rough terrain	Charge battery; Reduce weight; Move to smoother surface
Remote control not working	Remote batteries dead; Remote not paired	Replace remote batteries; Re-pair remote (refer to remote manual)
No sound from music panel	Volume too low; Bluetooth not connected	Adjust volume; Connect via Bluetooth

If problems persist, please contact ANPABO customer support.

9. SPECIFICATIONS

Feature	Detail
Model	B0DFXX77WT (Blue Shark)
Product Dimensions	48 x 35.4 x 24.4 inches
Item Weight	62 pounds
Battery	24V 7AH
Motors	4 x 200W
Maximum Speed	5.1 MPH
Recommended Age	3 years and up (3-12 for single rider, 3-6 for two riders)
Maximum Weight Capacity	110 lbs
Tires	EVA Rubber
Suspension	4-Wheeler Suspension

10. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please contact ANPABO customer service. Keep your purchase receipt and product model number handy for faster service.

You can visit the official ANPABO store for more information: [ANPABO Store](#)

