

Soozier A62-043V00BK

Soozier 8' x 6' Soccer Rebounder Net

INSTRUCTION MANUAL - MODEL A62-043V00BK

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembling and using this product. Failure to follow these instructions may result in injury or damage to the product.

- Ensure all components are present and undamaged before assembly.
- Assemble the rebounder on a flat, stable surface.
- Always use the provided ground stakes to secure the rebounder, especially in windy conditions.
- Keep children and pets away from the assembly area.
- Regularly inspect the net and frame for wear, tear, or damage. Discontinue use if any damage is found.
- This product is intended for recreational use. Do not use for purposes other than its intended design.
- Adult supervision is recommended for younger users.

2. PACKAGE CONTENTS

Verify that all parts listed below are included in your package. If any parts are missing or damaged, please contact customer support.



Image: The product package as received, indicating one package containing all components.

Components List:

- Main Frame Tubes (various lengths and shapes)
- Rebounder Net
- Bungee Cords for Net Attachment
- Adjustable Angle Mechanism Components
- Ground Stakes (4 pieces)
- Assembly Hardware (bolts, nuts, washers)

3. SETUP INSTRUCTIONS

Follow these steps carefully to assemble your Soozier Soccer Rebounder Net.

Step 1: Assemble the Base Frame

Connect the horizontal and vertical base frame tubes using the provided hardware. Ensure all connections are secure but do not fully tighten bolts until the entire frame is assembled.

Step 2: Attach the Upright Supports

Attach the upright support tubes to the base frame. These tubes will hold the main net frame.

Step 3: Assemble the Main Net Frame

Connect the top and side tubes to form the rectangular frame for the net. Secure this frame to the upright supports.



Image: The assembled rebounder net, illustrating its 8 feet width and 6 feet height, suitable for various training needs.

Step 4: Attach the Rebounder Net

Carefully unroll the rebounder net. Using the bungee cords, attach the net to the assembled frame. Start from one corner and work your way around, ensuring even tension. The bungee cords should pass through the net loops and around the frame tubes.



Image: A close-up view demonstrating how the net is secured to the frame using a bungee cord and plastic stopper.

Step 5: Install Adjustable Angle Mechanism

Connect the adjustable angle components to the rear support legs and the main net frame. This mechanism allows you to change the angle of the net. Refer to the detailed image for proper alignment.



Image: A detailed view of the adjustable angle mechanism, showing the pin and holes for setting different rebound angles.

Step 6: Final Tightening and Securing

Once the entire frame and net are assembled, go back and fully tighten all bolts and connections. Place the rebounder in your desired location and use the four ground stakes to anchor it firmly into the ground. Insert the stakes through the designated holes in the base frame.




Image: Four metal ground stakes, used to secure the rebounder net to the ground for stability.

4. OPERATING INSTRUCTIONS

The Soozier Soccer Rebounder Net is designed for various training exercises, including shooting, pitching, and fielding practice.

Adjusting the Angle:

The rebounder features 5 adjustable angles. To change the angle, locate the adjustment pins on the rear support legs. Pull out the pins, adjust the net to the desired angle, and reinsert the pins securely into the corresponding holes. A steeper angle will result in a higher rebound, while a shallower angle will produce a lower, more direct return.



Image: The rebounder net shown with an arrow indicating the five adjustable angles, allowing for varied training scenarios.

Using the Rebounder:

- Place the rebounder on a level surface, ensuring it is securely staked to the ground.
- Stand a safe distance from the net. The distance will vary based on the force of your kick/throw and the desired rebound.
- Kick or throw the ball towards the net. The net will return the ball, allowing for repetitive practice.
- Experiment with different angles and distances to simulate various game situations.



Image: Two children practicing soccer with the Soozier rebounder net, demonstrating its use for individual training.

5. MAINTENANCE

Proper maintenance will extend the life of your Soozier Soccer Rebounder Net.

- **Cleaning:** Wipe down the frame with a damp cloth as needed. Avoid harsh chemicals that could damage the finish.
- **Net Care:** The net is designed for all-weather use. However, for prolonged life, consider storing it indoors during extreme weather conditions or when not in use for extended periods.
- **Inspection:** Periodically check all bolts, nuts, and connections to ensure they remain tight. Inspect the net for any tears, fraying, or damage to the bungee cords. Replace damaged parts immediately.
- **Storage:** If disassembling for storage, keep all components and hardware together in a dry place.



Image: A composite image highlighting the powder-coated steel frame for durability, a stable base design, and the all-weather net material.

6. TROUBLESHOOTING

If you encounter issues with your rebounder net, refer to the following common problems and solutions.

- **Difficulty during Assembly:**
Ensure you are following the instructions step-by-step. Verify that all parts are correctly identified and oriented as shown in the diagrams. Some parts may appear similar but have subtle differences. Do not force connections. If parts do not fit, double-check the part numbers against the manual.
- **Missing or Damaged Parts:**
Before assembly, carefully check the package contents against the provided list. If any parts are missing or damaged upon arrival, do not proceed with assembly. Contact Soozier customer support immediately for assistance and replacement parts.
- **Net Tension Issues:**
If the net is too loose or too tight, re-adjust the bungee cords. Ensure they are evenly distributed and provide consistent tension across the entire net surface.
- **Rebounder Instability:**
Ensure the rebounder is placed on a flat, level surface. Always use the provided ground stakes to secure the base firmly into the ground. Check all frame connections to ensure they are fully tightened.

7. SPECIFICATIONS

Feature	Specification
Product Dimensions	240 x 90 x 0.1 cm (94.5" L x 35.4" W x 70.9" H)
Item Model Number	A62-043V00BK
Colour	Black
Frame Material	Alloy Steel (Powder Coated)
Net Material	All-weather net
Adjustable Angles	5 positions
UPC	673986292952




Image: A diagram showing the overall dimensions of the assembled rebounder net: 94.5 inches (240 cm) in length, 35.4

inches (90 cm) in width, and 70.9 inches (180 cm) in height.

8. WARRANTY AND SUPPORT




Soozier products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Soozier website.

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Soozier customer support. Have your model number (A62-043V00BK) and purchase details ready when contacting support.

Contact Information:

Please visit the Soozier official website or refer to your purchase documentation for the most current customer support contact details.

Related Documents - A62-043V00BK

	<p>Soozier A62-043V00 Soccer Rebounder Net Assembly Instructions</p> <p>Comprehensive assembly guide for the Soozier A62-043V00 soccer rebounder net. Includes detailed steps, parts list, safety warnings, and contact information for Aosom LLC and Aosom Canada. Bilingual (English/French) instructions.</p>
	<p>Soozier A91-176 Home Gym Assembly and User Manual</p> <p>This manual provides detailed assembly instructions, safety guidelines, and usage tips for the Soozier A91-176 Home Gym. Learn how to set up, operate, and maintain your fitness equipment for effective home workouts.</p>
	<p>Soozier A70-060 Mini Pool Table Assembly Instructions</p> <p>Step-by-step assembly guide for the Soozier A70-060 mini pool table. Includes safety warnings, parts list, and assembly procedures for this recreational game.</p>

	<p>Soozier A91-176 Home Gym User Manual and Assembly Guide</p> <p>Comprehensive user manual for the Soozier A91-176 Home Gym, covering assembly, safety, usage, and maintenance instructions for domestic fitness.</p>
	<p>Soozier Stepper Assembly Instructions and Exercise Monitor Manual</p> <p>Comprehensive guide for assembling and using the Soozier stepper, including safety information, specifications, and replacement parts.</p>
	<p>Soozier A90-302 Motorized Elliptical Trainer Assembly & Instruction Manual</p> <p>Comprehensive assembly and instruction manual for the Soozier A90-302 Motorized Elliptical Trainer, covering safety precautions, parts list, operating instructions, product care, and troubleshooting.</p>