

[Manuals.plus](#) /

> [Simsky](#) /

> Simsky Video Baby Monitor YM300 User Manual: Dual 4MP Camera, 7-inch Touch Screen

Simsky YM300

Simsky Video Baby Monitor YM300 User Manual

Model: YM300

1. INTRODUCTION

The Simsky Video Baby Monitor YM300 is designed to provide comprehensive monitoring of your child. This system includes a 7-inch UHD touch screen monitor and a dual 4MP camera with 6X zoom capabilities. It offers advanced features such as AI tracking, cry detection, and secure local storage, ensuring peace of mind for parents.



2. PRODUCT COMPONENTS

Verify that all items listed below are included in your package:

- Monitor x1
- Camera x1
- USB Cable x2
- Reset Tool x1
- Power Adapter x2
- Mounting Bracket x1
- Drywall Anchors x3
- Screws x3
- Wall Mount x1



Image 2.1: All components included in the Simsky Video Baby Monitor YM300 package.

3. SETUP INSTRUCTIONS

3.1 Powering On and Initial Pairing

1. Connect the power adapters to the monitor and camera, then plug them into a power outlet.
2. The monitor and camera will automatically attempt to pair. If pairing is unsuccessful, refer to the troubleshooting section.
3. Once paired, the camera's video feed will appear on the monitor screen.

3.2 Camera Placement and Mounting

Position the camera in a location that provides a clear view of the monitoring area. Ensure it is out of reach of children. The included wall mount and hardware can be used for secure installation.

1. Choose a suitable wall location, ensuring it is at least 3 feet (1 meter) away from the crib or play area.
2. Use the mounting bracket as a template to mark drill holes.
3. Drill pilot holes and insert drywall anchors if necessary.
4. Secure the mounting bracket to the wall using the provided screws.
5. Attach the camera to the mounting bracket.

3.3 Smartphone App Connection (Optional)

For remote access and additional features, download the Simsky app on your smartphone (Android or iOS).

1. Scan the QR code in the quick start guide or search for "Simsky" in your device's app store.
2. Follow the in-app instructions to create an account and add your camera device.
3. Ensure your smartphone is connected to a stable Wi-Fi network for optimal performance.



Image 3.1: The monitor offers both local viewing and remote access via a smartphone application.

4. OPERATING INSTRUCTIONS

4.1 Monitor Operation

The 7-inch touch screen monitor provides intuitive control over the camera and system settings.

- **Touch Interface:** Navigate menus, adjust settings, and control camera movement directly on the screen.
- **Live View:** Displays real-time video from the camera.
- **Volume Control:** Adjust the audio output from the camera.

- **Brightness:** Modify screen brightness for comfortable viewing.



Image 4.1: The 7-inch touch screen offers easy navigation and control.

4.2 Camera Control and Features

The dual 4MP camera offers advanced viewing capabilities:

- **Pan and Tilt:** Remotely adjust the camera's horizontal and vertical viewing angles to cover the entire room.
- **6X Optical-Quality Zoom:** Utilize the dual lenses for detailed close-ups without loss of clarity.
- **Night Vision:** Automatic infrared LEDs provide clear video monitoring in low-light or complete darkness.
- **Two-Way Talk:** Use the monitor or app to speak to your child through the camera's speaker.
- **Lullabies:** Play soothing sounds or lullabies directly from the camera.
- **Night Light:** The camera features an adjustable backlit night light to create a calming ambiance.

Dual 4MP Camera

See Clearer & Farther



Image 4.2: The dual 4MP camera provides 6x optical-quality zoom for detailed viewing.

4.3 Advanced AI Functions

The monitor integrates intelligent detection features for enhanced safety:

- **Smart AI Tracking:** The camera automatically adjusts its pan-tilt to keep your child in view.
- **Cry Detection:** Notifies you when your child cries, ensuring timely attention.
- **Face Covered Detection:** Alerts you if your child's face is obstructed, promoting safe breathing.
- **Danger Zone Detection & Virtual Fence:** Define specific areas to receive alerts if your child enters or exits them.

Smart Detection

Alerts you when needed



Image 4.3: Smart detection features provide alerts for various events.

5. DATA STORAGE AND SECURITY

The Simsky YM300 prioritizes your privacy and data security:

- **32GB Local Storage:** All recordings are stored locally on the included 32GB Micro SD card, ensuring data privacy. The system supports up to 256GB Micro SD cards.
- **24/7 Recording:** Continuous recording is available via the Simsky app.
- **AES 128-bit Encryption:** Data transmission is secured with AES 128-bit encryption and TLS protocols.

Face Covered Detection

Receive alerts if your baby's face is obstructed, ensuring safe breathing while they sleep.



Image 5.1: Data privacy and security are maintained through local storage and encryption.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your Simsky Video Baby Monitor.

- **Cleaning:** Use a soft, dry cloth to clean the monitor screen and camera lenses. Avoid abrasive cleaners or solvents.
- **Battery Care:** The monitor contains a Lithium Ion battery. To prolong battery life, avoid extreme temperatures and fully discharge and recharge periodically.
- **Software Updates:** Check the Simsky app regularly for firmware updates to ensure your device has the latest features and security enhancements.

7. TROUBLESHOOTING

If you encounter issues with your Simsky Video Baby Monitor, refer to the following common solutions:

Problem	Possible Cause	Solution
No image on monitor	Camera or monitor not powered on; Out of range; Pairing lost	Ensure both devices are plugged in and powered on. Move camera closer to monitor. Re-pair devices (refer to manual for specific steps).
Poor image quality	Low light; Dirty lens; Interference	Ensure adequate lighting or check night vision. Clean camera lens. Move devices away from other electronics.
No audio or poor audio	Volume too low; Microphone/speaker blocked; Out of range	Increase monitor volume. Ensure nothing is covering the camera's microphone or speaker. Move camera closer to monitor.
Monitor battery drains quickly	High screen brightness; Continuous use; Aging battery	Reduce screen brightness. Plug in monitor when not actively moving it. Contact support if battery life significantly degrades.

Problem	Possible Cause	Solution
App connectivity issues	Weak Wi-Fi signal; Incorrect app settings; Outdated app version	Ensure strong Wi-Fi signal. Verify app settings and camera connection. Update the Simsky app to the latest version.

8. SPECIFICATIONS

Feature	Detail
Model Number	YM300
Display Size	7 inches
Camera Resolution	Dual 4MP
Optical Zoom	6x
Connectivity	Wi-Fi, Wireless
Local Storage	32GB Micro SD (expandable up to 256GB)
Power Source	Battery Powered (Lithium Ion), AC Adapter
Control Method	App, Remote (Monitor)
Viewing Angle	360 Degrees (Pan/Tilt)
Security	AES 128-bit Encryption, TLS protocols
Special Features	Touch Screen, AI Tracking, Cry Detection, Face Covered Detection, Danger Zone Detection, Virtual Fence, Two-Way Talk, Lullabies, Night Light, T/H Sensor
UPC	632412969356

9. WARRANTY AND SUPPORT

For warranty information and technical support, please contact Simsky customer service. Details can

typically be found on the official Simsky website or within the product packaging.

You can also visit the [Simsky Store on Amazon](#) for additional product information and support resources.