

MoKo P840401427200

MoKo Keyboard Case for iPad Pro 13 Inch (M4, 2024) - Instruction Manual

Model: P840401427200

INTRODUCTION

Thank you for choosing the MoKo Keyboard Case for your iPad Pro 13 Inch (M4, 2024/2025). This manual provides detailed instructions on how to set up, operate, and maintain your new keyboard case to ensure optimal performance and protection for your device. Please read this manual thoroughly before use.

COMPATIBILITY

This keyboard case is specifically designed for the following models:

- NEW iPad Pro 13 Inch (M4) 2024 (Models: A2925, A2926, A3007)
- iPad Pro 13 Inch (M5) 2025 (Models: A3360, A3361, A3362)

Note: This case is **not** compatible with iPad Pro 12.9" (2022/2021/2020/2018), iPad Air 12.9" 2024, or any other iPad models. Please verify your iPad model number on the back of your device before use.



Multi-touch Trackpad

Transform the way you navigate your iPad using the large precision trackpad with multi-touch gesture support.

Image: Compatibility chart illustrating supported and unsupported iPad models for this keyboard case.

WHAT'S IN THE Box

Your package should contain the following items:

- 1 x MoKo iPad Pro 13 Inch Case
- 1 x Magnetic Wireless Keyboard
- 1 x User Manual

Note: Apple Pencil is not included.

SETUP

1. Installing Your iPad

1. Gently align your iPad Pro 13 Inch with the case.
2. Press the iPad firmly into the protective TPU back case until it is securely seated. Ensure all edges are properly covered.

2. Connecting the Keyboard (Bluetooth Pairing)

1. **Charge the Keyboard:** Ensure the keyboard is sufficiently charged. Connect the charging cable to the keyboard and a power source.
2. **Power On:** Push the power switch on the keyboard to the "ON" position. The power indicator light will illuminate for 3 seconds.
3. **Activate Pairing Mode:** Press the **Fn + C** keys simultaneously on the keyboard. The Bluetooth indicator light will start blinking, indicating the keyboard is in pairing mode.
4. **Enable Bluetooth on iPad:** On your iPad, go to **Settings > Bluetooth** and turn Bluetooth ON.
5. **Select Keyboard:** Your iPad will search for available devices. Select "Bluetooth Keyboard" (or similar name) from the list of devices.
6. **Confirm Connection:** Once connected, the Bluetooth indicator light on the keyboard will stop blinking. Your keyboard is now paired and ready for use.




Image: Steps for connecting the magnetic detachable keyboard via Bluetooth.

OPERATING INSTRUCTIONS

1. Using the Multi-Touch Trackpad

The integrated multi-touch trackpad allows for precise navigation and gesture control on your iPad, eliminating the

need for an external mouse. Common gestures include:

- **Single Finger Tap:** Left-click.
- **Two Finger Tap:** Right-click (context menu).
- **Two Finger Scroll:** Scroll up/down or left/right.
- **Pinch to Zoom:** Zoom in or out.
- **Three Finger Swipe Up:** Open App Switcher.
- **Three Finger Swipe Down:** Return to Home Screen.



Image: Demonstrating the use of the multi-touch trackpad for smooth navigation.

2. Adjusting Backlight Colors and Brightness

The keyboard features 7 different backlight colors and 3 adjustable brightness levels for comfortable typing in various lighting conditions.

- **Change Backlight Color:** Press the **RGB key** (often depicted with a lightbulb icon) to cycle through the 7 available colors.
- **Adjust Brightness:** Press the **Fn + RGB key** (or a dedicated brightness key) to cycle through the 3 brightness levels (low, medium, high, off).



Image: Visual representation of the 7-color backlight and brightness adjustment.

3. Utilizing Multi-Angle Stands

The case offers multiple stable viewing angles to enhance your experience whether you are typing, watching videos, browsing, or reading. The anti-slip grooves ensure your iPad remains secure in your chosen position.

- Adjust the iPad's position within the case to align with the desired groove for your preferred viewing angle.



Image: Illustration of the keyboard case supporting two stable stand modes for comfortable viewing.

4. Pencil Holder Functionality

A built-in slot is provided to securely hold your Apple Pencil, ensuring it is always accessible and protected. The design supports both Apple Pencil Pro (securely held, magnetically attached, wirelessly charged) and Apple Pencil (USB-C) (securely held, magnetically attached).



Image: Detail of the built-in pencil holder, designed to keep your Apple Pencil secure and ready.

5. Charging the Keyboard

To charge the keyboard, connect the provided USB-C charging cable to the keyboard's charging port and a suitable USB power adapter. The charging indicator light will show the charging status.

- **Charging Time:** Approximately 2 hours for non-backlit use, 3 hours for backlit use.
- **Working Time:** Up to 90 hours for non-backlit typing, up to 5 hours for backlit typing.



Image: Information on keyboard charging duration and operational battery life.

MAINTENANCE

To ensure the longevity and optimal performance of your MoKo Keyboard Case, follow these maintenance guidelines:

- **Cleaning the Case:** Wipe the exterior of the case with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Cleaning the Keyboard:** Use a soft, dry cloth to clean the keyboard surface. For dust between keys, use compressed air. Do not spray liquid directly onto the keyboard.
- **Storage:** When not in use for extended periods, store the keyboard case in a cool, dry place. Ensure the keyboard is turned off to conserve battery.
- **Avoid Extreme Conditions:** Do not expose the product to extreme temperatures, direct sunlight, or high humidity.



Image: Features of the case material and design, emphasizing durability and protection.

TROUBLESHOOTING

If you encounter any issues with your keyboard case, please refer to the following common solutions:

Problem	Solution

Problem	Solution
Keyboard not connecting via Bluetooth	<ul style="list-style-type: none"> • Ensure the keyboard is charged and powered on. • Make sure Bluetooth is enabled on your iPad. • Re-enter pairing mode (Fn + C) on the keyboard. • Forget the device on your iPad's Bluetooth settings and try pairing again. • Restart both your iPad and the keyboard.
Keys not responding	<ul style="list-style-type: none"> • Check if the keyboard is connected to your iPad. • Ensure the keyboard has sufficient battery. • Try restarting the keyboard and reconnecting.
Trackpad not working	<ul style="list-style-type: none"> • Ensure the keyboard is connected. • Check iPad settings for trackpad support (Settings > Accessibility > Touch > AssistiveTouch). • Restart the keyboard and iPad.
Backlight not working or changing	<ul style="list-style-type: none"> • Ensure the keyboard has sufficient battery. • Press the RGB key to cycle colors or Fn + RGB to adjust brightness.

SPECIFICATIONS

Feature	Detail
Product Dimensions	11.3 x 9.33 x 0.98 inches
Item Weight	1.98 pounds
Manufacturer	MoKo
Item Model Number	P840401427200
Compatible Devices	iPad Pro 13 inch 2024 Generation, iPad Pro 13 (M5) 2025 (Models: A3360, A3361, A3362)
Form Factor	Case with Keyboard
Shell Type	Hard
Color	Black
Keyboard Connectivity	Bluetooth
Backlight	7 Colors, 3 Brightness Levels

Feature	Detail
Trackpad	Multi-Touch Sensitive
Pencil Holder	Built-in, supports Apple Pencil Pro and Apple Pencil (USB-C)

WARRANTY AND SUPPORT

MoKo products are designed for durability and performance. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official MoKo website. Our customer service team is available to assist you with any questions or concerns regarding your product.



Image: MoKo customer service is available for support.