

[manuals.plus](#) /› [Anmytek](#) /› [Anmytek 63" Tall Bathroom Storage Cabinet User Manual](#)

Anmytek H0146

Anmytek 63" Tall Bathroom Storage Cabinet User Manual

Model: H0146

INTRODUCTION

Thank you for choosing the Anmytek 63" Tall Bathroom Storage Cabinet. This versatile and stylish cabinet is designed to provide ample storage space in various rooms, including bathrooms, living rooms, kitchens, and entryways. Featuring a distinctive rattan design, a convenient drawer, and adjustable shelves, it helps keep your space organized and tidy. This manual provides detailed instructions for assembly, usage, maintenance, and troubleshooting to ensure you get the most out of your new furniture.

IMPORTANT SAFETY INFORMATION

Please read and understand all safety warnings and instructions before assembly and use. Failure to follow these guidelines may result in injury or damage to the product.

- Use caution when assembling and ensure the cabinet is stable before use.
- Keep the cabinet away from heat sources and direct sunlight to prevent material degradation.
- Do not overload the shelves to prevent tipping. Distribute weight evenly.
- Always use the provided anti-tip device to secure the cabinet to a wall, especially in homes with children or pets.
- Do not allow children to climb on or play with the cabinet.
- Ensure all screws and fasteners are securely tightened before use and periodically check for looseness.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts and hardware are present. If any items are missing or damaged, please contact customer support.

- Cabinet Panels (Top, Bottom, Sides, Back, Shelves, Drawer components, Door panels)
- Hardware Pack (Screws, dowels, cam locks, hinges, drawer slides, knobs, anti-tip kit)

Product Size



* Due to some kind of reasons (shooting condition, lights, or screen display), please allow some color difference between the pictures displayed and the actual item.

Figure 1: Product Dimensions and Component Overview

ASSEMBLY INSTRUCTIONS

Before You Begin

- Choose a clean, flat, and spacious area for assembly.
- Gather necessary tools: Phillips head screwdriver, hammer (optional, for dowels), level.
- Identify all parts and hardware using the provided list and diagrams.

Step-by-Step Assembly

1. **Assemble the Base:** Attach the four solid wood legs to the bottom panel of the cabinet using the

specified screws. Ensure they are securely fastened and stable.

2. **Construct the Frame:** Connect the side panels to the bottom panel and then to the top panel using cam locks and dowels. Follow the pre-drilled holes carefully.
3. **Install Back Panel:** Slide or nail the back panel into the grooves or attach it to the rear of the cabinet frame.
4. **Assemble the Drawer:** Connect the drawer sides, front, and back panels. Install the drawer bottom. Attach the drawer slides to the drawer and the corresponding cabinet interior.
5. **Install Adjustable Shelves:** Insert shelf support pegs into the desired holes within the cabinet sections. Place the adjustable shelves onto the pegs.
6. **Attach Doors:** Secure the hinges to the cabinet doors and then attach the doors to the cabinet frame. Adjust hinges as needed to ensure proper alignment and smooth opening/closing.
7. **Attach Knobs:** Fasten the knobs to the drawer front and cabinet doors.
8. **Secure Anti-Tip Device:** Attach the anti-tip device to the top rear of the cabinet and then to a wall stud using appropriate wall anchors. This step is crucial for safety.



Figure 2: Adjustable Shelves Feature



Figure 3: Adjustable Shelf Peg Holes



Figure 4: Magnetic Door Catch

OPERATION AND USAGE

Storage Features

The Anmytek storage cabinet offers flexible storage solutions for various items:

- **Top and Bottom Door Cabinets:** Ideal for concealing items you prefer to keep out of sight, such as toiletries, cleaning supplies, or personal belongings. The rattan design adds a decorative touch.
- **Adjustable Shelves:** Both the top and bottom cabinet sections feature adjustable shelves, allowing you to customize the storage height to accommodate items of different sizes. Simply move the shelf support pegs to the desired level.
- **Open Storage Space:** The central open compartment is perfect for displaying decorative items, frequently accessed essentials, or small appliances.
- **Convenient Drawer:** A smooth-gliding drawer provides additional enclosed storage for smaller items like accessories, stationery, or personal care products.



Figure 5: Cabinet in Kitchen Use

Before

Messy and disorderly



After

Neat and orderly



Figure 6: Organization Before and After



Figure 7: Drawer Interior

MAINTENANCE AND CARE

To ensure the longevity and appearance of your Anmytek storage cabinet, follow these care guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Moisture Protection:** While suitable for bathrooms, avoid prolonged exposure to excessive moisture. Wipe up spills immediately.
- **Dusting:** Regularly dust the cabinet with a dry, soft cloth to prevent buildup.
- **Hardware Check:** Periodically check all screws, bolts, and connections to ensure they remain tight. Retighten if necessary.
- **Avoid Overloading:** Do not place excessively heavy items on shelves or in the drawer, as this can cause structural damage or instability.

TROUBLESHOOTING

If you encounter any issues with your cabinet, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Cabinet wobbles or is unstable.	Uneven floor; loose connections; anti-tip device not installed.	Ensure cabinet is on a level surface. Tighten all assembly screws. Install the anti-tip device securely to a wall stud.
Drawer sticks or does not slide smoothly.	Misaligned drawer slides; debris in tracks; overloaded drawer.	Check that drawer slides are correctly installed and aligned. Clear any debris from the tracks. Reduce the weight in the drawer.
Cabinet doors do not close properly or are misaligned.	Misaligned hinges; obstruction; magnetic catch not engaging.	Adjust the hinges using a screwdriver to align the doors. Remove any obstructions. Check if the magnetic catch is properly installed and aligned.
Missing parts during assembly.	Packaging error.	Review the package contents list. Contact Anmytek customer support with details of the missing parts.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Anmytek
Model Number	H0146
Color	Original Wood Color
Product Dimensions	11.84"D x 15.7"W x 62.99"H (30cm D x 40cm W x 160cm H)
Item Weight	46 Pounds (20.87 kg)
Material	Engineered Wood, Rattan

Feature	Detail
Mounting Type	Floor Mount (Freestanding)
Number of Shelves	2 (Adjustable)
Number of Compartments	3 (Top Cabinet, Open Space, Bottom Cabinet)
Assembly Required	Yes

WARRANTY AND SUPPORT

Anmytek stands behind the quality of its products. For specific warranty details, please refer to the product packaging or contact Anmytek customer support directly. If you have any questions regarding assembly, missing parts, or product functionality, please do not hesitate to reach out.

Customer Support:

- Visit the official Anmytek store on Amazon: [Anmytek Store](#)
- Refer to your purchase documentation for direct contact information.

© 2024 Anmytek. All rights reserved.