

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [KEMEI](#) /

› [KEMEI Professional Hair Clippers & Trimmers Kit \(Km-1071+2299\) Instruction Manual](#)

## KEMEI Km-1071+2299

# KEMEI Professional Hair Clippers & Trimmers Kit

Model: Km-1071+2299 - Instruction Manual

## 1. INTRODUCTION

Thank you for choosing the KEMEI Professional Hair Clippers & Trimmers Kit. This kit provides a versatile solution for hair cutting and detailing, designed for both professional and personal use. Please read this manual thoroughly before first use to ensure safe and effective operation and to maximize the lifespan of your devices.

## 2. SAFETY INFORMATION

To prevent injury or damage to the device, observe the following safety precautions:

- Always use the haircut cloak to protect against hair getting into eyes or mouth during use.
- Keep the devices away from heat sources and moisture, especially during charging.
- Do not immerse the devices in water or other liquids.
- Keep out of reach of children.
- Ensure the devices are fully charged before extended use to avoid power interruptions.
- Do not attempt to repair or disassemble the devices yourself. Contact qualified personnel for service.

## 3. PACKAGE CONTENTS

Your KEMEI Professional Hair Clippers & Trimmers Kit (Km-1071+2299) includes the following items:

- 1 x KEMEI Hair Clipper (Km-1071)
- 1 x KEMEI Hair Trimmer (Km-2299)
- 6 x Limit Combs for Clipper (3mm, 6mm, 10mm, 13mm, 16mm, 19mm)
- 3 x Limit Combs for Trimmer (1mm, 2mm, 3mm)
- 2 x USB Charging Cables
- 1 x Cleaning Brush
- 1 x Lubricating Oil
- 1 x Charging Base (for clipper)
- 1 x Travel/Storage Case

# 9 Limit Combs

1-19mm(0.04-0.75inch)

Multiple limit combs to choose from





Image: The KEMEI Hair Clippers and Trimmers Kit, showcasing both devices and the nine included limit combs for various cutting lengths.



Image: A detailed view of the KEMEI Hair Clippers and Trimmers Kit, displaying all components including the main clipper, trimmer, various guide combs, charging cables, and accessories.

## 4. PRODUCT FEATURES

This KEMEI kit is engineered with advanced features for a superior grooming experience:

- **Adjustable Blades & Limit Combs:** The main clipper features an adjusting lever for easy blade length modification. It comes with 6 limit combs (3mm, 6mm, 10mm, 13mm, 16mm, 19mm). The trimmer includes 3 additional limit combs (1mm, 2mm, 3mm) for precise detailing.
- **Powerful & Quiet Motor:** Both devices are equipped with a robust and durable motor, capable of cutting various hair types efficiently while maintaining low noise levels.
- **Large Capacity Battery:** The main clipper offers up to 240 minutes of use after a 180-minute charge. The trimmer provides 180 minutes of use from a 180-minute charge, ideal for travel.
- **Smart Light Indicator:** An intelligent light indicator on each device allows for easy monitoring of battery levels, signaling when recharging is needed.

## R-shaped blade &Adjustable Length

The more you use it, the sharper it gets




Image: Close-up of the KEMEI clipper's R-shaped blade and adjustable length mechanism, highlighting its sharp and safe design.

# Powerful motor

## Quick and efficient hair cutting



Image: An illustration demonstrating the powerful and quiet motor of the KEMEI clippers, emphasizing efficient cutting with low noise.

## 5. SETUP

### 5.1 Initial Charging

Before first use, fully charge both the clipper and trimmer. Connect the appropriate USB charging cable to each device and a compatible USB power source (e.g., computer, car charger, mobile power adapter). The smart light indicator will show charging status.

- Clipper Charging Time: Approximately 180 minutes for 240 minutes of use.
- Trimmer Charging Time: Approximately 180 minutes for 180 minutes of use.



Image: The KEMEI hair clipper and trimmer connected via USB for charging, illustrating the convenience of USB power.

### 5.2 Attaching Guide Combs

Select the desired limit comb for your intended hair length. Align the comb with the blade and firmly push it into place until it clicks. Ensure it is securely attached before operating the device.

### 5.3 Blade Adjustment (Clipper Only)

The main clipper features an adjustable lever on the side. Move the lever up or down to fine-tune the cutting length of the blade, even without a guide comb, for precise fading and blending.

## 6. OPERATING INSTRUCTIONS

### 6.1 Powering On/Off

Press the power button located on the device to turn it on or off. The smart light indicator will illuminate when the device is active.

## 6.2 Hair Cutting with Clipper (Km-1071)

Attach the desired limit comb. Hold the clipper with the blade facing away from you and move it against the direction of hair growth. Use smooth, even strokes. For blending, utilize the adjustable lever to gradually change cutting lengths.



Image: A KEMEI hair clipper being used by a barber to cut a client's hair, demonstrating professional application.

## 6.3 Detailing with Trimmer (Km-2299)

The trimmer is ideal for precise edging, outlining, and detailing. Use it without a comb for closest cuts or with the 1mm, 2mm, or 3mm combs for short beard trims or stubble. Gently press the blade against the skin and move it in the desired direction for clean lines.

Video: A demonstration of the KEMEI Professional Hair Clippers Set for Men, showcasing its features and use in a barber setting. This video provides a general overview of the product's capabilities.

Video: An unboxing and demonstration of the KEMEI 2296+2299 Professional hair clipper and trimmer set, highlighting the components and their initial setup and operation.

## 7. MAINTENANCE

---

### 7.1 Cleaning the Blades

After each use, turn off the device and remove any attached guide comb. Use the provided cleaning brush to remove loose hairs from the blades. For a more thorough cleaning, the blades can be carefully detached (refer to the video below for guidance) and rinsed under running water, ensuring the main body of the device does not get wet. Allow blades to air dry completely before reattaching.

Video: A step-by-step guide on how to change the clipper blade, which is useful for thorough cleaning and maintenance.

### 7.2 Oiling the Blades

Regularly apply a few drops of the provided lubricating oil to the blades after cleaning, especially if they feel stiff or noisy. Turn the device on for a few seconds to distribute the oil evenly. This helps maintain blade sharpness and smooth operation.

### 7.3 Storage

Store the devices and all accessories in the provided travel case in a cool, dry place, away from direct sunlight and moisture. Ensure the devices are fully charged before long-term storage to preserve battery health.

## 8. TROUBLESHOOTING

---

If you encounter issues with your KEMEI Hair Clippers & Trimmers Kit, consider the following:

- Device not turning on:** Ensure the device is fully charged. Check the charging cable and power source.
- Poor cutting performance:** Clean the blades thoroughly and apply lubricating oil. Ensure guide combs are correctly attached. Blades may need to be sharpened or replaced if heavily worn.
- Excessive noise or vibration:** Clean and oil the blades. Ensure the blade assembly is correctly secured.

For persistent issues not resolved by these steps, please contact KEMEI customer support.

## 9. SPECIFICATIONS

---

Feature	Detail
Product Dimensions	7.28 x 2.17 x 1.77 inches; 14.82 ounces
Batteries	1 Lithium Ion battery required (included)
Charging Time	180 minutes
Battery Description	Lithium-Ion
Power Source	Battery Powered
Manufacturer	KEMEI

## 10. WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the documentation included with your purchase or visit the

official KEMEI website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 KEMEI. All rights reserved.