

[Manuals.plus](#) /

> [Brightever](#) /

> Brightever Dusk to Dawn Outdoor Wall Light Fixture Instruction Manual (Model 9033-A)

## Brightever 9033-A

# Brightever Dusk to Dawn Outdoor Wall Light Fixture Instruction Manual

Model: 9033-A

## 1. SAFETY INFORMATION

---

Please read these instructions carefully before installation and retain them for future reference. Improper installation or use can lead to electrical shock, fire, or other hazards.

- **Disconnect Power:** Always turn off the main power supply at the circuit breaker before installing, servicing, or cleaning the fixture.
- **Qualified Electrician:** Installation should be performed by a qualified electrician or a person familiar with the construction and operation of the product and the hazards involved.
- **Grounding:** Ensure the fixture is properly grounded to avoid potential electrical shock.
- **Bulb Requirements:** Use only E26 base bulbs. Do not exceed the maximum recommended wattage of 100W for incandescent bulbs or 14W for LED bulbs.
- **Handle with Care:** The glass panels are sturdy but can break if mishandled.
- **Outdoor Use Only:** This fixture is designed for outdoor use and is waterproof.

## 2. PACKAGE CONTENTS

---

Verify that all components are present before beginning installation. This product is supplied as a 2-pack.

- Outdoor Wall Light Fixture (2 units)
- Instruction Manual
- Mounting Hardware (including wire connectors and screws)

## Product, Details



Figure 2.1: Product dimensions and included accessories for installation.

### 3. PRODUCT FEATURES

The Brightever Dusk to Dawn Outdoor Wall Light Fixture is designed with several key features for convenience and durability:

- **Dusk to Dawn Photocell Sensor:** Automatically turns the light on at dusk and off at dawn, optimizing energy use and providing hands-free operation.
- **Anti-corrosion & Weather Resistant:** Constructed with a pure aluminum framework, waterfall glass panels, and a bronze alloy finish, ensuring resistance to rain, snow, and extreme temperatures.
- **Sturdy Waterfall Glass:** Features thick, durable glass panels designed to withstand outdoor elements.
- **Open Bottom Design:** Facilitates easy bulb replacement and cleaning without disassembling the fixture.
- **Standard E26 Socket:** Compatible with various E26 base bulbs, including LED, CFL, and incandescent types (bulb not included).
- **Durable Metal Construction:** High-quality metal ensures longevity and robust performance in

outdoor environments.

Your browser does not support the video tag.

Video 3.1: An overview of the Brightever Dusk to Dawn Outdoor Wall Light, highlighting its automatic operation, waterproof design, durable metal, E26 socket, and water-ripple glass.

OURS	OTHERS
 Study Tempered Glass	 Fragile Thin Glass
 Premium Quality Aluminum	 Inferior Quality Metal
 Waterproof	 Not Waterproof
 Anti-rust	 Easy to Rust
 Anti-corrosion	 Easy to Corrosion

Figure 3.2: Durability comparison highlighting the fixture's waterproof and anti-corrosion properties.



# Compatible with Variety E26 Edison Bulbs

(LED, CFL, Incandescent)

Bulbs are not included



Figure 3.3: Bulb compatibility for the E26 socket.



Figure 3.4: Examples of the outdoor wall light in various application scenarios.

## 4. SETUP (INSTALLATION)

---

Follow these steps to install your Brightever outdoor wall light fixture. Ensure power is disconnected before starting.

1. **Prepare for Installation:** Turn off power at the main circuit breaker. Gather necessary tools (screwdriver, wire strippers, electrical tape, ladder).
2. **Mount the Fixture:** Secure the mounting bracket to the junction box using the provided screws. Ensure it is firmly attached.
3. **Wire Connections:** Connect the fixture's wires to your household electrical wires using the included wire connectors. Match black to black (live), white to white (neutral), and green/bare copper to green/bare copper (ground). Secure all connections with electrical tape.
4. **Attach the Fixture:** Carefully align the fixture with the mounting bracket and secure it with the provided screws.
5. **Install Bulb:** Insert an E26 base bulb (max 100W incandescent or 14W LED) into the socket.
6. **Restore Power:** Turn the power back on at the circuit breaker.

## 5. OPERATING INSTRUCTIONS

---

This fixture features an integrated photocell sensor for automatic operation.

- **Automatic On/Off:** The photocell sensor detects ambient light levels. The light will automatically turn on when it gets dark (dusk) and turn off when it becomes bright (dawn).
- **Optimal Placement:** For best performance, ensure the photocell sensor is not obstructed by objects or exposed to direct artificial light sources (e.g., other bright lights, streetlights) at night, as this may interfere with its operation.



Figure 5.1: Illustration of the automatic dusk to dawn functionality.

## 6. MAINTENANCE

---

Regular maintenance ensures the longevity and optimal performance of your light fixture.

- **Cleaning:** To clean the fixture, ensure power is off. Wipe the exterior with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish or glass.

- **Bulb Replacement:** Due to the open bottom design, bulb replacement is straightforward. Simply unscrew the old E26 bulb and screw in a new one (ensure power is off before replacing).
- **Inspection:** Periodically check for any loose wiring or damage to the fixture.

## 7. TROUBLESHOOTING

If you encounter issues with your light fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on at night.	No power; faulty bulb; photocell sensor obstructed or exposed to light.	Check circuit breaker. Replace bulb. Ensure sensor is clear and not receiving external light.
Light does not turn off during the day.	Photocell sensor obstructed or faulty; insufficient ambient light.	Ensure sensor is clear and receiving sufficient daylight. If problem persists, sensor may be faulty.
Light flickers.	Loose bulb; faulty bulb; unstable power supply.	Tighten or replace bulb. Check wiring connections. Consult an electrician if power supply is suspected.

## 8. SPECIFICATIONS

Detailed specifications for the Brightever Dusk to Dawn Outdoor Wall Light Fixture (Model 9033-A):

- **Brand:** Brightever
- **Model Number:** 9033-A
- **Color:** Bronze
- **Material:** Metal (Aluminum framework)
- **Shade Material:** Waterfall Glass
- **Item Dimensions (L x W x H):** 8.07" x 8.07" x 12.6"
- **Power Source:** Corded Electric
- **Voltage:** 120 Volts
- **Wattage:** Max 100W (Incandescent), Max 14W (LED)
- **Bulb Base:** E26
- **Controller Type:** Photocell Sensor (Dusk to Dawn)
- **Water Resistance Level:** Waterproof
- **Brightness:** Up to 800 lumens (bulb dependent)
- **Color Temperature:** 3000 Kelvin (bulb dependent)
- **Installation Type:** Wall Mount
- **Number of Items:** 2 (2-Pack)

## 9. WARRANTY AND SUPPORT

---

Your Brightever Dusk to Dawn Outdoor Wall Light Fixture (Model 9033-A) comes with a manufacturer's warranty.

- **Warranty:** This product is covered by a 1-year seller warranty.
- **Customer Support:** For any questions, technical assistance, or warranty claims, please contact Brightever customer support through your purchase platform or the official Brightever website.