



[Manuals.plus](#) /

› [HOMCOM](#) /

› HOMCOM Shoe Cabinet with 2 Doors, Model ES837-623V81ND0731 - Instruction Manual

HOMCOM ES837-623V81ND0731

HOMCOM Shoe Cabinet with 2 Doors

Model: ES837-623V81ND0731

INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your HOMCOM 2-door shoe cabinet. Please read all instructions carefully before assembly and use to ensure safe and correct operation.



Figure 1: HOMCOM 2-Door Shoe Cabinet in an entryway setting.

SAFETY INFORMATION

- Handle and assemble all components with care to prevent injury or damage.
- Ensure all screws and fasteners are securely tightened during assembly.
- Regular cleaning and maintenance are required to preserve the product's condition.
- Do not exceed the maximum weight capacities specified in the 'Specifications' section.
- This unit is designed for indoor use only.
- Always use the provided anti-tip hardware to secure the cabinet to a wall, especially in households with children or pets.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet panels (sides, top, bottom, back, doors)
- Adjustable shelves
- Door handles
- Hinges and associated hardware
- Assembly screws and fasteners
- Anti-tip hardware

SETUP AND ASSEMBLY

Assembly is required for this shoe cabinet. It is recommended to assemble the unit on a soft, clean surface to prevent scratches. Two people are recommended for assembly.

1. **Prepare Components:** Unpack all parts and identify them using the provided diagram (if available in the physical manual). Ensure all hardware is present.
2. **Assemble Frame:** Connect the side panels to the bottom and top panels using the designated screws and dowels. Ensure the back panel groove is correctly aligned.
3. **Install Shelves:** Insert the adjustable shelf pins into the desired holes on the side panels. Place the shelves onto these pins. The shelves can be adjusted to accommodate different shoe sizes.
4. **Attach Doors:** Secure the hinges to the cabinet doors and then attach the doors to the main cabinet frame. Adjust the hinges as needed to ensure proper door alignment and closure.
5. **Install Handles:** Attach the door handles to the front of the cabinet doors.
6. **Secure Anti-tip Device:** For safety, attach the anti-tip hardware to the back of the cabinet and secure it to a wall stud. This prevents the cabinet from tipping over.



Figure 2: Product dimensions for assembly planning.

ESTANTE AJUSTABLE

Adecuado para zapatos de diversos tamaños y tipos



Figure 3: Adjustable shelf feature.

DETALLES DEL PRODUCTO




Pomo elegante



Bordes
redondeados



Bisagras metálicas



Superficie
veteada

Figure 4: Details of the cabinet's components and finish.

OPERATING INSTRUCTIONS

The HOMCOM shoe cabinet is designed for organizing footwear and small items in your entryway or other rooms.

- **Shoe Storage:** The cabinet features two main compartments behind doors and open shelves on the right side. It can store approximately 12 pairs of shoes, depending on shoe size and type.
- **Adjustable Shelves:** The internal shelves are adjustable. To change shelf height, remove the shelf, reposition the shelf pins to the desired level, and then reinsert the shelf.
- **Top Surface:** The top surface can be used for decorative items, keys, or other small belongings. Ensure items placed on top do not exceed the specified weight capacity.

AMPLIO ESPACIO DE ALMACENAJE

Cuenta con 8 estantes y 1 encimera para mantener tu pasillo ordenado y organizado



Figure 5: Interior storage capacity with 8 shelves.



Figure 6: View of the cabinet interior with doors open.

MAINTENANCE

Proper maintenance will extend the life of your shoe cabinet.

- **Cleaning:** Wipe the surfaces with a dry cloth. For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid abrasive cleaners or harsh chemicals.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Door Alignment:** If doors become misaligned, adjust the hinges as described in the assembly instructions or consult a professional.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Doors do not close properly or are misaligned.	Hinges are not adjusted correctly or screws are loose.	Adjust the hinge screws to align the doors. Ensure all hinge screws are tightened. Refer to the assembly instructions for hinge adjustment details.
Cabinet feels unstable or wobbly.	Assembly screws are loose or the unit is not level. Anti-tip device not installed.	Check and tighten all assembly screws. Ensure the cabinet is placed on a flat, level surface. Install the anti-tip device securely to a wall stud.
Shoes do not fit on shelves.	Shelves are set at an unsuitable height.	Adjust the height of the shelves using the adjustable shelf pins to accommodate larger shoes or boots. Some larger shoe sizes may need to be placed diagonally.

SPECIFICATIONS

Brand	HOMCOM
Model Number	ES837-623V81ND0731
Color	Natural Wood
Material	Melamine
Overall Dimensions (L x W x H)	83 cm x 30 cm x 90 cm
Max Total Weight Capacity	35 kg
Max Top Shelf Weight Capacity	10 kg
Max Shelf Weight Capacity (each)	5 kg
Number of Doors	2
Number of Shelves	8
Assembly Required	Yes
Care Instructions	Clean with a dry cloth

WARRANTY AND SUPPORT

No specific warranty information is provided in the product details. For support, missing parts, or warranty inquiries, please contact your retailer or the manufacturer, HOMCOM, directly. Refer to your purchase documentation for contact details.

PRODUCT VIDEOS

No official product videos from the seller were found for this item.

