

[manuals.plus](#) /

› [HOMCOM](#) /

› [HOMCOM Manual Swivel Recliner Chair Instruction Manual](#)

HOMCOM 839-964V80BK

HOMCOM Manual Swivel Recliner Chair Instruction Manual

Model: 839-964V80BK | Brand: HOMCOM

INTRODUCTION

Thank you for choosing the HOMCOM Manual Swivel Recliner Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner chair. Please read these instructions carefully before use and retain them for future reference.



Figure 1: HOMCOM Manual Swivel Recliner Chair (Upright)

SAFETY INFORMATION

Important Safety Precautions:

- The maximum weight capacity for this chair is 330 lbs (150 kg). Do not exceed this limit.
- Ensure proper assembly for stability. Follow all assembly instructions carefully.
- Before each use, verify that all parts are securely fastened and the chair is stable.
- Keep children and pets away from the chair during assembly and operation to prevent injury.
- Avoid placing fingers or other body parts near moving mechanisms to prevent pinching.
- Do not stand on the chair or use it as a step stool.

SETUP AND ASSEMBLY

Assembly of the HOMCOM Manual Swivel Recliner Chair is required. Please follow the instructions provided in the package to assemble the chair. Ensure all parts are securely fastened and the chair is stable before use.

General Assembly Steps:

1. Unpack all components and verify against the parts list in your package.
2. Attach the backrest to the seat base, ensuring the connection points align and lock securely.
3. Connect the armrests to the main chair frame.
4. Assemble the swivel base and attach it to the chair's underside.
5. Ensure all screws, bolts, and fasteners are tightened appropriately. Do not overtighten.
6. Test the reclining and swivel functions to ensure smooth operation.



Figure 2: Robust Construction Details

OPERATING INSTRUCTIONS

This manual swivel recliner chair offers adjustable lounging options for enhanced comfort.

Reclining Function

To recline the chair, locate the side knobs on the chair's mechanism. Rotate these knobs to adjust the backrest angle up to 135 degrees. Once the desired angle is achieved, tighten the knobs to lock the position. This allows for comfortable reading, watching TV, or napping.

LIFTED FOOTREST



Figure 3: Reclining the Chair to 135 Degrees

Footrest Adjustment

To engage the built-in footrest, pull the side lever located near the seat. The footrest will extend, providing support for your legs. To retract the footrest, push it down with your legs while simultaneously pulling the lever.



360° SWIVEL BASE

Allows for fun and easy movement in a complete circle

Figure 4: Lifted Footrest

360-Degree Swivel Base

The chair features a 360-degree rotating base, allowing for seamless movement and easy rotation. This is ideal for engaging in conversations or adjusting your position without moving the entire chair.

HIGH COMFORT



Figure 5: 360-Degree Swivel Base

Video Demonstration

Watch this official product video for a visual guide on the chair's features and operation:

Your browser does not support the video tag.

Video 1: HOMCOM 839-964V80BK Recliner Chair Features and Operation. This video demonstrates the reclining and footrest functions of the chair.

MAINTENANCE

To ensure the longevity and appearance of your HOMCOM recliner chair, follow these maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the PU leather upholstery.
- **Regular Inspection:** Periodically check all fasteners and connections to ensure they remain tight. Tighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the PU leather to fade or

crack.

- **Spills:** Clean spills immediately with a soft, dry cloth to prevent staining.

TROUBLESHOOTING

If you encounter any issues with your recliner chair, please refer to the following common troubleshooting tips:

- **Chair does not recline smoothly:** Check if the side knobs are loose or if there is any obstruction in the reclining mechanism. Ensure the chair is on a level surface.
- **Footrest does not extend/retract:** Verify that the side pull lever is functioning correctly and not jammed. Check for any obstructions under the footrest.
- **Chair feels unstable:** Re-check all assembly connections and tighten any loose screws or bolts. Ensure the chair is placed on a flat, stable floor.
- **Squeaking noises:** Apply a small amount of silicone-based lubricant to moving metal parts if squeaking occurs. Avoid oil-based lubricants on upholstery.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

Brand	HOMCOM
Model Name	Recliner Chair
Item Model Number	839-964V80BK
Color	Black
Material	Faux Leather (PU Leather), Foam, Powder Coated Steel Frame, Wood Base
Product Dimensions (Upright)	30.7" W x 34.6" D x 40.6" H
Product Dimensions (Fully Reclined)	29.9" W x 59.4" D x 36.6" H
Seat Height	17.7 Inches
Seat Depth	22 inches
Maximum Weight Recommendation	330 Pounds
Item Weight	40.8 Pounds
Special Features	Arm Rest, Foot Rest, Reclining, Swivel, Upholstered Leather



Figure 6: Product Dimensions

WARRANTY AND SUPPORT

For warranty information, technical support, or to report missing/damaged parts, please contact HOMCOM customer service. Refer to the contact details provided in your product packaging or visit the official HOMCOM website.

Manufacturer: Aosom LLC