

YXYKODM LX-10

YXYKODM LX-10 Touch Screen Wireless Earbuds Instruction Manual

Model: LX-10 | Brand: XYKODM

1. SAFETY INFORMATION

Please read all safety instructions carefully before using this product. Keep this manual for future reference.

- Avoid prolonged exposure to high volume levels to prevent hearing damage.
- Do not use the earbuds in situations where inability to hear ambient sounds may pose a danger (e.g., driving, cycling, or walking in traffic).
- Keep the device away from water and moisture. This product is not water resistant.
- Do not expose the product to extreme temperatures or direct sunlight.
- Do not attempt to disassemble, repair, or modify the product. This may void the warranty and cause damage.
- Dispose of the product and its battery responsibly according to local regulations.

2. PRODUCT OVERVIEW

The XYKODM LX-10 Touch Screen Wireless Earbuds feature advanced Active Noise Cancelling (ANC) technology, a smart touch screen charging case, and Bluetooth 5.0 connectivity for a superior audio experience.

What's in the Box:

- XYKODM LX-10 Earbuds (Left and Right)
- Smart Touch Screen Charging Case
- USB-C Charging Cable
- Multiple Sizes of Ear Caps
- User Manual

Key Features:

- **Active Noise Cancelling (ANC):** Reduces external noise by up to 35dB for immersive listening.
- **ENC Call Noise Reduction:** Ensures clear calls even in noisy environments.
- **Full-Color Touch Screen Case:** Provides intuitive control over music, settings, and more.
- **Bluetooth 5.0:** Offers stable and efficient wireless connectivity.
- **Long Battery Life:** Up to 4-5 hours playtime per charge, with 24 hours additional charge from the case.
- **Multiple Sound Modes:** Includes Music, Game, and Movie modes for optimized audio.
- **Customizable Equalizer:** Adjust sound preferences with various EQ modes (Pop, Rock, Classical, Jazz, Vocals, Electric, Dance).
- **Personalized Screen Savers:** Switch between five dynamic screen displays.

Product Diagram:

Multifunctional touch screen headphones

ANC+ENC double mark noise reduction

"⑤" EQ SOUND EFFECTS
⑩ A PRACTICAL FUNCTION




Image: YXYKODM LX-10 Touch Screen Wireless Earbuds and their charging case, illustrating the overall design and components.

3. SETUP

3.1 Charging the Case and Earbuds

1. **Initial Charge:** Before first use, fully charge the charging case and earbuds.
2. **Charge the Case:** Connect the provided USB-C charging cable to the charging port on the case and a power source. The LED display on the case will show the charging status. A full charge takes approximately 1.5 hours.
3. **Charge the Earbuds:** Place the earbuds into their respective slots in the charging case. They will automatically begin charging. The case's display will show the battery levels of both earbuds.



**18H comprehensive
strong endurance**

A 1.5h charge gives you a full day of listening

Image: The YXYKODM LX-10 charging case is shown connected to a USB-C cable, indicating it is being charged. The screen displays charging progress.

3.2 Bluetooth Pairing

1. **Activate Bluetooth:** Ensure Bluetooth is enabled on your smartphone or other audio device.
2. **Open the Case:** Open the charging case. The earbuds will automatically enter pairing mode.
3. **Select Device:** On your device, search for "LX-10" in the Bluetooth settings and select it to connect.

4. **Confirmation:** Once connected, the earbuds will indicate successful pairing, and the case display may show a connected icon.

4. OPERATING INSTRUCTIONS

The smart touch screen on the charging case provides comprehensive control over your earbuds' functions. You can also use touch controls directly on the earbuds.

4.1 Touch Screen Controls (Charging Case)

The full-color touch screen allows for easy navigation and control. Swipe left/right or tap icons to access various functions.

LED full color touch screen

LCD full color touch screen, call answering,
Music playback, as well as
many headphone functions



Image: The YXYKODM LX-10 charging case with its LED full-color touch screen displaying multiple functional icons for control.

- **Music Playback:** Play, pause, skip tracks, and adjust volume directly from the screen.
- **ANC/Transparency Mode:** Toggle between Active Noise Cancelling, Transparency, and Normal modes.

- **Equalizer Settings:** Select from preset EQ modes (Pop, Rock, Classical, Jazz, Vocals, Electric, Dance) to customize your audio experience.
- **Find My Earphone:** Activate a beeping sound on a lost earbud to help locate it.
- **Personalized Screen Savers:** Choose from five dynamic screen displays to personalize your case.
- **Other Functions:** Access features like flashlight, camera remote control, and timer.

Personalized saverswitch

Five high appearance level
dynamic displays can be switched at any time



* With 5 high appearance horizontal display,
2 dynamic display, can be switched at any time



Image: The YXYKODM LX-10 charging case showing options for personalized screensavers, allowing users to select different dynamic displays.

4.2 Earbud Touch Controls

The earbuds themselves also feature touch-sensitive areas for quick control without needing to access the charging case.

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap the right earbud.
- **Previous Track:** Double tap the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Long press on either earbud.

- **Activate Voice Assistant:** Triple tap on either earbud.

4.3 Sound Modes

Optimize your listening experience with dedicated sound modes:

- **Musical Pattern:** Simulates a wide sound field with enhanced vocals.
- **Game Mode:** Provides ultra-low latency (0.06 seconds) for synchronized audio during gaming.
- **Movie Mode:** Enhances sound effects for an immersive cinematic experience.

Three scene modes

Professional grade tuning different scenes:
Smart music/game/movie three modes
casual switching



Musical pattern

When listening to songs,
simulate a wide sound field,
The voice is enhanced,
and the timbre is bright and clear.



Game mode

Stable 0.06 seconds ultra-low latency
listening position recognition



Movie mode

The enhanced sound effect and the
colorful sound quality give you a feeling
of being there

Image: The YXYKODM LX-10 earbuds are shown with a graphic illustrating three distinct sound modes: Musical, Game, and Movie, each optimized for different audio experiences.

4.4 Active Noise Cancellation (ANC) and Environmental Noise Cancellation (ENC)

The earbuds are equipped with advanced noise reduction technologies:

- **ANC:** Reduces up to 35dB of external noise, blocking up to 99.44% of environmental sounds. Activate via the touch screen or earbud controls.
- **ENC:** Enhances call clarity by reducing background noise during phone conversations.



ANC actively deep noise reduction

35DB intelligent broadband depth noise reduction,
blocking up to 99.44%

External noise, fearless noise, quiet life.

Image: A visual representation of the YXYKODM LX-10 earbuds demonstrating active deep noise reduction, showing sound waves being cancelled around the ear.

ENC call noise reduction

ENC noise reduction technology,
Even in a noisy environment
You can talk clearly and easily



Image: A graphic showing the YXYKODM LX-10 earbuds with ENC call noise reduction, indicating clear communication even in noisy environments.

4.5 Equalizer Adjustment

Fine-tune your audio with the built-in equalizer accessible via the touch screen.

Music equalizer adjustment

You control your sound preferences with 7 sound modes, Balanced mode: Pop, rock, Classical, Jazz, vocals, electric, dance.



Image: The YXYKODM LX-10 charging case's touch screen shows various music equalizer adjustment options, including Pop, Rock, Jazz, and Classical modes.

4.6 Video Demonstrations

Video: This video demonstrates the Bluetooth 5.4 connectivity and multifunction touch screen features of the YXYKODM LX-10 earbuds, showcasing various controls and settings.

Video: This video highlights the wireless charging case and touch screen functionalities of the YXYKODM LX-10 earbuds, demonstrating ease of use and interactive display.

Video: This video showcases the Bluetooth touch screen features of the YXYKODM LX-10 wireless earbuds, focusing on the interactive display and various control options.

Video: This video provides a detailed look at the LED Bluetooth headset, highlighting its design, features, and user interaction with the touch screen.

Video: This video demonstrates the noise-cancelling capabilities of the YXYKODM LX-10 touchscreen earbuds, showing how they effectively block out surrounding noise.

5. MAINTENANCE

5.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear caps and clean them with mild soap and water, then dry thoroughly before reattaching.
- Ensure charging contacts on both earbuds and case are clean and free of debris.

5.2 Storage

When not in use, store the earbuds in their charging case to protect them and ensure they remain charged.

6. TROUBLESHOOTING

Common Issues and Solutions:

- **Earbuds not pairing:** Ensure both earbuds are charged and in the case. Open the case to initiate pairing mode. Check your device's Bluetooth settings and try reconnecting.
- **No sound from one earbud:** Place both earbuds back in the case, close it, then reopen to reset. Check device's audio balance settings.
- **Charging issues:** Ensure the charging cable is securely connected and the power source is active. Clean charging contacts if necessary.
- **Touch screen unresponsive:** Restart the charging case by placing earbuds inside, closing the lid, and then reopening.

7. SPECIFICATIONS

Feature	Specification
Model Name	Touch screen earbuds Wireless Earbuds
Item Model Number	LX-10
Brand	YXYKODM
Connectivity Technology	Bluetooth 5.0
Bluetooth Range	Approximately 10 Meters

Feature	Specification
Noise Control	Active Noise Cancellation (ANC)
Battery Life (Earbuds)	4-5 Hours
Charging Case Playback Time	24 Hours
Charging Time (Case)	1.5 Hours
Control Method	Touch
Material	Plastic, Silicone
Item Weight	4.6 ounces
Water Resistance Level	Not Water Resistant
Compatible Devices	iPhone, Android devices

8. WARRANTY AND SUPPORT

For any questions, concerns, or if you receive a defective product, please contact YXYKODM customer support. Refer to the packaging or the official YXYKODM website for specific warranty details and contact information.

© 2024 YXYKODM. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question