

Holyask VV-128GB

Holyask VV-128GB Digital Voice Recorder User Manual

Model: VV-128GB

1. INTRODUCTION

The Holyask VV-128GB Digital Voice Recorder is designed for high-quality audio capture in various settings, including lectures, meetings, and personal notes. It features a large 128GB internal storage, voice-activated recording, and robust security options. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your device.





Figure 1: Holyask VV-128GB Digital Voice Recorder and included 128GB Micro SD card.

2. SETUP

2.1. Package Contents

Before proceeding, please verify that all items are present in the package:

- 1 x Holyask VV-128GB Digital Voice Recorder
- 1 x USB-C Data Charging Cable
- 1 x User Manual (this document)

2.2. Initial Charging

The device comes with a built-in Lithium Ion battery. For optimal performance, fully charge the recorder before first use.

1. Connect the smaller end of the provided USB-C cable to the recorder's USB-C port.
2. Connect the larger end of the USB-C cable to a standard USB power adapter (not included) or a computer's USB port.
3. The battery indicator on the screen will show charging status. A full charge typically takes approximately 2-3 hours.

2-in-1 Transfer Data Cable

Either charge or use the USB-C cable to transfer recordings to any device.
Hassle-free and convenient



Figure 2: Connecting the device for charging or data transfer using the USB-C cable.

3. OPERATING INSTRUCTIONS

3.1. Device Overview



Figure 3: Labeled diagram of the recorder's buttons and ports.

3.2. Power On/Off

To power on the device, slide the **Power switch** (7) to the ON position. To power off, slide it to the OFF position.

3.3. Recording Audio

The recorder supports high-quality 1536Kbps PCM audio recording with noise cancellation.

1536Kbps PCM Recording

Dual Microphone system, let you enjoy the superior recording quality, Display file names in date and time format, easily manage your recording files.



Figure 4: High-quality PCM recording with dual microphones.

1. Ensure the device is powered on.
2. Slide the **REC switch** (6) upwards to start recording. The screen will display the recording interface.
3. To pause recording, briefly slide the REC switch downwards. To resume, slide it upwards again.
4. To stop and save the recording, slide the REC switch downwards and hold for a few seconds. The screen will display "Saved".

3.4. Voice-Activated Recording (VOR)

The device can automatically start recording when sound is detected (above 60dB) and pause when silent, saving memory.

Voice Sound Transducers

Utilizes the latest in audio technology, the recorder's superior acoustic sensor fine-tunes its sensitivity to sound. When there is sound (above 60dB), recording will start automatically.



Figure 5: Voice-activated recording feature.

1. Navigate to the recording settings menu.
2. Select "VOR Mode" or "Voice Activated Recording".
3. Adjust the voice decibel level sensitivity as needed.
4. Activate VOR mode. The recorder will now only record when sound is detected above the set threshold.

3.5. Playback

You can play back recorded files directly on the device.




Figure 6: Playback function with earphones.

1. From the main menu, select "Music" or "Recordings".
2. Use the navigation buttons to select the desired file.
3. Press the **Play/Use button** (15) to start playback.
4. Use the **Volume -** (11) and **Volume +** (9) buttons to adjust playback volume.
5. The device supports A-B repeat functionality for specific sections of audio.

3.6. File Management & Transfer

The device has 128GB of storage and can store up to 999 audio files. Files are saved in MP3 or WAV formats.

1. Connect the recorder to your computer using the provided USB-C cable.
2. The device will appear as a removable disk drive.
3. Drag and drop files to and from the recorder to transfer them.
4. Files are named with date and time for easy organization.

3.7. Password Protection

Protect your recordings with a password.

Password Protection

No one can open the device without the correct password. Save recording files in a safe place to protect your privacy



Figure 7: Password protection feature.

1. Navigate to the security settings in the device menu.
2. Select "Password Protection" and follow the on-screen prompts to set or change your password.

4. MAINTENANCE

4.1. Cleaning

To maintain the device's appearance and functionality:

- Wipe the exterior with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.

4.2. Battery Care

The device uses a rechargeable Lithium Ion battery. To prolong battery life:

- Avoid extreme temperatures.
- Charge the device regularly, even if not in frequent use.
- Do not leave the device fully discharged for extended periods.

4.3. Storage

When not in use, store the recorder in a cool, dry place away from direct sunlight and moisture. The compact size makes it easy to carry.



Figure 8: The compact design allows for easy portability and storage.

5. TROUBLESHOOTING

If you encounter issues with your Holyask VV-128GB Digital Voice Recorder, please refer to the following common solutions:

| Problem | Possible Cause | Solution |
|------------------------------------|---|--|
| Device does not power on. | Low battery; Power switch in OFF position. | Charge the device fully. Ensure the Power switch is in the ON position. |
| Cannot record. | Insufficient storage space; REC switch not engaged; Device frozen. | Delete old files to free up space. Ensure REC switch is firmly slid upwards. Restart the device. |
| Poor recording quality. | High background noise; Incorrect microphone placement; Low recording bitrate. | Use noise reduction settings. Ensure microphones are clear. Adjust recording quality settings (e.g., to 1536Kbps PCM). |
| Cannot transfer files to computer. | Loose USB connection; Driver issue; Incorrect mode. | Ensure USB-C cable is securely connected. Try a different USB port or cable. The device should automatically enter USB drive mode. |

6. SPECIFICATIONS

| Feature | Detail |
|---------------------------|---------------------------|
| Model Number | VV-128GB (RM) |
| Storage Capacity | 128 GB |
| Recording Formats | MP3, WAV |
| Recording Quality | Up to 1536Kbps PCM |
| Battery Type | 1 Lithium Ion (included) |
| Continuous Recording Time | Up to 54 hours |
| Dimensions (L x W x H) | 4.13 x 1.45 x 0.43 inches |
| Item Weight | 3.31 ounces |
| Microphone Form Factor | Mini |
| Headphones Jack | 3.5 millimeters |
| Hardware Interface | USB |

7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided with your purchase or visit the official Holyask website. Keep your purchase receipt for warranty claims.

Manufacturer: Holyask