

[Manuals.plus](#) /

› [Legami](#) /

› Legami SLBAG0002 Lunch Bag Instruction Manual

Legami SLBAG0002

Legami SLBAG0002 Lunch Bag Instruction Manual

Model: SLBAG0002

INTRODUCTION

This manual provides comprehensive instructions for the proper use, care, and maintenance of your Legami SLBAG0002 Lunch Bag. Please read this manual carefully before first use to ensure optimal performance and longevity of your product. Keep this manual for future reference.

PRODUCT FEATURES

The Legami SLBAG0002 Lunch Bag is designed for convenient and efficient food transport. Key features include:

- **Durable Construction:** Made with robust materials for everyday use.
- **Heat-Insulating Interior:** Helps maintain the temperature of your food, keeping it warm or cool.
- **Washable Materials:** Easy to clean for hygiene and repeated use.
- **Main Zippered Compartment:** Secure storage for your main meal.
- **Two Side Mesh Pockets:** Ideal for water bottles, small snacks, or accessories.
- **One Front Zippered Pocket:** Provides additional storage for utensils, napkins, or personal items.
- **Removable and Adjustable Shoulder Strap:** Offers versatile carrying options for comfort.



Image: Front view of the Legami SLBAG0002 Lunch Bag, showcasing the main compartment, front pocket, and shoulder strap. The bag features a blue background with a white star pattern and text.

SETUP

The Legami SLBAG0002 Lunch Bag requires minimal setup before use.

Adjusting the Shoulder Strap

1. Locate the adjustable buckle on the shoulder strap.
2. Slide the buckle to lengthen or shorten the strap to achieve your desired carrying length.
3. Ensure the strap is securely fastened and adjusted for comfort before carrying the bag.



Image: Close-up view of the top of the Legami SLBAG0002 Lunch Bag, showing the dual zippers for the main compartment and the sturdy top handle.

OPERATING INSTRUCTIONS

Packing Your Lunch Bag

1. Open the main zippered compartment.
2. Place your food containers and beverages inside the main compartment.
3. Utilize the two side mesh pockets for items such as water bottles, fruit, or small snacks.
4. Use the front zippered pocket for utensils, napkins, condiments, or other small personal items.
5. Close all zippers securely to maintain insulation and prevent items from falling out.



Image: The Legami SLBAG0002 Lunch Bag shown open, revealing its spacious, insulated interior and indicating a 7.7-liter capacity.

Carrying Your Lunch Bag

- **Top Handle:** Use the integrated top handle for convenient hand carrying.
- **Shoulder Strap:** Attach the adjustable shoulder strap for hands-free carrying over your shoulder or across your body.

Insulation Tips

- For best results with cold items, place ice packs (not included) inside the main compartment along with your food.
- For warm items, ensure food is packed warm and the bag is closed immediately to retain heat.

MAINTENANCE AND CARE

Proper care will extend the life of your Legami SLBAG0002 Lunch Bag.

- **Cleaning:** Hand wash the lunch bag using mild soap and cold water. Do not use a washing machine or dryer.

- **Drying:** Air dry thoroughly after cleaning. Ensure the bag is completely dry before storing to prevent mold or mildew.
- **Storage:** Store the lunch bag in a clean, dry place away from direct sunlight when not in use.
- **Precautions:** Avoid exposing the bag to high heat, as this can damage the material and compromise its insulating properties. Do not use harsh chemicals, bleach, or abrasive cleaners.



Image: Side view of the Legami SLBAG0002 Lunch Bag, highlighting one of the mesh side pockets.

TROUBLESHOOTING

If you encounter any issues with your lunch bag, refer to the following common solutions:

Issue	Possible Cause / Solution
Food not staying cold/warm	Ensure all zippers are fully closed to seal the insulated compartment. For cold items, use ice packs (not included) to enhance cooling. For warm items, pack them warm and close the bag immediately.

Issue	Possible Cause / Solution
Zipper sticking or difficult to move	Check for any fabric caught in the zipper teeth. Gently remove it. Apply a small amount of zipper lubricant (e.g., wax or silicone spray) to the zipper teeth. Avoid forcing the zipper, as this can cause damage.
Unpleasant odor inside the bag	Thoroughly clean the interior of the bag as per the "Maintenance and Care" instructions. Allow the bag to air dry completely in a well-ventilated area. Place an open box of baking soda inside the bag overnight to absorb odors.

SPECIFICATIONS

Model	SLBAG0002
Capacity	7.7 Liters
Dimensions (L x W x H)	28 cm x 17 cm x 15 cm (approx. 11.02 in x 6.69 in x 5.91 in)
Weight	0.27 kg (approx. 0.6 lbs)
Material	RPET exterior, PEVA interior, sponge padding
Color / Pattern	Blue / Stars
Closure Type	Zipper
Included Components	Main Compartment, 2 Side Mesh Pockets, 1 Front Zip Pocket, Adjustable Shoulder Strap



Image: Angled view of the Legami SLBAG0002 Lunch Bag, illustrating its rectangular shape and the various compartments.

WARRANTY AND SUPPORT

Legami products are manufactured to high-quality standards. For specific warranty information, please refer to the documentation provided at the time of purchase or visit the official Legami website. For product support, inquiries, or assistance, please contact Legami customer service directly or reach out to your authorized retailer.