

## ODIKA SF-L-051224

# ODIKA L Shaped Convertible Sleeper Sofa Bed Instruction Manual

Model: SF-L-051224

Brand: ODIKA

## 1. SAFETY INFORMATION

---

Please read and understand all safety warnings before assembly and use of this product.

- Keep the sofa bed away from open flames or high heat sources to prevent fire hazards.
- Supervise children and pets around the sofa bed, especially during conversion, to avoid entrapment risks.
- Use the integrated USB-C and USB-A charging ports with caution. Always follow manufacturer's guidelines for connected devices to prevent electrical hazards. Do not overload the ports.
- Always follow the assembly instructions carefully to ensure the sofa bed is stable and safe for use. Improper assembly can lead to instability and injury.
- Do not exceed the maximum weight capacity of the sofa bed.

## 2. PRODUCT OVERVIEW

---

The ODIKA L Shaped Convertible Sleeper Sofa Bed is designed for versatility and comfort, featuring multiple functionalities to enhance your living space.



Image 2.1: Overview of the sofa bed with key dimensions (84" width, 31.5" depth, 31.9" height, 55.1" chaise length) and packaging details, indicating it arrives in two boxes.

## Key Features:

- **Pull-Out Sofa Bed:** Easily converts from a stylish L-shaped sofa to a comfortable full-size bed (54x75 inches), ideal for accommodating guests.
- **Dual Armrest Power:** Equipped with integrated USB-C and USB-A charging ports on both armrests for convenient device charging.
- **Hidden Chaise Storage:** The chaise lounge features a lift-up top, revealing a spacious storage compartment for blankets, pillows, or other essentials.
- **Removable & Washable Linen Covers:** The sofa cushions are fitted with removable linen covers that are machine washable for easy maintenance.
- **Pockets:** Side pockets are integrated into the armrests for storing small items like remote controls or magazines.

## 3. SETUP AND ASSEMBLY

---

Assembly of the ODIKA L Shaped Convertible Sleeper Sofa Bed is required. It is recommended to have two people for assembly. Ensure all parts are present before beginning.

### 3.1 Unpacking

1. Carefully unpack all components from the two shipping boxes.
2. Place all parts on a clean, soft surface (e.g., a rug or blanket) to prevent scratches.
3. Verify that all hardware and components listed in the assembly guide are present. If any parts are missing or damaged, contact customer support.

### 3.2 Assembly Steps (General Guidelines)

Refer to the detailed assembly instructions provided in the packaging for specific steps and diagrams. The general process involves:

1. Attach the sofa legs to the main frame sections.
2. Connect the main sofa sections together using the provided connectors.
3. Assemble the chaise lounge unit and attach it to the main sofa frame. Ensure the orientation (left or right) is as desired.
4. Install the armrests, ensuring they are securely fastened. Some users have reported that armrest cleats might be installed upside down from the factory; if you encounter difficulty, try reorienting them.
5. Place the seat cushions, back cushions, and pillows onto the sofa.
6. Connect the power cord for the USB charging ports to a wall outlet.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Converting Sofa to Bed

To convert your L-shaped sofa into a bed:

1. Remove all back cushions and pillows from the sofa.
2. Locate the pull-out handle or strap on the front of the sofa's main section.
3. Gently pull the bed mechanism outwards until it fully extends and locks into place. Ensure it is level and stable.
4. To revert to sofa mode, lift the front edge of the bed slightly to disengage the lock, then push the mechanism back into the sofa until it is fully retracted.



**Sofa**



**Bed**

Image 4.1: The sofa in its standard seating configuration and then fully extended as a bed, demonstrating the conversion process.

## 4.2 Using Dual USB-C Charging Ports

The sofa is equipped with USB-C and USB-A charging ports on both armrests.

1. Ensure the sofa's power cord is plugged into a functional wall outlet.
2. Connect your device's charging cable to the appropriate USB-C or USB-A port on either armrest.
3. The ports are designed for charging small electronic devices. Avoid connecting high-power devices that may exceed the port's capacity.

# Built in Power

## Available on Both Sides



Image 4.2: A close-up view of the armrest, highlighting the integrated Type C and USB-A charging port and the convenient side storage pockets.


### 4.3 Accessing Hidden Chaise Storage

The chaise lounge offers hidden storage space.

1. Locate the fabric handle on the front edge of the chaise cushion.
2. Using the handle, lift the chaise cushion upwards. The assisted lift mechanism will help hold the lid open.
3. Place or retrieve items from the storage compartment.
4. Gently lower the chaise cushion until it rests securely in place.

# Lift-Up Chaise

## Hidden Storage for Larger Items



  
**Assisted Lift**

  
**Extra Large  
Storage Space**

  
**Convenient  
Fabric Handle**

Image 4.3: The chaise lounge with its top lifted, revealing the spacious hidden storage compartment, suitable for larger items.

## 5. MAINTENANCE

### 5.1 Cleaning the Fabric Covers

The sofa features removable and washable linen covers for easy cleaning.

1. Unzip and remove the linen covers from the cushions.
2. Machine wash the covers according to the care label instructions, typically on a gentle cycle with cold water.
3. Air dry or tumble dry on low heat to prevent shrinking or damage. Do not bleach.
4. Once dry, carefully place the covers back onto the cushions.

# Ultimate Comfort

Includes 3 Back Cushions + 2 Pillows



Image 5.1: A detailed view of a sofa cushion, showing the zipper for easy removal of the breathable, durable, and washable linen cover.

## 5.2 General Care

- For general cleaning of the sofa frame or non-removable fabric areas, wipe clean with a dry cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the material.
- Periodically check all bolts and fasteners to ensure they remain tight. Retighten as necessary.
- Avoid prolonged exposure to direct sunlight to prevent fading of the fabric.

## 6. TROUBLESHOOTING

This section addresses common issues you might encounter with your sofa bed.

### 6.1 Sofa Bed Mechanism Not Extending/Retracting Smoothly

- **Check for Obstructions:** Ensure no objects (e.g., rugs, toys, debris) are blocking the mechanism's path.
- **Verify Alignment:** Make sure the pull-out frame is aligned correctly with the tracks. If it feels stuck,

gently jiggle it while pulling or pushing.

- **Lubrication:** If the mechanism is stiff, a silicone-based lubricant can be applied to the moving parts (avoid oil-based lubricants on plastic components).
- **Rails Dislodged:** If the pull-out part comes off the rails, carefully lift and guide it back into the tracks. This may require two people.

## 6.2 USB Charging Ports Not Working

- **Power Connection:** Confirm that the sofa's main power cord is securely plugged into a live wall outlet.
- **Device Compatibility:** Ensure your device and charging cable are functional and compatible with USB-A or USB-C standards.
- **Overload Protection:** The ports may have overload protection. Disconnect all devices, unplug the sofa for a minute, then reconnect and try again with a single device.

## 6.3 Chaise Storage Lid Not Closing Properly

- **Check for Overfilling:** Ensure the storage compartment is not overfilled, preventing the lid from closing completely.
- **Hinge Alignment:** Inspect the hinges and assisted lift mechanism for any misalignment or damage.

# 7. SPECIFICATIONS

Feature	Specification
Brand	ODIKA
Model Number	SF-L-051224
Type	Sofa Bed (L Shape)
Colour	Beige
Overall Dimensions (D x W x H)	135.6D x 185.7W x 74.7H centimetres (approx. 53.4D x 73.1W x 29.4H inches)
Sleeper Bed Size	Full size (approx. 54 x 75 inches)
Seat Depth	66 centimetres (approx. 26 inches)
Seat Height	13.6 Inches (approx. 34.5 cm)
Seating Capacity	3.0
Frame Material	Iron
Upholstery Material	Linen (Breathable, durable, easy to maintain)
Cushion Fill Material	Foam
Special Features	Hidden Storage, Pull-Out Sofa Bed, Dual USB-C/USB-A Charging, Removable & Washable Covers

Assembly Required	Yes
Product Care Instructions	Wipe Clean with Dry Cloth (for frame), Machine Washable (for covers)

## 8. WARRANTY INFORMATION

---

This ODIKA L Shaped Convertible Sleeper Sofa Bed comes with a **Limited Warranty**. Details regarding the duration and coverage of this warranty are typically provided in the warranty card included with your product packaging. Please retain your proof of purchase for any warranty claims.

The limited warranty generally covers manufacturing defects in materials and workmanship under normal use. It typically does not cover damage resulting from misuse, accidents, unauthorized repairs, or normal wear and tear.

## 9. CUSTOMER SUPPORT

---

If you have any questions, require assistance with assembly, or encounter issues not covered in this manual, please contact ODIKA customer support.

Please refer to the contact information provided in your product packaging or visit the official ODIKA website for support options.

When contacting support, please have your model number (SF-L-051224) and proof of purchase readily available.