

[Manuals.plus](#) /

› [VGR](#) /

› VGR V-360 Digital Display Cordless Dual Sided OneBlade Trimmer & Shaver User Manual

VGR V-360

VGR V-360 Digital Display Cordless Dual Sided OneBlade Trimmer & Shaver User Manual

Model: V-360 | Brand: VGR

SAFETY INFORMATION

Please read all instructions carefully before using the VGR V-360 Trimmer & Shaver. Keep this manual for future reference.

- Do not immerse the charging adapter in water. The trimmer itself is waterproof (IPX6 rated) and can be rinsed under water, but ensure the charging port is dry before connecting the charger.
- Keep the appliance away from children.
- Do not use the appliance if the blade or comb is damaged, as this may cause injury.
- Only use the provided charging cable.
- Avoid extreme temperatures. Do not expose the trimmer to direct sunlight or store it in very hot or cold environments.
- For external use only. Do not use on irritated skin or open wounds.

PRODUCT OVERVIEW

Components

- VGR V-360 Trimmer & Shaver Unit
- Adjustable Limit Guide Comb (0.5-9mm)
- USB Charging Cable
- Cleaning Brush



This image displays the VGR V-360 trimmer, its adjustable guide comb, USB charging cable, and a small cleaning brush, which are all included in the package.

Adjustable limit guide comb



A detailed view of the adjustable limit guide comb for the VGR V-360 trimmer, showing the dial for selecting cutting lengths from 0.5mm to 9mm.

SETUP

Initial Charge

Before first use, fully charge the VGR V-360 trimmer. Connect the USB charging cable to the trimmer's charging port and plug the other end into a compatible USB power source (e.g., computer, USB wall adapter). The LED digital display will indicate the charging status.



This image highlights the LED digital display on the VGR V-360 trimmer, indicating battery status and travel lock, along with the USB charging port.

Attaching the Guide Comb

To attach the adjustable guide comb, align it with the trimmer head and push it firmly until it clicks into place. To adjust the cutting length, rotate the dial on the comb to select your desired setting between 0.5mm and 9mm.

OPERATING INSTRUCTIONS

Powering On/Off

Press the power button located on the front of the trimmer to turn it on. Press the button again to turn it off. The LED display will show the power status.



Bilateral knife net

Both sides of the cutter head can be shaved, making shaving easier.



IPX 6 waterproof grade

The whole body can be washed with water for easy cleaning.



LED liquid crystal display

Display Working and charging status



Switch button

Easy to use and operate

This image illustrates key features of the VGR V-360 trimmer, including its bilateral knife net for easy shaving, IPX6 waterproof rating for full washability, LED liquid crystal display for status, and the simple switch button for operation.

Trimming and Shaving

The VGR V-360 features a dual-sided blade for versatile grooming. For best results:

- **Dry Shave:** Ensure your skin is clean and dry. Move the trimmer against the direction of hair growth for a close shave.
- **Wet Shave:** Apply shaving cream or gel to your skin. The IPX6 waterproof design allows for comfortable wet shaving in the shower. Rinse the trimmer head frequently during use.
- **Trimming with Comb:** Attach the adjustable comb and select your desired length. Move the trimmer smoothly over the area to be trimmed, ensuring even contact with the skin.
- The dual-sided blade allows for precise edging and detailing. Use the edge of the blade to create sharp lines.

MAINTENANCE AND CLEANING

Cleaning the Trimmer

Regular cleaning ensures optimal performance and hygiene. The VGR V-360 is IPX6 waterproof, making cleaning simple:

- 1. Turn off the trimmer and disconnect it from the charging cable.
- 2. Remove the guide comb (if attached).
- 3. Rinse the trimmer head and the comb under running water. You can also use the provided cleaning brush to remove trapped hairs.
- 4. Shake off excess water and allow the trimmer to air dry completely before storing or recharging.



This image shows two VGR V-360 trimmers, one in green and one in orange, highlighting their IPX6 waterproof rating, which allows for easy cleaning under running water.

Blade Care

The stainless steel blades are designed for durability. For prolonged sharpness, ensure the blades are clean and dry after each use. No oiling is typically required for this type of blade.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Trimmer does not turn on.	Low battery or travel lock engaged.	Charge the trimmer fully. Check the LED display for battery status. If travel lock is active, press and hold the power button for a few seconds to deactivate.
Poor trimming/shaving performance.	Blades are clogged with hair, low battery, or comb not properly attached.	Clean the blades and trimmer head thoroughly. Ensure the trimmer is fully charged. Re-attach the guide comb securely.
Trimmer makes unusual noise.	Hair or debris caught in the blade mechanism.	Turn off the trimmer and carefully clean the blade area. Ensure no foreign objects are obstructing the blades.

SPECIFICATIONS

Model	V-360
Power Source	Battery Powered
Battery Type	Integrated/Built-in Rechargeable Lithium-Ion, 500mAh
Runtime	Up to 60 Minutes
Charging Time	Approx. 1.5 hours
Waterproof Rating	IPX6
Cutting Lengths	0.5mm - 9mm (with adjustable comb)
Blade Material	Stainless Steel
Dimensions (LxWxH)	20 x 12.5 x 4.5 cm
Item Weight	270 g

WARRANTY AND SUPPORT

Warranty Information

The VGR V-360 Trimmer & Shaver comes with a **12-month quality warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

The warranty does not cover damage resulting from misuse, accident, unauthorized modification, or failure to follow the instructions in this manual.

Customer Support

For any questions, concerns, or warranty claims, please contact VGR customer service. Refer to the product packaging or the official VGR website for the most current contact information.

