Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Aroepurt /
- > Aroepurt Headwolf Fpad 3 8.4-Inch Tablet Case User Manual

Aroepurt Headwolf Fpad 3 8.4-Inch Tablet Case

Aroepurt Headwolf Fpad 3 8.4-Inch Tablet Case User Manual

Model: Headwolf Fpad 3 8.4-Inch Tablet Case

1. PRODUCT OVERVIEW

This manual provides instructions for the Aroepurt 360 Degree Rotation Multi-Viewing Angles PU Leather Stand Folio Cover, designed specifically for the Headwolf Fpad 3 8.4-Inch Tablet. This case offers comprehensive protection and versatile viewing options for your device.



Image 1.1: The Aroepurt tablet case, showcasing its red and black design and how a tablet fits inside for both vertical and horizontal viewing.

Key features include:

- **360-Degree Rotation:** Allows for both portrait and landscape viewing orientations.
- Multi-Viewing Angles: Integrated stand supports various viewing positions.
- Durable Material: Constructed from premium synthetic PU leather with a soft anti-slip interior.
- Full Body Protection: Guards against scratches, shocks, fingerprints, and dust.
- Reserved Camera Opening: Ensures camera functionality without removing the tablet from the
- Storage Pocket: Convenient for carrying cards, documents, or cash.




Image 1.2: Illustration of the case's all-over protection, covering corners and edges, and highlighting its slim design and precise cutouts for ports.

2. SETUP AND INSTALLATION

Follow these steps to properly install your Headwolf Fpad 3 8.4-Inch Tablet into the case:

- 1. Open the Case: Lay the case flat on a clean surface and open the folio cover.
- 2. **Position the Tablet:** Carefully align your Headwolf Fpad 3 8.4-Inch Tablet with the internal frame of the case. Ensure the tablet's camera aligns with the reserved camera opening on the back of the case.
- 3. **Secure the Tablet:** Gently press the tablet into the protective frame until it is securely seated. Verify that all edges are properly enclosed and that access to ports, speakers, and buttons is unobstructed.
- 4. **Check Camera Alignment:** Confirm that the tablet's rear camera is visible and usable through the case's dedicated opening.

COMPATIBLE WITH A LOT OF TABLET

Please kindly check your tablet size before purchase as shown



Image 2.1: An overhead view showing a tablet securely fitted into the case, emphasizing the precise cutouts and overall compatibility.



Image 2.2: Close-up showing the three pre-cutouts on the back of the case, designed to accommodate tablets with different camera positions.

3. OPERATING INSTRUCTIONS

3.1 Using the Stand Function

The case features an integrated stand with anti-slip strips to provide stable viewing angles.

- 1. Open the Cover: Open the front cover of the case.
- 2. **Fold into Stand:** Fold the cover back to form a triangular stand. The anti-slip strips on the interior of the cover will help secure the tablet at your desired angle.
- 3. **Adjust Angle:** Position the tablet along the anti-slip strips to achieve various viewing angles for typing, watching videos, or browsing.



Image 3.1: The tablet case folded into a stand, illustrating how the anti-slip stripe helps maintain a stable viewing angle.

3.2 360-Degree Rotation

The case allows for 360-degree rotation of your tablet, enabling both portrait and landscape orientations while in stand mode.

- 1. **Access Rotation Mechanism:** With the tablet secured in the case, gently rotate the tablet within its frame.
- 2. **Select Orientation:** Rotate the tablet to either a vertical (portrait) or horizontal (landscape) position as needed
- 3. **Re-adjust Stand:** If using the stand, re-adjust the folded cover to support the tablet in its new orientation.

ADJUSTABLE MULTIPLE ANGLES

Supports multiple viewing angles with 360° free rotate



Image 3.2: Visual representation of the 360-degree rotation capability, showing the tablet rotating from landscape to portrait mode within the case.

3.3 Using the Storage Pocket

The case includes a convenient storage pocket on the front cover.

- Access Pocket: Locate the large welt pocket on the exterior of the front cover.
- Store Items: Use this pocket to store small items such as cards, documents, or cash.



Image 3.3: The tablet case displaying its storage pocket, with examples of cards and cash placed inside.

4. MAINTENANCE AND CARE

To ensure the longevity and appearance of your Aroepurt tablet case, follow these maintenance guidelines:

- **Cleaning:** Wipe the exterior PU leather surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the material.
- Stain Removal: For minor stains, use a mild soap solution on a damp cloth and gently blot the affected area. Wipe clean with a fresh damp cloth and allow to air dry.
- Avoid Extreme Conditions: Do not expose the case to direct sunlight for prolonged periods or to extreme temperatures, as this may cause discoloration or material degradation.
- Storage: When not in use, store the case in a cool, dry place away from direct sunlight.

5. TROUBLESHOOTING

• Tablet Does Not Fit: Ensure your tablet is the Headwolf Fpad 3 8.4-Inch model. This case is specifically designed for this model. Verify the tablet's dimensions against the case specifications.

- **Stand Instability:** Ensure the anti-slip strips are clean and free of debris. Adjust the tablet's position on the strips for better grip.
- Camera Obstruction: Confirm the tablet is correctly seated within the case, aligning the camera with the designated cutout. The case features multiple cutouts to accommodate slight variations in camera placement for compatible tablets.
- No Auto-Sleep/Wake Function: Please note that this case does not support the auto-sleep/wake function of any tablet. You will need to manually lock/unlock your tablet.

6. SPECIFICATIONS


Feature	Detail
Brand	Aroepurt
Compatible Devices	Headwolf Fpad 3 8.4-Inch Tablet
Material	Premium Synthetic PU Leather
Special Features	360 Degree Rotation, Multi-Viewing Angles, Anti-slip Strip, Card Insertion, Storage Pocket, Thickened Anti-drop Corner Protector
Form Factor	Flip Case
Color	Red (as per current product)
Product Dimensions	0.39 x 0.39 x 0.39 inches
Item Weight	2.46 ounces
Manufacturer	SSPB-BT1

7. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Aroepurt tablet case, please contact the seller directly through the platform where the purchase was made. Please refer to your purchase documentation for specific warranty information, as it may vary by retailer.

Seller: Huayijie-us

Please retain your proof of purchase for any warranty claims or support inquiries.



Satechi Vegan-Leather Magnetic Case for iPad Pro - Quick Guide

A quick guide detailing the installation and compatibility of the Satechi Vegan-Leather Magnetic Case for iPad Pro, designed for seamless integration with Apple devices and accessories.



PIVOT A35A User Guide: Protective Case for iPad Mini (6th Gen & A17 Pro)

Official user guide for the PIVOT A35A case, offering detailed instructions on installation, features, and compatibility for iPad Mini (6th generation) and iPad Mini (A17 Pro). Learn about protection, functionality, and mounting solutions.



Typecase FOLIO User Manual for Surface 13-inch Tablet

Comprehensive user manual for the Typecase FOLIO keyboard case, compatible with Surface 13inch tablets. Covers setup, Bluetooth pairing, function keys, touchpad gestures, charging, troubleshooting, technical specifications, and FCC compliance.