Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tefal E308SB74

Tefal Primary Stainless Steel Cookware Set E308SB74

User Instruction Manual

Introduction

Thank you for choosing the Tefal Primary Stainless Steel Cookware Set, Model E308SB74. This 11-piece set is designed for everyday cooking, featuring durable stainless steel construction, comfortable handles, and glass lids. It is compatible with all cooktops, including induction, and is dishwasher safe for easy cleaning. This manual provides essential information for the safe and effective use and maintenance of your new cookware.



Image: The complete Tefal Primary 11-piece stainless steel cookware set, showcasing various pots, a saucepan, and cooking utensils.

Set Components:

- 18 cm Pot with Lid
- 20 cm Pot with Lid
- 24 cm Pot with Lid
- Saucepan (size not specified in detail, but part of the 11-piece set)
- Additional Lids (total of 3 lids for the pots)
- Cooking Utensils (ladle, spatula, spoon - total of 3)

Setup and First Use

1. **Unpacking:** Carefully remove all cookware and accessories from the packaging. Retain packaging for future storage or transport if needed.
2. **Initial Cleaning:** Before first use, wash all items thoroughly with warm soapy water. Rinse well and dry completely to remove any manufacturing residues.
3. **Cooktop Compatibility:** This cookware set is compatible with all heat sources, including gas, electric, ceramic, halogen, and induction cooktops. Ensure the base of the cookware is clean and dry before placing it on the cooktop.



Image: Symbols illustrating the cookware's compatibility with various heat sources, including gas, electric, ceramic, and induction.



Image: The base of a Tefal pot, highlighting the 'Thermo-Fusion' and 'Induction Technology' markings, confirming its suitability for induction cooktops.

Operating Instructions

Cooking:

- **Heat Management:** Stainless steel cookware heats efficiently. Start with medium heat and adjust as needed. Avoid excessively high heat, especially when the pan is empty, to prevent damage and discoloration.
- **Even Heat Distribution:** The thick base of the cookware ensures even heat distribution for consistent cooking results.
- **Measurement Marks:** Pots feature internal measurement marks for precise liquid quantities, simplifying recipes.




Image: A close-up view of the interior of a pot, clearly showing the engraved measurement marks for easy liquid volume assessment.

Lids and Handles:

- **Glass Lids:** The transparent glass lids allow you to monitor your cooking without lifting the lid, preserving heat and moisture. They are equipped with steam vents to prevent boil-overs.
- **Comfortable Handles:** The stainless steel handles are designed for a comfortable and secure grip during cooking and serving.



Image: A detailed shot of the ergonomic, heat-resistant handle of a Tefal pot, designed for comfortable and secure handling.

Maintenance and Cleaning

- **Dishwasher Safe:** All items in this cookware set are dishwasher safe for convenient and easy cleaning.
- **Hand Washing:** For best results and to maintain the shine of your stainless steel, hand washing with warm soapy water and a soft sponge is recommended. Avoid abrasive cleaners or scouring pads that can scratch the surface.
- **Stubborn Food Residues:** For burnt-on food, soak the cookware in warm soapy water before cleaning. A paste of baking soda and water can also be used for gentle scrubbing.

- **Drying:** Always dry your cookware thoroughly after washing to prevent water spots and maintain its appearance.



Image: A Tefal saucepan and frying pan positioned near a dishwasher, emphasizing their dishwasher-safe design for effortless cleaning.

Troubleshooting

- **Discoloration/Tarnishing:** Stainless steel can sometimes show blue or rainbow-like discoloration, especially if heated empty or exposed to high heat. This is typically harmless and can often be removed with a stainless steel cleaner or a mixture of vinegar and water.
- **Food Sticking:** Ensure you use enough cooking oil or fat. Preheat the pan properly before adding food. Avoid overcrowding the pan, which can lower the temperature and cause sticking.
- **White Spots/Mineral Deposits:** These can occur due to minerals in water or salt added to cold water. To remove, boil a solution of water and vinegar (1:1 ratio) in the pot, then wash and dry.

Specifications

Feature	Detail
Brand	Tefal
Model Number	E308SB74
Material	Stainless Steel (18/10)
Handle Material	Stainless Steel
Lid Material	Glass
Number of Pieces	11
Included Components	18cm Pot with Lid, 20cm Pot with Lid, 24cm Pot with Lid, Saucepan, 3 Cooking Utensils
Cooktop Compatibility	All heat sources, including Induction, Gas, Electric, Ceramic, Halogen
Dishwasher Safe	Yes
Oven Safe	No

Year of Manufacture	2024
Package Weight	6.53 kg
Package Dimensions	53.0 × 36.9 × 23.8 cm

Warranty

The Tefal Primary Stainless Steel Cookware Set comes with a**10-year warranty** on its stainless steel components, covering manufacturing defects under normal household use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, neglect, or normal wear and tear.



Image: Tefal Primary cookware highlighting its high-quality 18/10 stainless steel construction and a prominent 10-year warranty badge.

Support

For further assistance, product inquiries, or warranty claims, please contact Tefal customer service. You can find contact information on the official Tefal website or through your local retailer.

Visit the official Tefal Store on Amazon for more information and products.

© 2024 Tefal. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DFZ2L7DM

More documents and user manuals: **https://manuals.plus/**