

[manuals.plus](#) /

› [Koolatron](#) /

› [Koolatron Kenmore Deep Freezer Model KKCF07-W User Manual](#)

Koolatron KKCF07-W

Koolatron Kenmore Deep Freezer User Manual

Model: KKCF07-W

1. PRODUCT OVERVIEW

The Koolatron Kenmore Deep Freezer, Model KKCF07-W, is a versatile 7.0 cubic feet appliance designed for flexible food storage. This unit functions as both a deep freezer and a convertible refrigerator, adapting to various household needs. Its robust design is suitable for diverse environments, including garages, basements, and cottages. Key features include a spacious interior, adjustable temperature control, and an easy-access drain for simplified maintenance.



Figure 1: Front view of the Kenmore Deep Freezer.

2. SAFETY INFORMATION

Before operating this appliance, read all instructions thoroughly to prevent personal injury or property damage. Keep this manual for future reference. Ensure the unit is placed on a stable, level surface and is properly grounded. Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance. Avoid placing heavy objects on top of the freezer lid.

3. SETUP AND INSTALLATION

- Unpacking:** Carefully remove all packaging materials, including tape and internal packing. Keep packaging materials out of reach of children.
- Placement:** Position the freezer on a flat, stable surface away from direct sunlight and heat sources. Ensure adequate ventilation around the unit. The space-saving flat back design allows for placement closer to walls. This unit is designed to be garage-ready.

3. **Leveling:** Adjust the leveling foot to ensure the unit is stable and level. Proper leveling helps in efficient operation and prevents vibrations.
4. **Power Connection:** Plug the freezer into a dedicated, grounded electrical outlet. Avoid using extension cords. Allow the unit to stand upright for at least 2-4 hours before plugging it in to allow refrigerants to settle.

7 CUBIC FOOT CAPACITY




Figure 2: The Kenmore Deep Freezer is designed to be garage-ready.

4. OPERATING INSTRUCTIONS

4.1. Convertible Mode Selection

This unit offers versatile cooling with a front-mount dial that allows you to switch between fridge and freezer modes. The dial is located on the lower front panel of the appliance.



GARAGE-READY IN FREEZER MODE



Figure 3: Front-mounted control dial for mode and temperature adjustment.

- **Freezer Mode:** Set the dial to the 'Freezing' range for temperatures between -12°C (10°F) to -24°C (-11°F).
- **Refrigerator Mode:** Set the dial to the 'Cooling' range for temperatures between 0°C (32°F) to 8°C (46°F).

4.2. Temperature Adjustment

The adjustable thermostat ensures you can set the perfect temperature for your food and beverages. Rotate the dial to your desired setting. Higher numbers typically indicate colder temperatures in freezer mode, and lower numbers indicate warmer temperatures in refrigerator mode.

4.3. Internal Organization

The freezer includes a hanging basket for easy organization of smaller or frequently accessed items. The balanced hinge lid stays open, providing hands-free convenience during loading and unloading.

EASY ORGANIZATION



Figure 4: Interior view with the removable hanging basket.

5. MAINTENANCE

5.1. Defrosting

This unit features manual defrost. Defrosting is simplified with an easy-access drain and leakproof plug located at the front bottom of the unit. To defrost:

1. Unplug the appliance from the power outlet.
2. Remove all food items and store them in another freezer or cooler.
3. Place a shallow pan or towel under the drain plug to collect water.
4. Remove the drain plug to allow water to flow out.
5. Once defrosted, clean the interior with a mild detergent and warm water.
6. Replace the drain plug and plug the unit back in. Allow it to cool down before returning food.



Figure 5: Front-mounted drain plug for convenient defrosting.

5.2. Cleaning

Regularly clean the interior and exterior of the freezer with a soft cloth and mild, non-abrasive cleaner. Ensure the door gasket is clean and free of debris to maintain an airtight seal.

6. TROUBLESHOOTING

- Appliance does not operate:** Check if the power cord is securely plugged into a live outlet. Verify the circuit breaker or fuse is not tripped. Ensure the temperature control dial is not set to 'OFF'.
- Temperature is not cold enough:** Adjust the temperature control to a colder setting. Ensure the lid is closing properly and the gasket is sealing. Avoid frequent lid openings. Check if the appliance is placed near a heat source or in direct sunlight.
- Excessive frost buildup:** This is a manual defrost unit. Regular defrosting is required. Ensure the lid is properly sealed and not left open for extended periods.
- Unusual noises:** Some operational noises are normal (e.g., refrigerant circulation, compressor starting/stopping). Ensure the unit is level and not touching any walls or other appliances.

7. SPECIFICATIONS

Feature	Specification
Brand	Koolatron
Model Info	KKCF07-W
Item Weight	65.3 pounds
Product Dimensions	22.05 x 30.31 x 33.46 inches
Capacity	7 Cubic Feet
Installation Type	Freestanding
Color	Crystal White
Voltage	115 Volts
Wattage	250 KW
Defrost Type	Manual


Feature	Specification
Door Hinges	Top
Door Material Type	Painted Metal
Shelves	1 (hanging basket)
Included Components	Convertible freezer/fridge; 1 x hanging basket


8. WARRANTY AND SUPPORT

Every Kenmore product comes with a 2-year warranty, ensuring durability and reliability. This warranty protects your investment and guarantees a high-quality product built to last. For support or warranty claims, please refer to the contact information provided with your purchase documentation or visit the official Koolatron website.

© 2024 Koolatron. All rights reserved.

Related Documents - KKCF07-W

 <p>Koolatron KTCF155 Chest Freezer User Manual</p> <p>Comprehensive user manual for the Koolatron KTCF155 chest freezer, covering warranty, installation, operating instructions, care and cleaning, and troubleshooting. Includes important safety information and practical tips.</p>
 <p>Koolatron SmartKool Portable Cooler Freezer User Manual and Warranty</p> <p>Detailed user manual and warranty information for Koolatron SmartKool portable cooler freezers (SK30, SK40, SK50). Covers setup, operation, safety guidelines, troubleshooting, technical specifications, and maintenance for optimal use in vehicles and camping.</p>
 <p>Koolatron Compact Fridge User Manual: KBC46-W & KBC88-W-CH Installation, Operation, and Maintenance Guide</p> <p>Official user manual for Koolatron compact refrigerators, models KBC46-W and KBC88-W-CH. Includes detailed instructions on warranty, safety precautions, installation, features, maintenance, and troubleshooting.</p>
 <p>Koolatron WC12MG 12-Bottle Wine Cooler User Guide and Warranty</p> <p>Official user guide and warranty information for the Koolatron WC12MG 12-bottle thermoelectric wine cooler. Covers features, specifications, safety, installation, operation, maintenance, and troubleshooting.</p>
 <p>Koolatron WC18-MG 18-Bottle Dual Zone Wine Cellar User Manual and Guide</p> <p>This user manual provides comprehensive instructions for the Koolatron WC18-MG 18-bottle dual-zone wine cellar. It covers warranty, features, specifications, safety guidelines, installation steps, operating procedures, maintenance tips, and a troubleshooting guide.</p>



[Kenmore Garage-Ready Chest Freezer Use & Care Guide \(KKCF05-C, KKCF07-SSB\)](#)

Comprehensive use and care guide for Kenmore Garage-Ready Chest Freezers (models KKCF05-C, KKCF07-SSB). Covers safety instructions, installation, operation, features, food storage, defrosting, cleaning, troubleshooting, and warranty information.